Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Havit TW952 PRO RGB

Havit TW952 Pro RGB Audio Series TWS Earbuds User Manual

Model: TW952 PRO RGB

Brand: Havit

Introduction

Thank you for choosing the Havit TW952 Pro RGB Audio Series TWS Earbuds. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new earbuds. Please read this manual carefully before use to ensure optimal performance and longevity of your device.



Image: The Havit TW952 Pro RGB TWS Earbuds shown alongside their charging case. The case features RGB lighting and a distinct design, while the earbuds are white with subtle light accents.

Setup

Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the charging case to a USB power source using the provided charging cable. The LED indicators on the case will show the charging status. Once fully charged, the indicators will change or turn off.

Pairing with Your Device

1. Ensure the earbuds are in the charging case and the case is charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and their LED indicators will flash.
3. On your device (smartphone, tablet, computer), enable Bluetooth.
4. Search for "Havit TW952 Pro" or a similar name in the list of available Bluetooth devices.
5. Select the earbuds to connect. Once connected, a voice prompt will confirm the successful pairing, and the earbud LEDs will stop flashing.
6. If pairing fails, place the earbuds back in the case, close it, and repeat the steps.

Operating

Touch Controls

The Havit TW952 Pro earbuds feature touch-sensitive controls for easy operation:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds (e.g., Siri, Google Assistant).
- **Game Mode/Music Mode:** Press and hold the left earbud for 2 seconds to switch between modes.

Active Noise Cancellation (ANC)

The earbuds are equipped with Adaptive ANC technology. To activate or deactivate ANC, press and hold the right earbud for 2 seconds. A voice prompt will confirm the change in mode.

Maintenance

Proper maintenance ensures the longevity and performance of your earbuds:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove the silicone ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- **Charging Ports:** Keep the charging contacts on the earbuds and inside the case clean and free of debris. Use a dry cotton swab if needed.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or direct sunlight. Avoid dropping or subjecting them to strong impacts.

Troubleshooting

If you encounter issues with your Havit TW952 Pro earbuds, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Earbuds won't turn on	Low battery	Place earbuds in the charging case and charge fully.
Cannot pair with device	Bluetooth off; earbuds not in pairing mode; interference	Ensure Bluetooth is on. Open case to enter pairing mode. Move closer to device. Forget device and re-pair.
No sound from one earbud	Low battery; not properly paired; earbud malfunction	Charge both earbuds. Re-pair. If issue persists, contact support.

Problem	Possible Cause	Solution
Poor sound quality	Ear tips not sealed; low battery; interference	Adjust ear tips for a snug fit. Charge earbuds. Move away from interference sources.
Touch controls not responding	Dirty sensor; temporary glitch	Clean the touch sensor area. Place earbuds back in case, close, then reopen to reset.

Specifications

Detailed technical specifications for the Havit TW952 Pro RGB Earbuds:

- **Model Name:** TWS Earbuds
- **Item Model Number:** TW952 PRO RGB
- **Brand Name:** Havit
- **Connectivity Technology:** Wireless
- **Headphones Form Factor:** In-Ear
- **Noise Control:** Active Noise Cancellation
- **Color:** Multi-color
- **Product Dimensions:** 7.2 x 5 x 3 cm
- **Item Weight:** 200 grams
- **Batteries:** 2 Lithium Ion batteries required (Included)
- **Included Components:** Charging Station
- **Age Range Description:** Adult
- **Material:** Metal
- **Cable Feature:** Without Cable
- **Date First Available:** February 28, 2023

Warranty and Support

Havit products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included in your product packaging or visit the official Havit website. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BN1M9ZT5

More documents and user manuals: **https://manuals.plus/**