Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aoxun 58" Oak Wood TV Stand

Aoxun 58" Oak Wood TV Stand Instruction Manual

Brand: Aoxun | **Model:** 58" Oak Wood TV Stand

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Aoxun 58" Oak Wood TV Stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.
The Aoxun 58" Oak Wood TV Stand is designed to accommodate televisions up to 65 inches and features multiple storage options, including open shelves and closed compartments, to organize your entertainment devices and media.

Safety Information

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all parts are present before beginning assembly. Refer to the parts list.
- Do not overtighten screws, as this may damage the material.
- Keep small parts away from children during assembly.
- For stability, place the TV stand on a level surface.
- Do not exceed the maximum weight capacity for the top surface (160 lbs) and shelves (35 lbs).

Package Contents

Please verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- All wooden panels for the TV stand structure.
- Hardware kit (screws, dowels, cam locks, etc.).
- 6 solid wooden feet.
- Cabinet door bouncers.

- Drawer tracks.
- Assembly instructions sheet.

Setup and Assembly

Assembly typically requires two people and approximately 1-2 hours. A Phillips head screwdriver and a hammer (not included) may be required.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Compare each part to the provided parts list in the assembly instructions to ensure everything is present.
2. **Assemble the Base:** Attach the wooden feet to the bottom panel of the TV stand using the provided hardware. Ensure they are securely fastened.
3. **Construct the Main Frame:** Connect the side panels, back panel, and internal dividers to the base using the cam locks, dowels, and screws as indicated in the assembly diagram.
4. **Install Shelves:** Insert the open shelf into its designated slot.
5. **Assemble and Install Drawer:** Assemble the drawer components according to the instructions. Install the drawer tracks onto the stand and then slide the assembled drawer into place. Ensure smooth operation.
6. **Attach Cabinet Doors:** Mount the fluted cabinet doors to the designated compartments. Adjust hinges if necessary for proper alignment. Install cabinet door bouncers for smooth closing.
7. **Final Check:** Once assembled, gently lift and move the stand to its desired location. Ensure all connections are tight and the stand is stable.



Figure 1: Product Dimensions. This image illustrates the overall dimensions of the TV stand: 57 inches wide, 22 inches high, and 15.75 inches deep. It also shows the weight capacity for the top surface (160 lbs) and the open shelf (35 lbs), and the 5.5-inch clearance for cleaning underneath.



Figure 2: Storage Features. This image details the various storage options available: a spacious tabletop, an open shelf for media devices, a large pull-out drawer, and a hidden cabinet with fluted doors for concealed storage.



Figure 3: Key Features. This image highlights specific design and functional elements: the cabinet door bouncer for soft closing, integrated cable holes for wire management, silky smooth drawer tracks for easy operation, and the six solid wooden feet providing enhanced stability.

Operating Instructions

Once assembled, your Aoxun TV stand is ready for use.

- **Placing Your Television:** Carefully place your television on the top surface. Ensure the TV's base is centered and stable. This stand is designed to fit TVs up to 65 inches. Do not exceed the maximum weight capacity of 160 lbs.
- **Organizing Devices:** Use the open shelf for media players, gaming consoles, or soundbars. Utilize the integrated cable holes in the back panel to manage and route wires neatly, preventing tangles and maintaining a clean appearance.
- **Utilizing Storage:**
  - The large drawer provides concealed storage for accessories, remote controls, or small items.
  - The hidden cabinet behind the fluted doors offers ample space for larger items, books, or other media.

The cabinet door bouncers ensure smooth and quiet closing.



Figure 4: Operational Setup. This image displays the TV stand in a typical living room environment, showcasing a television placed above it, and various media devices and decorative items arranged on its surfaces and within its compartments.

Maintenance and Care

To ensure the longevity and appearance of your Aoxun TV stand, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish. Dry immediately with a clean cloth.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood finish.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat and Moisture:** Do not place hot items directly on the surface. Use coasters or protective pads. Avoid excessive moisture.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if

necessary.



Figure 5: Cleaning Space. This image demonstrates the ample 5.5-inch clearance beneath the TV stand, allowing for easy cleaning, including the use of robot vacuum cleaners.

Troubleshooting

Problem	Possible Cause	Solution
Stand is wobbly or unstable.	Loose fasteners; uneven floor.	Ensure all screws and cam locks are tightened. Move the stand to a level surface or use shims if necessary.
Drawer does not slide smoothly.	Drawer tracks misaligned; debris in tracks.	Check that drawer tracks are correctly installed and aligned. Clean any dust or debris from the tracks.

Problem	Possible Cause	Solution
Cabinet doors are misaligned or do not close properly.	Hinges not adjusted correctly; door bouncer issue.	Adjust the hinges on the cabinet doors. Ensure the door bouncers are installed correctly and not obstructed.
Missing parts during assembly.	Packaging error.	Review the parts list. Contact Aoxun customer support with the specific part number(s) needed.

Specifications

- **Brand:** Aoxun
- **Model:** 58" Oak Wood TV Stand
- **Material:** Oak Wood (finish)
- **Overall Dimensions (Approx.):** 57" (Width) x 15.75" (Depth) x 22" (Height)
- **TV Size Compatibility:** Up to 65 inches
- **Weight Capacity (Top Surface):** 160 lbs
- **Weight Capacity (Open Shelf):** 35 lbs
- **Storage:** 1 Open Shelf, 1 Large Drawer, 1 Hidden Cabinet with Fluted Doors
- **Features:** Cable Management Holes, Cabinet Door Bouncers, Solid Wooden Feet
- **UPC:** 799413407093
- **ASIN:** B0DRG7PQZF

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Aoxun website. Please have your model number (58" Oak Wood TV Stand) and ASIN (B0DRG7PQZF) ready when contacting support.
Aoxun Official Store: Visit Aoxun Store on Amazon

© 2024 Aoxun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BN5C4B97

More documents and user manuals: **https://manuals.plus/**