Rainbow High 587514C3

Rainbow High Dream & Design Fashion Studio Playset

Instruction Manual

Model: 587514C3

Introduction

Welcome to the world of fashion design with the Rainbow High Dream & Design Fashion Studio Playset. This playset provides aspiring designers with the tools and inspiration to create unique fashion pieces for their Rainbow High dolls. It includes an exclusive Skyler Bradshaw doll, a functional workstation, and a no-sew fashion kit for endless creative possibilities.



Image: The Rainbow High Dream & Design Fashion Studio Playset, showcasing the Skyler doll, workstation, and various accessories within its retail packaging.

Recommended for ages 4-12 years.

Included Components (40+ Pieces)

Before beginning, please ensure all components listed below are present in your playset:

- 1 Fashion doll (Exclusive Skyler Bradshaw)
- 1 Complete doll outfit
- 1 Pair of doll boots
- 1 Pair of earrings
- 1 Doll stand
- 1 Water Reveal Design Sketchbook
- 1 Fashion Design Worktable
- Designer Must-Haves: Sewing Machine (non-functional), Iron, Pencils, Push Pins, Coffee Cup, Scissors, Plant
- No-Sew Fashion Designer Kit: 5 Rolls of Rainbow High Fabric, Mannequin, Mannequin Push-Pins



Image: A complete overview of all 40+ pieces included in the playset, neatly arranged on a white surface.

Setup

1. **Unpack Components:** Carefully remove all items from the packaging. Dispose of packaging materials responsibly.
2. **Assemble Workstation:** Place the fashion design worktable on a flat, stable surface. Arrange the sewing machine, iron, and other small designer accessories on the worktable as desired.
3. **Set up Mannequin:** Assemble the mannequin stand and place the mannequin on top. This will be used for draping fabrics.
4. **Prepare Fabric Rolls:** Unroll the included Rainbow High fabrics and have them ready for design.
5. **Position Skyler Doll:** Place the exclusive Skyler Bradshaw doll at the workstation or near the mannequin, ready for her design tasks.



Image: The Skyler doll is positioned beside the fully assembled fashion studio workstation, which includes a sewing machine, iron, and various fabric rolls.

Operating the Playset

The Rainbow High Dream & Design Fashion Studio offers multiple ways to engage in creative play:

1. **No-Sew Fashion Design Kit:**
    - Select a fabric roll and drape it around the mannequin.
    - Use the mannequin push-pins to secure the fabric in place, creating various dress and outfit designs.
    - Experiment with different fabrics and draping techniques to achieve over 300 unique looks.



Image: A collage demonstrating the no-sew design process, showing hands pinning fabric onto a mannequin and various completed no-sew outfits.

2. **Water Reveal Design Sketchbook:**
    - Open the sketchbook to reveal blank design pages.
    - Using a small amount of water (e.g., with a brush or damp cloth), gently apply it to the pages.
    - Watch as hidden fashion designs magically appear, inspiring new creations.
3. **Fashion Designer Worktable & Accessories:**
    - Utilize the miniature sewing machine (for pretend play only, does not actually sew), iron, scissors, and other tools to simulate a real fashion studio environment.
    - The Skyler doll can interact with these accessories, enhancing imaginative play scenarios.



Image: The Skyler doll is shown in four different poses, demonstrating interaction with the playset's accessories: sketching in the book, cutting fabric, using the sewing machine, and ironing a garment.

4. **Exclusive Skyler Bradshaw Doll:**
    - The fully articulated Skyler doll can be posed in various ways to model designs or engage in design activities.
    - Her outfit and accessories are removable and interchangeable with other Rainbow High doll fashion pieces (sold separately).



Image: A detailed view of the exclusive Skyler Bradshaw doll, featuring her distinctive blue hair, denim skirt, and blue boots. The image also indicates her height as 11 inches (28 cm).

Video: An official product video from MGA Entertainment showcasing the Rainbow High Dream & Design Fashion Studio Playset in action, demonstrating its features and play possibilities.

Maintenance

- **Cleaning:** Wipe down the workstation and plastic accessories with a soft, damp cloth. Do not immerse electronic components (if any) in water.
- **Doll Care:** Gently brush the doll's hair to prevent tangles. Avoid harsh chemicals on the doll or clothing.
- **Storage:** Store all components in a clean, dry place away from direct sunlight to prevent fading or damage. Keep small parts in a designated container to avoid loss.

Troubleshooting

- **Missing Parts:** If any components are missing upon unboxing, please refer to the Warranty & Support section for contact information.
- **Water Reveal Sketchbook Not Working:** Ensure the sketchbook pages are completely dry before attempting to reveal new designs. Use clean water for best results.
- **Doll Hair Tangles:** Use a wide-tooth comb and a small amount of water or doll-safe conditioner to gently detangle the doll's hair.

Specifications

Feature	Detail
Product Dimensions	17.8 x 5.3 x 12 inches
Item Weight	1 pound
Model Number	587514C3
Manufacturer	MGA Entertainment
Recommended Age	4 - 12 years
Release Date	September 27, 2023

Safety Information

Refer to the complete owner's manual provided with the product for detailed safety guidelines and warnings. This playset contains small parts which may pose a choking hazard for children under 3 years of age. Adult supervision is recommended during play.

Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact MGA Entertainment directly through their official website or customer service channels. Specific warranty terms and conditions may vary by region.

© 2023 MGA Entertainment. All rights reserved. Rainbow High is a trademark of MGA Entertainment.