Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

QSDXNYDC Mini Lithium chainsaw

QSDXNYDC Cordless Mini Chainsaw User Manual

Model: Mini Lithium Chainsaw

1. Introduction

This user manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your QSDXNYDC Cordless Mini Chainsaw. Designed for portability and efficiency, this 6-inch mini chainsaw is compatible with Makita 18V LXT series batteries (battery not included) and is ideal for light wood cutting, tree branch pruning, and general gardening tasks. Please read this manual thoroughly before first use to ensure proper handling and to maximize the lifespan of your tool.



Figure 1: QSDXNYDC Cordless Mini Chainsaw and included accessories.

2. Safety Instructions

Always prioritize safety when operating power tools. Failure to follow these instructions may result in serious injury or property damage.

- **Personal Protective Equipment (PPE):** Always wear appropriate safety gear, including safety glasses, gloves, and sturdy footwear. Hearing protection is recommended for extended use.
- **Accidental Activation Prevention:** The chainsaw is equipped with a security lock. The security lock and start button must be pressed simultaneously to activate the chainsaw. Always engage the security lock when the tool is not in use or when changing accessories.
- **Protective Baffle:** The integrated safety baffle helps prevent wood debris from splashing towards the user. Ensure it is in place and undamaged before operation.
- **Secure Grip:** Utilize the anti-slip textured handle to maintain a firm grip on the mini chainsaw during operation.
- **Battery Safety:** Always remove the battery from the chainsaw when not in use, during assembly, maintenance, or

when storing the tool. Use only compatible Makita 18V LXT series batteries.

- **Work Area:** Keep the work area clear of obstructions and ensure good lighting. Do not operate the chainsaw in wet conditions or near flammable liquids or gases.
- **Chain Maintenance:** A loose chain can be dangerous. Regularly check chain tension and tighten as necessary. Refer to the "Setup" section for chain adjustment.
- **Overload Protection:** The brushless motor is designed for efficient cutting. Avoid forcing the saw through material, which can lead to overheating and damage.



Figure 2: Trigger safety lock and protective baffle for enhanced user safety.

3. Package Contents

Verify that all items are present upon unboxing:

- Electric Chain Saw (Chainsaw body) x1
- Guide Chain x2 (One pre-installed)
- Screwdriver x1
- Chainsaw File x1
- Chainsaw Guide Protector x1
- User Manual x1
- Anti-cut Gloves x1 pair



Figure 3: All items included in the package.

4. Product Overview

Familiarize yourself with the components of your mini chainsaw:

A. Saw Chain: The cutting component.

B. Guide Bar: Supports and guides the saw chain.

C. Protective Baffle: Shields against debris.

D. Handle: For gripping the tool.

E. Safety Switch: Prevents accidental starts.

F. Trigger: Activates the motor.

G. Battery Interface: Connects to Makita 18V LXT batteries.

H. Heat Dissipation Vents: For motor cooling.



Figure 4: Key components and approximate dimensions of the mini chainsaw.

5. Setup

5.1 Battery Installation

This chainsaw is designed to be compatible with Makita 18V LXT series batteries (BL1850B, BL1860B, BL1830B, BL1840B, BL1820B). Ensure the battery is fully charged before use.

1. Align the battery with the battery interface on the chainsaw handle.
2. Slide the battery firmly into place until it clicks, indicating it is securely locked.
3. To remove the battery, press the release button on the battery and slide it out.



Figure 5: Compatibility with Makita 18V LXT batteries. Always remove the battery when not in use.

5.2 Chain Installation and Replacement

The chainsaw comes with one chain pre-installed and one spare. Follow these steps to replace or install a new chain:

1. **Step 1: Loosen the Compression Nut.** Use the provided screwdriver to loosen the compression nut on the side cover.
2. **Step 2: Open the Side Cover.** Carefully remove the side cover to expose the guide bar and chain.
3. **Step 3: Remove the Old Chain.** Lift the old chain off the sprocket and guide bar.
4. **Step 4: Replace the New Chain.** Place the new chain around the guide bar, ensuring the cutting teeth are oriented correctly (pointing in the direction of rotation).
5. **Step 5: Put on the Cover.** Realign the side cover and place it back onto the chainsaw body.
6. **Step 6: Tighten the Screws.** Securely tighten the compression nut to hold the side cover and guide bar in place. Ensure the chain has proper tension – it should be snug but still able to be pulled slightly away from the guide bar.




Figure 6: Detailed steps for changing the saw chain.

6. Operating Instructions

6.1 Starting the Chainsaw

With a charged battery installed and all safety checks performed:

1. Hold the chainsaw firmly with one hand on the handle.
2. Simultaneously press the safety switch (usually a button or lever near the trigger) and then squeeze the trigger to start the motor.
3. Release the safety switch once the motor is running. The chainsaw will continue to operate as long as the trigger is pressed.
4. To stop the chainsaw, release the trigger.

6.2 Cutting Techniques

The QSDXNYDC mini chainsaw is designed for efficient cutting of branches and small logs up to 6 inches in diameter.

- **Branch Cutting:** For smaller branches, position the chainsaw firmly against the branch and allow the saw to do the work. Do not apply excessive pressure.
- **Larger Diameter Cuts:** For branches approaching the 6-inch capacity, make a small undercut first if possible to prevent pinching, then complete the cut from the top.
- **Brushless Motor Efficiency:** The high-efficiency brushless motor provides strong power and fast cutting speeds (up to 26 FT/S chain speed), allowing it to cut a 6-inch log in approximately 8 seconds.
- **One-Hand Operation:** Its lightweight design (approx. 2.4 lbs without battery) allows for comfortable one-hand operation, reducing fatigue during extended use.



Figure 7: The brushless motor provides high-efficiency cutting.



Figure 8: The lightweight design enables comfortable one-hand operation.



Figure 9: Versatile applications of the QSDXNYDC mini chainsaw.

7. Maintenance

Regular maintenance ensures optimal performance and extends the life of your chainsaw.

- **Chain Tension:** Periodically check the chain tension. A chain that is too loose can come off the guide bar, while a chain that is too tight can cause excessive wear and reduce cutting efficiency. Adjust as described in Section 5.2.
- **Chain Lubrication:** While this model does not have an automatic oiling system, applying a small amount of chainsaw bar and chain oil directly to the chain and guide bar before and during use (especially for longer tasks) is highly recommended to reduce friction and wear.
- **Chain Sharpening:** Use the included chainsaw file to keep the chain sharp. A sharp chain cuts more efficiently and safely. Refer to standard chainsaw chain sharpening guides for proper technique.
- **Cleaning:** After each use, remove the battery and clean the chainsaw. Use a brush or compressed air to remove sawdust, debris, and resin from the guide bar, chain, and motor vents.

- **Storage:** Store the chainsaw in a dry, secure place, out of reach of children. Always install the chainsaw guide protector when storing. Remove the battery before storage.
- **Heat Dissipation:** Ensure the heat dissipation vents are clear of debris to prevent thermal overload and maximize motor life.



Figure 10: Clear heat dissipation vents are crucial for motor longevity.

8. Troubleshooting

This section addresses common issues you might encounter with your mini chainsaw.

Problem	Possible Cause	Solution
Chainsaw does not start.	Battery not installed correctly or discharged. Safety switch not pressed simultaneously with trigger.	Ensure battery is fully charged and securely installed. Press the safety switch and trigger at the same time.
Chain comes loose frequently.	Chain tension is too low. Chain stretching (normal with new chains).	Tighten the chain tension as described in Section 5.2. Re-tension the chain after initial uses.
Chainsaw cuts slowly or binds.	Dull chain. Incorrect chain tension. Overloading the saw.	Sharpen or replace the chain. Adjust chain tension. Do not force the saw; allow it to cut at its own pace.
Excessive vibration or noise.	Loose chain or components. Damaged chain or guide bar.	Check and tighten all components, especially chain tension. Inspect chain and guide bar for damage; replace if necessary.

9. Specifications

Feature	Detail
Brand	QSDXNYDC
Model Number	Mini Lithium chainsaw (MT-DJ)

Feature	Detail
Power Source	Battery Powered (Compatible with Makita 18V LXT series)
Horsepower	550 Watts
Item Weight	1.54 pounds (approx. 700 grams)
Product Dimensions	4"L x 3"W x 2"H (approximate)
Chain Length	6 Inches
Material	Plastic
Color	Blue
Usage	Wood Cutting, Tree Trimming, Gardening
UPC	768443359481

10. Warranty and Support

For any questions, concerns, or technical support regarding your QSDXNYDC Cordless Mini Chainsaw, please contact the seller or manufacturer through the platform where the product was purchased. Please retain your proof of purchase for any warranty claims. Specific warranty details may vary; refer to the product listing or contact customer service for more information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BN8BNP5J

More documents and user manuals: **https://manuals.plus/**