Oclean Oclean W10

Oclean W10 Cordless Water Flosser Instruction Manual

Model: Oclean W10

Brand: Oclean

1. Overview

The Oclean W10 Cordless Water Flosser is a portable oral irrigator designed for effective inter-dental and gum-line cleaning. It features multiple flossing modes and replaceable jet tips, making it suitable for various oral care needs, including brace care. Its rechargeable battery and waterproof design enhance convenience for both home and travel use.



Figure 1: Oclean W10 Cordless Water Flosser and included accessories.

Key Features:

- **Five Flossing Modes:** Intensive, Standard, Gentle, Pulsating, and On-demand for tailored cleaning.
- **Clean Efficiency:** Built-in maglev brushless motor delivers 1,400 pulses per minute frequency and 30-100 psi intensity.
- **15-secs Quadpacer:** Guides users to switch flossing zones for thorough cleaning.
- **30-Day Battery Life:** Long-lasting battery, fully charges in 4 hours, ideal for travel.
- **200 ML Detachable Reservoir:** Easy to fill, clean, and monitor water levels.

2. Safety Information

- Ensure the device is dry before use near electrical outlets to prevent electrical hazards.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

3. What's in the Box

Upon opening the package, verify that all components are present:



Figure 2: Packaging contents of the Oclean W10 Oral Irrigator.

- Oclean W10 Oral Irrigator x1
- Delicate Nozzles x4
- Type-C USB Cable x1
- User Manual x1
- Product Details Illustration x1

4. Setup

1. **Charge the Device:** Before first use, fully charge the Oclean W10 using the provided Type-C USB cable. The charging port is located at the bottom of the device. A full charge takes approximately 4 hours and provides up to 30 days of daily usage.



Figure 3: Charging the Oclean W10 Water Flosser.

2. **Fill the Water Reservoir:** The Oclean W10 features a 200ml detachable reservoir. To fill, either detach the reservoir from the bottom or use the easy-accessible lid at the top. Fill with water.



Figure 4: Filling the 200ml detachable water reservoir.

3. **Attach a Jet Tip:** Select one of the four provided jet tips based on your oral care needs. Insert the chosen tip firmly into the top opening of the flosser until it clicks into place.



Figure 5: Visual guide for initial setup and usage steps.

5. Operating Instructions

The Oclean W10 offers 5 distinct flossing modes to cater to various sensitivities and cleaning requirements. To select a mode, press the mode button (usually the second button from the top). The indicator lights will show the active mode.



Figure 6: Control panel showing the five flossing modes.

Flossing Modes:

- **Intensive Mode:** Provides the strongest water pressure (up to 100 psi) for deep cleaning.
- **Standard Mode:** A balanced pressure setting for daily cleaning.
- **Gentle Mode:** Lower pressure (around 30 psi) for sensitive gums or first-time users.
- **Pulsating Mode:** Alternating pressure for gum massage and improved circulation.
- **On-demand Mode:** Water is released only when the power button is pressed, offering precise control for spot cleaning.

Usage Steps:

1. Select your desired flossing mode.
2. Aim the jet tip at the gum line at a 90-degree angle.
3. Press the power button to begin flossing.
4. Utilize the 15-second Quadpacer (available in Intensive, Standard, Gentle, and Pulsating modes) which reminds you to switch flossing zones for a comprehensive clean.
5. Move the tip along the gum line and between teeth, pausing briefly in each interdental area.
6. After use, turn off the device.

Your browser does not support the video tag.

Video 1: Demonstration of Oclean W10 Water Flosser modes and basic operation.

Your browser does not support the video tag.

Video 2: Overview of the Oclean W10 Water Pulse Oral Irrigator and its benefits for oral hygiene.

6. Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Oclean W10 Water Flosser.

1. **Empty and Clean Reservoir:** After each use, empty any remaining water from the 200ml detachable reservoir. It can be easily removed for thorough cleaning and drying to prevent mold and bacteria buildup.
2. **Clean the Device Exterior:** Wipe the exterior of the flosser with a soft, damp cloth. Do not submerge the main unit in water.
3. **Clean Jet Tips:** Rinse the jet tips under running water after each use. For deeper cleaning, tips can be soaked in a solution of 2 parts water to 1 part white vinegar for 5-10 minutes, then rinsed thoroughly.
4. **Storage:** Store the device in a clean, dry place. Ensure the reservoir is empty and dry before storing for extended periods.

7. Troubleshooting

If you encounter any issues with your Oclean W10 Water Flosser, please refer to the following general advice:

- **Device not turning on:** Ensure the device is fully charged. Connect it to the charger and wait for the charging indicator to light up.
- **Weak water pressure:** Check if the reservoir is sufficiently filled. Ensure the jet tip is securely attached and not clogged.
- **Water leakage:** Verify that the reservoir is correctly attached and sealed. Ensure the jet tip is properly inserted.

For more detailed troubleshooting or persistent issues, please contact Oclean customer support.

8. Specifications

Feature	Detail
Product Dimensions	3.15 x 2.17 x 9.45 inches; 1.21 Pounds
Item Model Number	Oclean W10
Manufacturer	Oclean
Power Source	Corded Electric (USB-C)
Special Features	Multiple Operation Modes; Multiple Tips; Portable
Product Benefits	Gum Health, Prevents Bad Breath
Unit Count	1.00 Count
Water Tank Capacity	200 ML
Pulse Frequency	1,400 pulses per minute
Pressure Range	30-100 psi
Battery Life	Up to 30 days (daily usage)
Charging Time	Approx. 4 hours

9. Warranty and Support

For warranty information, product support, or to purchase replacement parts and accessories, please visit the official Oclean website or contact Oclean customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.
Official Oclean Store: Oclean Amazon Store

© 2023 Oclean. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question