**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**XIAOWTEK A40 Pro**

# XIAOWTEK A40 Pro Wireless Earbuds User Manual

Model: A40 Pro

## Introduction

Thank you for choosing the XIAOWTEK A40 Pro Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.




The A40 Pro Wireless Earbuds in their open charging case, showcasing their sleek white design and compact form factor.

## What's in the Box

Your XIAOWTEK A40 Pro package includes the following items:

- XIAOWTEK A40 Pro Earbuds (Left and Right)
- Charging Case
- Type-C Charging Cable
- English User Manual
- S/M/L three pairs of ear caps




An illustration highlighting the advanced Bluetooth 5.3 technology, ensuring a solid connection, strong signal, and reduced power consumption for extended use.

## Setup and Pairing

### Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided Type-C cable to the charging port on the case and a compatible USB power source. The indicator lights on the case will show the charging status.

### One-Step Pairing

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "A40 Pro" from the list.
4. Once connected, the earbuds will indicate successful pairing. For subsequent uses, simply open the charging case, and the earbuds will automatically connect to the last paired device.




Visual guide for the one-step pairing process, demonstrating how the earbuds automatically connect to your device upon opening the charging case.

## Operating Instructions

### Smart Touch Control

The A40 Pro earbuds feature intuitive touch controls on each earbud. Refer to the table below for common functions:

| Action | Left Earbud (L) | Right Earbud (R) |
|---|---|---|
| Play/Pause | Single Tap | Single Tap |
| Next Track | Double Tap | Double Tap |
| Previous Track | Triple Tap | Triple Tap |
| Answer/End Call | Single Tap | Single Tap |
| Reject Call | Press and Hold (2s) | Press and Hold (2s) |
| Activate Voice Assistant (Siri) | Press and Hold (2s) | Press and Hold (2s) |




An internal view of the earbud highlighting the placement of the four microphones, designed to enhance call clarity by effectively reducing environmental noise.

## Maintenance and Care

To ensure the longevity and optimal performance of your A40 Pro Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Ear Tips:** Remove the ear tips and clean them with mild soap and water if necessary. Ensure they are completely dry before reattaching.
- **Charging Contacts:** Periodically clean the charging contacts on both the earbuds and inside the case with a dry cotton swab to ensure a good connection.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Water Resistance:** The earbuds are IPX7 waterproof, meaning they can withstand sweat, rain, and accidental splashes. However, they are not designed for swimming or prolonged submersion. Always ensure the charging port is dry before charging.




An image illustrating the lightweight and mini design of the earbuds, emphasizing their comfortable fit, IPX7 waterproof rating, and ultra-light 3.8g weight per earbud.

## TROUBLESHOOTING

If you encounter any issues with your A40 Pro Wireless Earbuds, please refer to the following common solutions:

| Problem | Possible Solution |
| --- | --- |
| Earbuds not pairing/connecting | ◦ Ensure earbuds are charged.<br>◦ Turn off and on Bluetooth on your device.<br>◦ Forget "A40 Pro" from your device's Bluetooth list and re-pair.<br>◦ Place earbuds back in the case, close, then open again. |
| No sound from one earbud | ◦ Ensure both earbuds are charged.<br>◦ Try resetting the earbuds (refer to manufacturer's website for specific reset steps if not in manual).<br>◦ Clean charging contacts on both earbuds and case. |
| Low volume or poor sound quality | ◦ Adjust volume on your device.<br>◦ Ensure ear tips are properly sealed in your ear. Try different sized ear tips.<br>◦ Clean earbud speakers and ear tips. |

| Problem | Possible Solution |
| --- | --- |
| Charging issues | ◦ Ensure charging cable is securely connected.<br>◦ Try a different charging cable or power adapter.<br>◦ Clean the charging port on the case and the charging contacts on the earbuds. |

## Specifications

Detailed technical specifications for the XIAOWTEK A40 Pro Wireless Earbuds:

| Feature | Detail |
| --- | --- |
| Model Name | A40 Pro |
| Brand | XIAOWTEK |
| Connectivity Technology | Wireless (Bluetooth) |
| Bluetooth Version | 5.3 |
| Battery Life (Earbuds) | Up to 5 hours on a single charge |
| Total Playtime (with Case) | Up to 50 hours |
| Charging Time | Approx. 1.5 hours |
| Water Resistance Level | IPX7 Waterproof |
| Control Type | Touch Control, Volume Control |
| Noise Control | Environmental Noise Cancellation (ENC) |
| Microphones | Built-in Noise Cancellation Mic (4 mics) |
| Earbud Weight | 3.8g (single earbud) |
| Compatible Devices | Tablets, Smartphones (Android and iOS) |




An overview of the impressive battery life: 5 hours on a single charge for the earbuds, a total of 50 hours with the charging case, and a quick 1.5-hour charging time.

## Warranty and Support

XIAOWTEK provides a standard warranty for the A40 Pro Wireless Earbuds. For specific warranty terms, conditions, and duration, please refer to the warranty card included in your product packaging or visit the official XIAOWTEK website. For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact XIAOWTEK customer service through the contact information provided on their official website or product packaging.

© 2025 XIAOWTEK. All rights reserved.
This manual is subject to change without prior notice.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0BNHVC6FP**

More documents and user manuals: **https://manuals.plus/**