PULIVIA YS-810

PULIVIA YS-810 Sports Stopwatch User Manual

Model: YS-810

1. Introduction

This manual provides detailed instructions for the operation and maintenance of your PULIVIA YS-810 Sports Stopwatch. Designed for athletes, coaches, and general timekeeping, this stopwatch offers multiple functions including lap/split timing, a countdown timer, alarm, and calendar.

2. Product Overview

The PULIVIA YS-810 Sports Stopwatch features a large display and a durable design. It includes several buttons for mode selection, start/stop, and reset/split functions.



Image: The PULIVIA YS-810 Sports Stopwatch displaying the current time and date. The stopwatch is black with yellow accents and features three buttons on the top and one red button on the bottom right.

Button Functions:

- **MODE Button:** Cycles through different operating modes (Time, Alarm, Stopwatch, Timer, Pace).
- **START/STOP Button:** Initiates and pauses timing functions.
- **SPLIT/RESET Button:** Records lap/split times and resets the stopwatch.
- **RECALL Button:** Accesses stored lap/split times.

3. Setup

3.1 Initial Use

- **Screen Protector:** A screen protector is attached to the watch. You may remove it for clearer visibility.
- **Battery:** The stopwatch comes with a pre-installed battery. If the display is dim or unresponsive, replace the battery (type not specified, refer to product packaging for details).

3.2 Setting Time and Date

1. In Time Mode (default display showing current time and date), press and hold the **MODE** button until the display flashes.
2. Use the **START/STOP** button to adjust the flashing value (e.g., hour, minute, year, month, day).
3. Press the **SPLIT/RESET** button to move to the next setting.
4. Once all settings are adjusted, press the **MODE** button again to exit the setting mode.

---

4. Operating Modes

4.1 Time Mode (Clock & Calendar)

This is the default display mode, showing the current time, day of the week, and date. Use the **MODE** button to cycle to this display if you are in another function.

4.2 Alarm Mode

To set the alarm:

1. Press the **MODE** button until 'AL' (Alarm) appears on the display.
2. Press and hold the **START/STOP** button until the hour digit flashes.
3. Use the **SPLIT/RESET** button to adjust the hour.
4. Press the **START/STOP** button to move to the minute setting, then use **SPLIT/RESET** to adjust.
5. Press **START/STOP** again to confirm and exit.
6. To activate/deactivate the alarm, press the **SPLIT/RESET** button while in Alarm Mode. An alarm icon will appear/disappear.

4.3 Stopwatch Mode

The stopwatch measures time with 1/100-second accuracy and can record multiple lap/split times.

1. Press the **MODE** button until 'STOPWATCH' appears.
2. Press **START/STOP** to begin timing.
3. Press **SPLIT/RESET** to record a lap or split time without stopping the main timer. The display will momentarily show the lap/split time.
4. Press **START/STOP** again to pause the stopwatch.
5. To resume, press **START/STOP**.
6. To reset the stopwatch to zero, ensure it is paused, then press **SPLIT/RESET**.

Recalling Lap/Split Times

The stopwatch can store up to 10 lap/split times.

1. After stopping the stopwatch, press the **RECALL** button.

2. Use the **SPLIT/RESET** button to scroll through the stored lap/split times.
3. Press **RECALL** again to exit the recall mode.

4.4 Timer Mode

The timer functions as a basic countdown timer.

1. Press the **MODE** button until 'TIMER' appears.
2. Press and hold the **START/STOP** button to set the desired countdown time (hours, minutes, seconds). Use **SPLIT/RESET** to adjust values and **START/STOP** to move between units.
3. Press **START/STOP** to begin the countdown.
4. Press **START/STOP** again to pause/resume.
5. When the timer reaches zero, an alarm will sound.

4.5 Pace Mode

The pace function allows you to set a desired pace (e.g., 5 to 40 beats per minute) for training.

1. Press the **MODE** button until 'PACE' appears.
2. Press and hold the **START/STOP** button to set the desired pace. Use **SPLIT/RESET** to adjust the value.
3. Press **START/STOP** to activate the pace function. The stopwatch will emit a beep at the set interval.
4. Press **START/STOP** again to stop the pace function.

---

5. Care and Maintenance

5.1 Water Resistance

The PULIVIA YS-810 stopwatch is water-resistant to dripping, splashing, and sweat. It is **not** designed for submersion in water, such as swimming or diving. Do not press any buttons while the stopwatch is wet or submerged.

5.2 Cleaning

Wipe the stopwatch with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the display or casing.

5.3 Storage

Store the stopwatch in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

---

6. Troubleshooting

- **No Display/Dim Display:** Check or replace the battery.
- **Buttons Unresponsive:** Ensure the stopwatch is not in a locked mode (if applicable, refer to specific model features) or try resetting the device by removing and reinserting the battery.
- **Incorrect Time/Date:** Follow the instructions in Section 3.2 to reset the time and date.

---

7. Specifications

- **Brand:** PULIVIA
- **Model:** YS-810
- **Accuracy:** 1/100-second
- **Lap/Split Memory:** Up to 10 laps/splits
- **Functions:** Stopwatch, Timer, Pace, Clock, Calendar, Alarm
- **Material:** Nylon (strap), durable plastic casing
- **Water Resistance:** Splash-proof (not for submersion)

8. Warranty and Support

PULIVIA offers customer service for any inquiries or issues you may encounter. For support, please contact us via Amazon email. We provide 7 days/24 hours customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question