TELESIN Max

TELESIN Magnetic Neck Mount Necklace Holder Lanyard Strap Instruction Manual

Model: Max (20cm/7.87" Collar)

1. Introduction

This manual provides instructions for the proper use and care of your TELESIN Magnetic Neck Mount Necklace Holder Lanyard Strap. This accessory is designed to provide a hands-free solution for capturing point-of-view (POV) footage with action cameras and smartphones.



Image 1.1: TELESIN Magnetic Neck Mount in use, demonstrating hands-free camera placement.

2. Product Overview

2.1 Components



Image 2.1: Detailed view of the neck mount components, including the silicone protective layer, stainless steel neck tube, aluminum alloy layer, smart neck button, magnetic rotating interface, and full force screw.

- **Silicone Protective Layer:** Provides comfort and flexibility.
- **Stainless Steel Neck Tube & Aluminum Alloy Layer:** Ensures durability and shape retention.
- **Smart Neck Button:** Facilitates quick opening and closing of the neck mount.
- **Magnetic Rotating Interface:** Allows for easy attachment and detachment of the camera adapter.
- **Full Force Screw:** Secures the camera to the adapter.

2.2 Package Contents

- 1 x TELESIN Magnetic Neck Holder Mount
- 1 x Adapter for GoPro
- 1 x Universal Locking Screw

3. Setup

3.1 Wearing the Neck Mount

1. Locate the neck switch on the mount.

2. Press the neck switch to open the collar.
3. Place the mount around your neck.
4. Close the collar by bringing the two ends together until the magnetic connection engages and locks securely.



Image 3.1: Visual guide for the magnetic lock/unlock mechanism and wearing the neck mount.

3.2 Attaching Your Camera

1. Attach your action camera or smartphone holder (not included) to the provided adapter using the universal locking screw. Ensure it is tightened securely.
2. Align the adapter with the magnetic rotating interface on the neck mount.
3. The strong magnetic suction will snap the adapter into place.
4. To further secure, rotate the adapter 90 degrees clockwise until it locks. This prevents accidental detachment.
5. To disassemble, rotate the adapter 90 degrees counter-clockwise and pull it out.

4. Operating

4.1 Adjusting Shooting Angles

The neck mount allows for multi-angle adjustment to achieve various shooting perspectives. The camera can be flipped up and down to adjust the angle as needed.



Image 4.1: Illustration of how to adjust the camera angle for different shooting perspectives.

4.2 Shooting Modes

- **Horizontal Shooting:** Position your camera horizontally for standard landscape footage.
- **Vertical Shooting:** For vertical video content, an external short link conversion head (not included) may be required to orient your camera vertically. The centered angle mount helps keep your camera in a central position for accurate POV recording.

5. Compatibility

The TELESIN Magnetic Neck Mount is compatible with a wide range of action cameras and smartphones.



Image 5.1: Examples of compatible devices, including various action cameras and smartphones.

- **GoPro:** Max, Hero 12, Hero 11, Hero 10, Hero 9, Hero 8, Hero 7, Hero 6, Hero 5 Black, Hero 4, 3+, Fusion, Session.
- **DJI:** Action 3, Action 4, Osmo Pocket 3.
- **Insta360:** One R, RS, X2, X3, X4, Go 2, Go 3, Ace Pro.
- **Other Wearable Cameras:** AKASO, Dragon Touch, APEMAN, Crosstour, XiaoYi, Apexcam, VEMONT, AKAIRIO, etc.
- **Smartphones:** Compatible with various iOS (iPhone) and Android devices. *Note: A separate phone holder is required and not supplied with this package.*

6. Maintenance

- Clean the silicone material with a damp cloth and mild soap if necessary. Avoid harsh chemicals.
- Ensure the magnetic connection points are free from debris to maintain a secure lock.
- Store the neck mount in a cool, dry place away from direct sunlight when not in use.
- Periodically check the universal locking screw for tightness to prevent camera detachment.

7. Troubleshooting

- **Camera feels loose or falls off:** Ensure the universal locking screw is fully tightened. Confirm the adapter is rotated 90 degrees clockwise into the locked position on the magnetic interface. Avoid excessive shaking or impact, especially with heavier camera setups.
- **Difficulty closing the neck mount:** Ensure the two ends are properly aligned before engaging the magnetic connection. The neck switch should be pressed firmly.
- **Neck mount feels uncomfortable:** The 20cm/7.87" collar is designed for comfort. If discomfort persists, ensure it is positioned correctly.

8. Specifications



Image 8.1: Overview of product dimensions and specifications.

Parameter	Value
Brand	TELESIN

Model Name	Magnetic Neck Holder Mount (MAX Version)
Material	Silicone, Stainless Steel, Aluminum Alloy
Collar Inner Length	20cm / 7.87 inches
Collar Inner Width	15cm / 5.9 inches
Item Weight	180g (0.4 lbs) / 6 ounces
Package Dimensions	7.28 x 5.39 x 2.83 inches
Special Features	Magnetic, Bendable
Compatible Devices	Cameras, Cellphones

9. Warranty and Support

TELESIN provides a warranty for its products. If you encounter any issues or have questions regarding your Magnetic Neck Mount, please contact TELESIN customer support for assistance. We are committed to resolving any problems quickly and efficiently.
For support, please refer to the contact information provided with your purchase or visit the official TELESIN website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question