eufy T2182-cr

eufy RoboVac L35 Hybrid+ Robot Vacuum and Mop User Manual

Model: T2182-cr

Important Safety Instructions

Before using this product, please read all safety instructions and operating instructions. Keep these instructions for future reference.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Only use the power adapter provided by the manufacturer to charge the device.
- Do not use the product in environments with open flames or fragile objects.
- Do not use the product to clean liquids, burning objects, or sharp objects.
- Ensure the auto-empty station is placed on a stable, level surface away from heat sources.

Product Overview

The eufy RoboVac L35 Hybrid+ is an advanced robotic vacuum and mop designed for comprehensive floor cleaning. It features iPath Laser Navigation for precise mapping, powerful suction, and a controllable water tank for mopping. The included auto-empty station provides up to 60 days of hands-free dust disposal.



Image: The eufy RoboVac L35 Hybrid+ robot vacuum and its accompanying auto-empty station. The robot is black with a blue patterned top surface, featuring two control buttons. The auto-empty station is a tall, black cylindrical unit positioned behind the robot.

Key Features

- **Up to 60 Days of Hands-Free Cleaning:** The auto-empty station automatically empties the RoboVac's dustbin, allowing for extended periods without manual intervention.
- **iPath Laser Navigation:** Utilizes advanced LiDAR technology to create real-time maps of your home for efficient and precise cleaning paths.
- **Ultra-Strong 3,200 Pa Suction:** Provides powerful suction across 4 adjustable levels to effectively remove dirt, debris, and pet hair from various floor types.
- **Controllable Water Tank:** An electronic 200 ml water tank allows for app-controlled water flow adjustments for different mopping needs.
- **Multi-Floor Mapping:** Capable of storing maps for up to 3 different levels, including custom preferences like No-Go Zones.

What's in the Box

Verify that all components are present upon unboxing:

- 1 x Robotic Vacuum Cleaner
- 1 x Auto-empty Station
- 1 x Power Cord
- 1 x Additional Filter
- 2 x Additional Side brushes
- 1 x Additional Washable Mopping Cloth
- 1 x Antibacterial & Deodorant Dust Bag (pre-installed in station)
- 1 x Cleaning tool
- 1 x Waterproof Pad
- 1 x Quick Start Guide
- 1 x Owner's Manual (this document)
- 1 x Warranty Information

Setup

1. Charging the RoboVac

Place the RoboVac on the auto-empty station. Ensure the charging pins on the RoboVac align with those on the station. The indicator light on the RoboVac will show charging status. Fully charge before first use (approximately 6 hours).

2. Installing Side Brushes

Attach the two side brushes to the square posts on the bottom of the RoboVac until they click into place.

3. Setting up the Auto-Empty Station

Choose a location for the auto-empty station that is against a wall, with at least 0.5 meters (1.6 ft) of clear space on both sides and 1.5 meters (4.9 ft) in front. Connect the power cord to the station and plug it into a wall outlet. Place the waterproof pad under the station if using the mopping function frequently.

4. Connecting to the eufyHome App

1. Download the 'eufyHome' app from the App Store (iOS) or Google Play (Android).
2. Create an account or log in.
3. Tap '+' to add a new device and select the RoboVac L35 Hybrid+.
4. Follow the on-screen instructions to connect the RoboVac to your Wi-Fi network.

5. Initial Mapping

For the first cleaning cycle, allow the RoboVac to complete a full cleaning run to create an accurate map of your home. Remove any obstacles that might hinder its path.

Operating the RoboVac

Cleaning Modes

- **Auto Clean:** The RoboVac cleans automatically based on the generated map. Press the power button on the robot or use the app.
- **Spot Clean:** Cleans a specific area intensely. Select this mode in the app and position the RoboVac.
- **Zone Clean:** Define specific zones on the map in the app for the RoboVac to clean.

Using the Mopping Function

To use the mopping function:

1. Fill the water tank with clean water.
2. Attach the mopping cloth to the water tank.
3. Slide the water tank into the back of the RoboVac until it clicks.
4. Select the desired water flow level (3 options) in the eufyHome app.

Scheduling Cleanings

Use the eufyHome app to set cleaning schedules for specific times and days. The RoboVac will automatically start cleaning at the scheduled times.

Using No-Go Zones and Virtual Walls

In the eufyHome app, you can define No-Go Zones (areas the RoboVac should avoid) and Virtual Walls (lines it should not cross) on your floor map to customize cleaning areas.

Voice Control

The RoboVac L35 Hybrid+ is compatible with Amazon Alexa and Google Assistant. Follow the instructions in the eufyHome app to link your device for voice commands.

Maintenance

Regular maintenance ensures optimal performance of your RoboVac.

1. Emptying the Dustbin (RoboVac)

Although the auto-empty station handles most dust, manually check and empty the RoboVac's internal dustbin

periodically, especially if you notice reduced suction.

2. Cleaning the Filter

Remove the filter from the dustbin and tap it gently to remove debris. Rinse with water if necessary, and allow it to air dry completely before reinserting. Replace every 3-6 months.

3. Cleaning the Rolling Brush

Remove the rolling brush cover and lift out the brush. Use the cleaning tool to cut and remove any hair or debris tangled around the brush. Clean the brush bearings as well.

4. Cleaning Side Brushes

Remove the side brushes and clean any hair or debris. If brushes are worn or bent, replace them. Replace every 3-6 months.

5. Cleaning Sensors and Charging Pins

Wipe the drop sensors, infrared sensors, and charging pins on both the RoboVac and the auto-empty station with a dry cloth to ensure proper function.

6. Maintaining the Water Tank and Mopping Cloth

After each mopping session, empty any remaining water from the tank and allow it to air dry. Wash the mopping cloth thoroughly and air dry. Replace the mopping cloth every 2-3 months depending on usage.

7. Auto-Empty Station Maintenance

Replace the dust bag in the auto-empty station when the indicator light signals it's full (approximately every 60 days). Wipe the dust inlet and charging contacts on the station.

Troubleshooting

Problem	Possible Cause	Solution
RoboVac does not charge.	Charging pins are dirty or misaligned.	Clean charging pins on both RoboVac and station. Ensure proper alignment.
Reduced suction power.	Dustbin full, filter clogged, or rolling brush tangled.	Empty dustbin, clean/replace filter, clean rolling brush.
RoboVac gets stuck frequently.	Obstacles in cleaning path or dirty drop sensors.	Clear obstacles. Clean drop sensors. Use No-Go Zones for persistent problem areas.
Cannot connect to Wi-Fi.	Incorrect Wi-Fi password, 5GHz network, or poor signal.	Ensure correct password. Connect to a 2.4GHz network. Move RoboVac closer to router.

Problem	Possible Cause	Solution
Mopping function not working.	Water tank empty, clogged nozzle, or incorrect installation.	Fill water tank. Clean water outlet. Reinstall water tank correctly.

Specifications

Brand	eufy
Model Number	T2182-cr
Color	Black
Product Dimensions	35 x 35 x 10.01 cm (RoboVac)
Item Weight	3.9 kg (8.6 lbs)
Dustbin Capacity	3 liters (Auto-empty station)
Suction Power	Up to 3,200 Pa
Water Tank Capacity	200 ml
Navigation Type	iPath Laser Navigation (LiDAR)
Battery Type	Lithium Ion
Auto-Empty Station Capacity	Up to 60 days of dust storage
Control Type	App Control, Voice Control (Alexa, Google Assistant)

Warranty and Support

This product comes with a limited warranty. Please refer to the 'Warranty Information' document included in the box for details on warranty coverage and terms. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact eufy customer service. Contact information can typically be found on the eufy official website or in your warranty documentation.

Note: As this product may be a renewed item, specific warranty terms might differ from new products. Please

consult the provided warranty information for your specific purchase.

© 2024 eufy. All rights reserved.