NIYAMA LG-976H

NIYAMA Universal Infrared Remote Control for LG TVs

Model: LG-976H

Brand: NIYAMA

1. Product Overview

The NIYAMA LG-976H is a universal infrared remote control specifically designed for LG LCD TVs. It is pre-configured for immediate use, eliminating the need for complex setup or registration processes. Its design mimics the original LG remote's button layout for intuitive and comfortable operation.



Figure 1: Front, side, and back view of the NIYAMA LG-976H remote control, showcasing its ergonomic design.



Figure 2: Key button functions and their intuitive layout on the remote control.

2. Setup

2.1 Battery Installation

The NIYAMA LG-976H remote control requires two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) and lift to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) ends align correctly with the indicators inside the compartment.

4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 3: Proper battery installation in the remote control.

Once batteries are installed, the remote is ready for immediate use with compatible LG LCD TVs without any further programming.

3. Operating Instructions

3.1 Basic Functions

- **Power Button:** Press to turn the TV on or off.
- **Number Buttons (0-9):** Use to directly select channels.
- **Channel Up/Down:** Navigate through channels sequentially.
- **Volume Up/Down:** Adjust the TV's volume level.
- **Input/Source:** Switch between different input sources (HDMI, AV, etc.).
- **Mute:** Mute or unmute the TV's audio.

3.2 Navigation and Menu Control

- **Directional Pad (Up, Down, Left, Right):** Navigate through on-screen menus and options.
- **OK/Enter Button:** Confirm selections or open menus.
- **Back/Return:** Go back to the previous screen or exit a menu.
- **Home Button:** Access the TV's main smart TV interface or home screen.
- **Settings Button:** Open the TV's settings menu.

3.3 Special Features

- **Netflix Button:** Direct access to the Netflix application.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within certain TV menus or applications, as

indicated on-screen.

- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind):** Control media playback.



Figure 4: The remote's design allows for comfortable operation in various holding styles.



Figure 5: Wide-angle infrared transmission ensures stable operation up to 8-10 meters with a 120-degree angle.

4. Maintenance

To ensure the longevity and optimal performance of your remote control, please follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or inconsistent. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact. Dropping it can damage internal components.

5. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Check battery polarity or replace with new batteries.
Remote has short range or intermittent response.	Low batteries; Obstruction between remote and TV; Remote sensor on TV is blocked.	Replace batteries; Remove any objects blocking the line of sight; Ensure TV's IR sensor is clear.
Certain buttons do not work.	Button malfunction; TV model incompatibility for specific advanced functions.	Ensure the remote is compatible with your specific LG TV model. If basic functions fail, contact support.
TV does not turn on/off.	TV is unplugged or main power is off.	Check TV power connection.

6. Specifications

Compatible Devices: LG LCD TVs

Max Number of Compatible Devices: 1

Color: Black

Features: Pre-configured, No setup required

Brand: NIYAMA

Item Model Number: LG-976H

Connectivity Technology: Infrared

Package Dimensions: 21.5 x 5 x 2.4 cm (8.46 x 1.97 x 0.94 inches)

Item Weight: 80 g (2.82 ounces)

Batteries Required: Yes (AAA x 2)

Batteries Included: No

Date First Available on Amazon.co.jp: December 7, 2022

7. Warranty and Support

NIYAMA Store is the exclusive sales channel for this product. We are committed to providing safe and reliable products made with environmentally friendly materials.

While we strive for the highest product quality, if you encounter any issues or defects, please do not hesitate to contact our customer support. We offer new product exchanges or refunds for any malfunctions.

When contacting customer support, please have your product details and order number ready for a smoother process.

For further assistance, please visit the NIYAMA Brand Store on Amazon.

© 2024 NIYAMA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question