ALLIMITY KS0971 KS1271 KHS1271

Allimity Replacement Remote Control for Sanyo Air Conditioners

Model Compatibility: Sanyo HS1852, SAP-K127GS5A, RCS-5S1E, RCS-7S1E, RCS-1PS4U-G, RCS-SH1BG, KMS0972, KMHS0772, KMHS1712, KS1872, KS2472, KS0951, KS1251, KS1852, KS0971, KS1271, KHS1271

1. Introduction

This manual provides instructions for the Allimity replacement remote control, designed for various Sanyo air conditioner models. It covers battery installation, basic operation, and troubleshooting to ensure proper use of your remote control.

2. Setup: Battery Installation

The remote control requires two 1.5V AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Image description: A view of the back of the remote control with the battery compartment open, showing the slots for two AAA batteries.

3. Operating Instructions

This remote control is pre-programmed and does not require any setup. Simply insert batteries to begin operation.




AIR CONDITIONER
SET TEMP.
1HR.
ON·I /OFF·O
MODE
▼TEMP.▲
ECONOMY
FAN SPEED
FLAP
ON TIMER OFF
CANCEL
ACL
SENSOR
QUIET
LED CLEAN

Image description: A front view of the Allimity replacement remote control, displaying all buttons and the LCD screen.

Button Functions

- **ON/OFF**: Powers the air conditioner on or off.
- **MODE**: Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP ▲ / ▼**: Adjusts the temperature setting up or down.
- **FAN SPEED**: Changes the fan speed (e.g., Low, Medium, High, Auto).
- **FLAP**: Controls the louver/flap direction.
- **ECONOMY**: Activates or deactivates economy mode for energy saving.
- **1HR.**: Activates a 1-hour timer function.
- **TIMER ON/OFF**: Sets or cancels the on/off timer.
- **CANCEL**: Cancels current timer settings.
- **ACL**: (All Clear/Reset) Resets settings. Use a pointed object to press this button.
- **SENSOR**: Activates or deactivates the temperature sensor function.
- **QUIET**: Activates or deactivates quiet operation mode.
- **LED CLEAN**: Activates or deactivates the LED display or a cleaning function.

4. Troubleshooting

- **Remote not responding:**
  - Check if batteries are inserted correctly with correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner.
- **Air conditioner not responding to specific functions:**
  - Verify that your air conditioner model is listed as compatible in the header of this manual.
  - Some functions on the remote may not be supported by all compatible air conditioner models.

5. Specifications

- **Product Dimensions:** 5.6 x 1.8 x 0.6 inches
- **Item Weight:** 1.76 ounces
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Compatible Devices:** Sanyo Air Conditioners (specific models listed in header)
- **Connectivity Technology:** Infrared

6. Warranty and Support

For product support or warranty inquiries, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific contact information and warranty terms.