Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY WH-E1NE / WC-E1NE

ALLIMITY WH-E1NE / WC-E1NE Replacement Remote Control User Manual

For Toshiba Air Conditioners

1. Introduction

This manual provides instructions for the ALLIMITY WH-E1NE / WC-E1NE replacement remote control, designed for use with various Toshiba Air Conditioner models. This remote control offers direct functionality without the need for programming.

1.1 Compatible Models

This remote control is compatible with the following Toshiba Air Conditioner models:

- WH-F09J
- WC-L03SE
- WC-H01EE
- WC-H01EF
- WH-L03SE
- WH-F08J
- WH-H01JE
- RAS-B18NKPX

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

No programming is required after battery installation; the remote is ready for use.



Image: Rear view of the remote control with the battery cover removed, illustrating the correct orientation for inserting two AAA batteries.

3. Operating Instructions

This section details the functions of the buttons on your ALLIMITY replacement remote control.



Image: Front view of the remote control, highlighting the display screen and various function buttons.

3.1 Button Functions

- **START/STOP:** Press to turn the air conditioner ON or OFF.
- **TEMP. ▼ / ▲:** Use these buttons to decrease (▼) or increase (▲) the desired temperature setting.
- **MODE:** Cycles through the available operating modes: Auto, Cool, Dry, Heat, and Fan.
- **FAN:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **ECONO:** Activates or deactivates the Economy mode, which optimizes energy consumption.
- **AUTO:** Sets the air conditioner to automatic operation, where it selects the appropriate mode and fan speed based on the room temperature.

- **SET:** Used to confirm settings, often in conjunction with timer functions.
- **TIMER:** Initiates the timer setting function.
- **ON:** Used to set the ON timer, scheduling when the unit should turn on.
- **OFF:** Used to set the OFF timer, scheduling when the unit should turn off.
- **RSV (Reserve):** Likely used to reserve or store a timer setting.
- **CNL (Cancel):** Cancels any active or pending timer settings.

4. Troubleshooting

If your remote control is not functioning as expected, consider the following troubleshooting steps:

- **Check Batteries:** Ensure that the batteries are new and correctly inserted with the proper polarity (+/-). Weak or dead batteries are a common cause of remote control malfunction.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the air conditioner's receiver. Obstructions can block the infrared signal.
- **Distance:** Operate the remote control within the recommended range of the air conditioner.
- **Interference:** Other electronic devices or strong light sources might interfere with the remote's signal. Try operating the remote in a different location or away from potential interference.
- **Clean Remote:** Ensure the infrared emitter on the front of the remote control is clean and free from dust or debris.

5. Specifications

Feature	Detail
Model Number	WH-E1NE / WC-E1NE
Power Supply	2 x 1.5V AAA Alkaline Batteries (Not Included)
Product Dimensions	5.3 x 2 x 0.6 inches (13.5 x 5.1 x 1.5 cm)
Item Weight	2.08 ounces (59 grams)
Connectivity Technology	Infrared
Compatible Devices	Toshiba Air Conditioners
Special Feature	No Programming Required

6. Support

For further assistance or inquiries regarding your ALLIMITY replacement remote control, please contact the seller or retailer from whom you purchased the product. Provide your purchase details and the model number (WH-E1NE / WC-E1NE) for efficient support.

ALLIMITY Replacement Remote Control Manual

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BPHBMV2P

More documents and user manuals: **https://manuals.plus/**