Azwok BN59-01012A

Azwok BN59-01012A Replacement Remote Control User Manual

Model: BN59-01012A
Brand: Azwok

1. Introduction

This manual provides instructions for the Azwok BN59-01012A Replacement Remote Control, designed for use with various Samsung LCD TVs. This remote control offers the primary functions of the original BN59-01012A remote without requiring any programming.

2. Product Overview

2.1 Key Features

- Direct replacement for Samsung BN59-01012A remote control.
- No programming or pairing required; ready to use after battery installation.
- Retains all major buttons and functions of the original remote.
- Durable construction for reliable performance.

2.2 Compatible TV Models

This remote control is compatible with a range of Samsung LCD TV models, including but not limited to:

- LA22C450, LA22C450E1D, LA22C450E1DXXY
- LA26C450, LA26C450E1M, LA26C450E1MXRD
- LA32C450, LA32C450E1M, LA32C450E1MXXY
- LE19C450E1W, LE19C450E1W/XXC, LE19C450E1W/XXN, LE19C450E1W/XZG
- LE22C455, LE22C455E1W, LE22C455E1W/XXE
- LE22D450, LE22D450G1W, LE22D450G1W/XXN
- LE26C450, LE26C450E1W, LE26C450E1W/XXN, LE26C450E1W/XZF, LE26C450E1W/XZG
- LE26C455, LE26C455E1W, LE26C455E1W/XXE
- LE32C450, LE32C450E1W, LE32C450E1W/XXC, LE32C450E1W/XXN, LE32C450E1W/XZF, LE32C450E1W/XZG, LE32C450E1WXXH
- LE32C455, LE32C455E1W, LE32C455E1W/XXE

- LN32C450, LN32C450E1D, LN32C450E1D/XZA
- PS42C430, PS42C430A1W, PS42C430A1W/XXC
- PS42C435, PS42C435A1W, PS42C435A1W/XXE
- PS42C450, PS42C450B1W, PS42C450B1W/XXC, PS42C450B1M, PS42C450B1MXRD
- PS42C451, PS42C451B1M, PS42C451B1MXRD
- PS50C430, PS50C430A1W, PS50C430A1W/XXC
- PS50C450, PS50C450B1W, PS50C450B1W/XXC, PS50C450B1M, PS50C450B1MXRD
- PS50C451, PS50C451B1M, PS50C451B1MXRD

If your specific TV model is not listed, or if your original remote differs significantly, please consult the manufacturer for compatibility confirmation.

3. Setup

3.1 Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Rear view of the BN59-01012A remote control, showing the battery compartment cover.





Image: The battery compartment of the remote control with two AAA batteries inserted, showing correct polarity.

Once batteries are installed, the remote control is ready for immediate use with compatible Samsung LCD TVs. No additional programming is required.

4. Operation

4.1 Button Layout and Functions




1
2
3
4
5
6
7
8
9
TTX/MIX
0
PRE-CH
MUTE
CH LIST
P
MEDIA
MENU
GUIDE
TOOLS
INFO
RETURN
EXIT
A
B
C
D
I-II
P.MODE
S.MODE
DUAL
AD
P.SIZE
SUBT.
BN59-01012A



Image: Front view of the BN59-01012A remote control, displaying all buttons.

The BN59-01012A remote control features a standard layout for Samsung LCD TVs. Below is a general guide to the main buttons and their functions:

Button	Function
POWER	Turns the TV on or off.
SOURCE	Selects the input source (e.g., HDMI, AV, Component).
Number Buttons (0-9)	Direct channel selection.
VOL (+/-)	Adjusts the volume level.
CH (Up/Down)	Changes TV channels.
MUTE	Mutes or unmutes the TV audio.
MENU	Opens the TV's main menu.
GUIDE	Displays the electronic program guide (EPG).
INFO	Displays information about the current program or input.
Directional Pad (Up/Down/Left/Right) & ENTER	Navigates menus and confirms selections.
RETURN / EXIT	Goes back to the previous menu or exits the current menu.
Colored Buttons (A, B, C, D)	Functions vary depending on the TV model and current menu/application.
P.MODE / S.MODE	Picture Mode / Sound Mode selection.
Play/Pause, Stop, Rewind, Fast Forward	Controls media playback (e.g., USB, connected devices).

For detailed information on specific button functions, refer to your Samsung TV's original user manual.

5. Troubleshooting

If you encounter issues with your remote control, please refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Confirm the remote control is pointed directly at the TV's sensor.
- **Limited Functionality:**
  - Verify that your TV model is listed as compatible in Section 2.2.
  - Some advanced smart TV features or specific app controls may require the original smart remote. This remote is designed for basic TV functions.

- **Intermittent Operation:**
  - This could indicate low battery power. Replace batteries.
  - Ensure no strong light sources (e.g., direct sunlight, fluorescent lights) are interfering with the IR signal.

If the issue persists after trying these steps, please contact customer support.

6. Specifications

Feature	Detail
Model Number	BN59-01012A (Replacement)
Brand	Azwok
Connectivity Technology	Infrared (IR)
Compatible Devices	Samsung LCD Televisions
Power Source	2 x AAA Batteries (not included)
Special Feature	No Programming Required
Product Dimensions	9.45 x 1.97 x 1.18 inches (approx.)
Item Weight	3.14 ounces (approx.)

7. Warranty and Support

7.1 Warranty Information

This Azwok BN59-01012A Replacement Remote Control comes with a**12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote control functions as described. If the product fails due to a manufacturing defect within this period, a replacement or refund may be provided.
The warranty does not cover damage caused by misuse, accidental damage, unauthorized repairs, or normal wear and tear.

7.2 Customer Support

For any questions, troubleshooting assistance, or warranty claims, please contact the seller or manufacturer directly. When contacting support, please provide your purchase details and the model number of the remote control.

© 2023 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question