Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-AA59-00602A-SM025

Azwok AA59-00602A Replacement Remote Control User Manual

For Samsung TV Models

1. Introduction

This manual provides instructions for the Azwok AA59-00602A replacement remote control, designed for use with various Samsung TV models. This remote functions as a direct replacement for your original AA59-00602A remote, offering all primary functions without the need for complex programming.

Please read this manual carefully to ensure proper setup and operation of your new remote control.

2. Setup

2.1 Battery Installation

The Azwok AA59-00602A remote control requires two (2) AAA batteries (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Back of the remote control with the battery compartment open, illustrating battery insertion.

2.2 Initial Use

This replacement remote control is ready to use immediately after battery installation. No programming or pairing is required. Simply point the remote at your Samsung TV and begin operation.

3. Operating Instructions

The Azwok AA59-00602A remote control replicates the functions of your original Samsung TV remote. Familiarize yourself with the button layout for seamless control of your television.



Image: Front view of the remote control, displaying all functional buttons.

3.1 Key Functions

- **Power Button (●)**: Turns the TV on or off.
- **Number Buttons (0-9)**: Directly select channels.
- **Volume Up/Down (+/-)**: Adjusts the TV volume.
- **Channel Up/Down (CH +/-)**: Changes TV channels sequentially.
- **Mute Button**: Silences the TV audio.

- **Source Button**: Cycles through available input sources (HDMI, AV, etc.).
- **Menu Button**: Accesses the TV's main menu.
- **Directional Pad (Up/Down/Left/Right) & Enter Button**: Navigates menus and confirms selections.
- **Return/Exit Buttons**: Go back to the previous screen or exit a menu.
- **Color Buttons (Red, Green, Yellow, Blue)**: Used for specific functions within certain TV applications or menus.

3.2 Compatible TV Models

This remote control is compatible with a wide range of Samsung TV models, including but not limited to:

- LA32E420, LA32E420E2M, LA32E420E2MXXY
- PS43E450, PS43E450A1M, PS43E450A1MXXY
- PS51E450, PS51E450A1M, PS51E450A1MXXY
- PS51E530, PS60E530
- PS51E531, PS51E531A6M, PS51E531A6MXXY
- PS60E531, PS60E531A6M, PS60E531A6MXXY
- UA32EH4003M, UA32EH4003MXXY
- UA26EH4000M, UA26EH4000MXXY
- UA32EH4000M, UA32EH4000MXXY
- UA32EH5006M, UA32EH5006MXXY
- UA40EH5006M, UA40EH5006MXXY
- UA40EH6000M, UA40EH6000MXXY
- UA46EH6000M, UA46EH6000MXXY
- UA50EH6000M, UA50EH6000MXXY
- UA55EH6000M, UA55EH6000MXXY
- UA60EH6000M, UA60EH6000MXXY
- UA19ES4000M, UA19ES4000MXXY
- UA22ES5000M, UA22ES5000MXXY

If your specific TV model is not listed, or if you are unsure about compatibility, please refer to the product listing or contact customer support for assistance.

4. Maintenance

4.1 Battery Replacement

When the remote control's performance degrades or it stops responding, it is likely time to replace the batteries. Follow the battery installation steps in Section 2.1 to replace the two AAA batteries.

Important: Always replace both batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AAA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Make sure you are within the effective range of the TV's IR receiver.
- **Some buttons not working:**
  - This remote is designed to replicate the original AA59-00602A functions. If a specific function is not working, ensure your TV model supports that function with the original remote.
  - Clean the remote control, especially around the buttons, to remove any debris that might be causing sticking.

If you continue to experience issues after following these troubleshooting steps, please contact customer support for further assistance.

6. Specifications

Feature	Detail
Model Number	AU-AA59-00602A-SM025
Brand	Azwok
Product Dimensions	6.54 x 1.73 x 0.94 inches
Item Weight	1.76 ounces
Batteries Required	2 AAA batteries
Connectivity Technology	Infrared (IR)
Special Feature	No Programming Required
Compatible Devices	Television

7. Warranty and Support

7.1 Warranty Information

This Azwok AA59-00602A replacement remote control comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as described. For warranty claims or issues, please retain your proof of purchase.

7.2 Customer Support

If you have any questions, require assistance with setup, or encounter any problems not covered in this manual, please do not hesitate to contact our customer support team. We are committed to providing prompt and helpful service.

For contact details, please refer to the seller's information on the platform where you purchased this product.

© 2026 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BPNRD3RG

More documents and user manuals: **https://manuals.plus/**