Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-RM-ED013-SN005

Azwok Replacement RM-ED013 Remote Control User Manual

Brand: Azwok | **Model:** AU-RM-ED013-SN005

1. Introduction

This manual provides instructions for the Azwok Replacement RM-ED013 Remote Control, designed for use with various Sony TV models. This remote control offers all major buttons and functions found on the original RM-ED013 remote. It is ready to use without any programming required; simply install batteries, and it will function immediately.



Image 1.1: Front view of the Azwok Replacement RM-ED013 Remote Control, showcasing its button layout and ergonomic design.

2. Setup

2.1 Battery Installation

The remote control requires two AA batteries (not included) for operation. Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.







Image 2.1: Back view of the remote control with the battery compartment open, showing the correct orientation for AA battery insertion.

2.2 Initial Use

This replacement remote control is designed for immediate use. No programming or pairing is required. Once batteries are correctly installed, the remote control is ready to operate your compatible Sony TV.

3. Operating Instructions

To operate your Sony TV, point the remote control directly at the TV's infrared receiver and press the desired function button. The remote control replicates the functions of the original RM-ED013 remote, providing access to power, volume, channel selection, menu navigation, and other standard TV controls.
Familiarize yourself with the button layout:

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel input.
- **Volume Up/Down:** Adjusts the audio level.
- **Channel Up/Down:** Changes TV channels.
- **Menu/Home Button:** Accesses the TV's main menu or smart features.
- **Navigation Pad (Up/Down/Left/Right/Enter):** For navigating menus and selecting options.
- **Return/Back Button:** Returns to the previous screen or menu.
- **Input/Source Button:** Selects input sources (HDMI, AV, etc.).

4. Compatibility

This Azwok replacement remote control is compatible with various Sony Bravia LCD Digital Colour TV models, including but not limited to the following:

- KDL-52V4000, KDL-46V4000, KDL-40V4000, KDL-40L4000
- KDL-52V42XX, KDL-52V4210, KDL-46V42XX, KDL-46V4210
- KDL-40V42XX, KDL-40V4240, KDL-40V4230, KDL-40V4220, KDL-40V4210
- KDL-40S40XX, KDL-40S4010, KDL-40S4000
- KDL-40U40XX, KDL-40U4000
- KDL22S5700, KDL32V5500, KDL32W5500, KDL40V5500, KDL40W5500, KDL40WE5
- KDL46W5500, KDL46WE5

It is also compatible with original remote models such as RM-GD007, RM-GA008, RM-GA007, GA006, RM-GA005, RM-ED016, and RM-ED011.
If your specific TV model number is not listed above, or if your original remote control differs significantly from the RM-ED013, please contact customer support to confirm compatibility before use.

5. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AA). Do not mix old and new batteries, or

different types of batteries.

- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Handling:** Avoid dropping the remote control or subjecting it to strong impacts, which can damage internal circuitry.

6. Troubleshooting

If you encounter issues with your remote control, refer to the following troubleshooting steps:

- **Remote Control Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AA batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Make sure you are within a reasonable operating range and pointing the remote directly at the TV.
- **Some Buttons Not Working:**
  - Verify that your TV model is listed as compatible. While this remote is broadly compatible, some specific functions might vary slightly depending on the exact TV model.
  - Clean the remote control, especially around the unresponsive buttons, to ensure no debris is interfering with their operation.
- **Intermittent Operation:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the infrared signal.

If these steps do not resolve the issue, please contact customer support for further assistance.

7. Specifications

Model Number	AU-RM-ED013-SN005
Product Dimensions	8.66 x 1.69 x 0.91 inches
Item Weight	2.61 ounces
Batteries Required	2 AA batteries (not included)
Connectivity Technology	Infrared (IR)
Compatible Devices	Sony Televisions
Special Feature	No Programming Required

8. Warranty and Support

8.1 Warranty Information

This Azwok replacement remote control comes with a 12-month (1-year) replacement warranty from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as intended under normal use. If the product fails due to a defect within the warranty period, a replacement will be provided.

8.2 Customer Support

For any questions, concerns, or assistance with your Azwok Replacement RM-ED013 Remote Control, please contact our customer support team. If you are unsure about compatibility or need help troubleshooting, do not hesitate to reach out. Please refer to your purchase documentation for specific contact details or visit the Azwok brand page on the retailer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BPT2TY62

More documents and user manuals: **https://manuals.plus/**