Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Omega FS1083B

Omega Freestyle Bluetooth V5.0 TWS Sports Earbuds

Model: FS1083B

Brand: Omega

Introduction

The Omega Freestyle FS1083B are complete wireless earbuds designed to deliver high-quality audio. They utilize modern Bluetooth 5.0 technology for stable and fast connections, offering true wireless stereo (TWS) sound. The earbuds come with a portable charging case that also functions as a power bank, ensuring your earbuds are always ready for use.
These earbuds are ideal for sports and active lifestyles, providing freedom of movement without restrictive cables. They feature an integrated microphone for hands-free calling and function buttons for easy control.

What's in the Box

- Omega Freestyle TWS Sports Earbuds (Left and Right)
- Portable Charging Case
- USB Charging Cable (Type C, inferred from product image)
- User Manual (this document)



Image: Omega Freestyle TWS Sports Earbuds nestled within their charging case.

Setup

Initial Charging

Before first use, fully charge both the earbuds and the charging case.

1. Place the earbuds into their respective slots in the charging case. Ensure they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and the other end to a compatible USB power source (e.g., computer USB port, wall adapter).
3. The charging indicators on the case and/or earbuds will illuminate to show charging status.
4. A full charge for both earbuds and the case typically takes approximately 1 hour.

The charging case has a built-in rechargeable battery (300 mAh) that can fully recharge the earbuds (50 mAh each) multiple times, extending their usage time.



Image: Close-up view of the Omega Freestyle TWS Sports Earbuds.

Operating Instructions

Power On/Off

- **Power On:** The earbuds will automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case. They will automatically power off and begin charging.

Bluetooth Pairing

The earbuds connect instantly to devices via Bluetooth 5.0 for a stable connection.

1. Ensure the earbuds are charged and removed from the charging case. They will enter pairing mode automatically.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices.
4. Select "FS1083B" or a similar name from the list of found devices to connect.
5. Once paired, the earbuds will confirm the connection, and you can begin audio playback.

Music Playback Control

Use the function buttons on the earbuds to control music playback:

- **Play/Pause:** Single press the function button on either earbud.
- **Next Track:** Double press the function button on the right earbud.
- **Previous Track:** Double press the function button on the left earbud.

Call Management

The integrated high-quality microphone allows for clear hands-free calls.

- **Answer/End Call:** Single press the function button on either earbud.
- **Reject Call:** Press and hold the function button on either earbud for 2 seconds.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water Resistance:** The earbuds are waterproof. However, avoid prolonged submersion in water and do not expose the charging case to liquids. Dry the earbuds thoroughly before placing them back in the charging case if they get wet.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not in constant use.

Troubleshooting

Problem	Possible Cause	Solution
Earbuds not powering on	Low battery; Not removed from case	Charge the earbuds and case; Ensure earbuds are removed from the case.
Cannot pair with device	Bluetooth off; Earbuds not in pairing mode; Device too far	Ensure Bluetooth is enabled on your device; Place earbuds back in case then remove to re-enter pairing mode; Keep devices within 10m range.
No sound or poor sound quality	Volume too low; Earbuds not properly seated; Interference	Adjust volume on device; Ensure earbuds are clean and properly inserted; Move away from other wireless devices.
Charging case not charging	Cable issue; Power source issue	Try a different USB cable or power adapter; Ensure connections are secure.

Specifications

- **Model Name:** FreeStyle Bluetooth V5.0 Sports Earbuds TWS + Charging Station Black
- **Model Number:** FS1083B
- **Connectivity Technology:** Wireless (Bluetooth)
- **Bluetooth Version:** 5.0 + EDR
- **Wireless Communication Technology:** Bluetooth
- **Earbud Battery Capacity:** 50 mAh (each earbud)
- **Case Battery Capacity:** 300 mAh
- **Continuous Playtime:** Up to 5 hours
- **Standby Time:** Up to 100 hours
- **Charging Time:** Approximately 1 hour (for headphones and power pack)
- **Speaker Diameter:** 10mm
- **Impedance:** 16ohm
- **Sensitivity:** 92dB
- **Frequency Response:** 24Hz-24.8kHz
- **Input Power:** 66.7mW
- **Special Features:** Microphone included, True Wireless Stereo (TWS), Active Noise Cancellation (CVC6.0 inferred from image)

- **Water Resistance Level:** Waterproof
- **Form Factor:** In-Ear
- **Material:** Plastic
- **Manufacturer:** Platinet S.A.



Image: Detailed specifications as printed on the product packaging.



Image: Additional product details and certifications from the packaging.

Safety Information

- Do not disassemble, repair, or modify the product.
- Keep away from extreme temperatures, direct sunlight, and open flames.
- Do not expose the charging case to water or moisture.
- Dispose of the product and its battery responsibly according to local regulations. Do not dispose of with household waste.
- Avoid listening at high volumes for extended periods to prevent hearing damage.

Warranty and Support

Information regarding spare parts availability and guaranteed software updates for this product is not available.
For warranty claims or technical support, please contact your retailer or the manufacturer, Platinet S.A., directly. Please retain your proof of purchase for any warranty-related inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BPY5NTS9

More documents and user manuals: **https://manuals.plus/**