Azwok RM-ED044

Azwok RM-ED044 Replacement Remote Control User Manual

Model: RM-ED044

Introduction

This manual provides instructions for the Azwok RM-ED044 Replacement Remote Control, designed for various Sony Bravia LCD TV models. This remote functions as a direct replacement for the original RM-ED044 remote control, offering all primary buttons and functions without requiring any programming.



Image: Angled view of the Azwok RM-ED044 replacement remote control.

Compatible Sony TV Models include:

- KDL-55EX720, KDL-46EX720, KDL-40EX720, KDL-37EX720, KDL-32EX720
- KDL-55EX723, KDL-46EX723, KDL-40EX723, KDL-37EX723, KDL-32EX723
- KDL-55EX725, KDL-46EX725, KDL-40EX725, KDL-37EX725, KDL-32EX725
- KDL-55EX721, KDL-46EX721, KDL-40EX721, KDL-32EX721
- KDL-55EX724, KDL-46EX724, KDL-40EX724, KDL-32EX724
- KDL-55EX726, KDL-46EX726, KDL-40EX726, KDL-32EX726
- KDL-55EX727, KDL-46EX727, KDL-40EX727, KDL-32EX727
- KDL-55EX728, KDL-46EX728, KDL-40EX728, KDL-32EX728
- KDL-55EX729, KDL-46EX729, KDL-40EX729, KDL-32EX729
- KDL-46HX720, KDL-40HX720, KDL-46HX723, KDL-40HX723, KDL-46HX725, KDL-40HX725
- KDL-60NX720, KDL-55NX720, KDL-46NX720, KDL-40NX720

- KDL-60NX723, KDL-55NX723, KDL-46NX723, KDL-40NX723
- KDL-60NX725, KDL-55NX725, KDL-46NX725, KDL-40NX725

If your specific TV model is not listed, or if your original remote differs significantly, please contact customer support for compatibility verification.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image: Back of the remote control with the battery cover open, revealing the battery slots.

2. Initial Use

Once batteries are installed, the remote control is ready for immediate use. No programming or pairing is required. Point the remote directly at your Sony TV and begin operating it.

Operating Instructions

The Azwok RM-ED044 remote control replicates the functionality of your original Sony RM-ED044 remote. Refer to your Sony TV's user manual for specific functions of each button if you are unfamiliar with them.



Image: Front view of the remote control, displaying all operational buttons.

Key Functions:

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel selection.
- **Channel Up/Down (CH +/-):** Navigates through channels.
- **Volume Up/Down (VOL +/-):** Adjusts the TV volume.
- **Mute:** Silences the TV audio.
- **Input/Source:** Selects input sources (HDMI, AV, etc.).
- **Menu/Home:** Accesses the TV's main menu or smart TV interface.
- **Navigation Pad (Up/Down/Left/Right/Enter):** For menu navigation and selection.
- **Return/Back:** Returns to the previous screen or menu.
- **Options:** Displays context-sensitive options.

- **Colored Buttons (Red, Green, Yellow, Blue):** For specific functions within menus or applications.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote in a dry place, away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Remote is not working.	Dead or incorrectly installed batteries.	Replace batteries with new AAA batteries, ensuring correct polarity (+/-).
Remote has limited functionality or some buttons don't work.	Remote is not compatible with your specific TV model.	Verify your TV model against the compatible list. Contact customer support if unsure.
Remote works intermittently.	Weak batteries or obstruction between remote and TV.	Replace batteries. Ensure a clear line of sight to the TV's IR receiver.

If troubleshooting steps do not resolve the issue, please contact customer support for further assistance.

Specifications

Model Number	RM-ED044 (AU-RM-ED044-SN052)
Brand	Azwok
Compatible Devices	Sony Bravia LCD Televisions (specific models listed in Introduction)
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Special Feature	No Programming Required
Product Dimensions	8.66 x 1.97 x 0.71 inches
Item Weight	3.17 ounces

Warranty and Support

Warranty Information

This Azwok RM-ED044 Replacement Remote Control comes with a 12-month replacement warranty from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as described. If the remote control fails to operate correctly with your compatible device within this period, you may be eligible for a replacement or exchange.

Customer Support

For any questions regarding compatibility, setup, operation, or warranty claims, please contact Azwok customer support. Provide your product model number (RM-ED044) and details of your issue for efficient assistance.

Note: Contact information for customer support is typically provided by the retailer or on the product packaging.

© 2024 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question