Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cecotec 08509

Cecotec IronHero 1800 Ultimate Vertical Steam Iron User Manual

Model: 08509

Important Safety Instructions

Please read these instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in accidents or damage to the product.

- Always ensure the voltage indicated on the appliance matches your mains voltage.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Do not leave the appliance unattended when connected to the power supply.
- Unplug the appliance after use and before cleaning.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged in any way.
- Use only manufacturer-recommended accessories.
- Do not direct steam at people, animals, or electrical appliances.
- The appliance becomes very hot during use. Handle with care.

Setup and Assembly

Before first use, ensure all packaging materials are removed. Familiarize yourself with the components of your Cecotec IronHero 1800 Ultimate vertical steam iron.

Components Overview

- Main unit with ceramic soleplate
- Water tank
- Power cord
- Lint brush attachment
- LED Touch Control panel



Figure 1: Front view of the Cecotec IronHero 1800 Ultimate vertical steam iron, showing the main body and control panel.



Figure 2: Side view of the steam iron, highlighting the water tank and ergonomic handle.

Filling the Water Tank

1. Ensure the appliance is unplugged from the power outlet.
2. Remove the water tank from the main unit.
3. Fill the water tank with clean tap water up to the MAX fill line. Do not overfill.
4. Reinsert the water tank securely into the main unit.

Operating Instructions

Follow these steps to effectively use your vertical steam iron for wrinkle removal and garment care.

Powering On and Heating

1. Plug the power cord into a suitable electrical outlet (230V AC).
2. Press the power button on the LED Touch Control panel to turn on the appliance. The indicator light will illuminate.
3. The iron will begin to heat up. The "Fast Steam" technology ensures it is ready for use in approximately 30 seconds.
4. Once the indicator light stops flashing and remains steady, the iron is ready to produce steam.



Figure 3: Activating the steam iron using the power button on the LED touch control panel.

Selecting Steam Modes

The IronHero 1800 Ultimate features 2 steam modes to suit different fabric types.

- Use the touch control panel to cycle through the available steam modes.
- Select a lower steam setting for delicate fabrics and a higher setting for heavier materials like cotton or linen.
- The "Power Steam" technology provides a continuous steam output of 28 g/min for effective wrinkle removal.

Steaming Garments

1. Hang the garment on a hanger.
2. Hold the steam iron vertically, keeping the soleplate a few centimeters away from the fabric.
3. Press the steam trigger to release steam. Move the iron slowly over the garment, from top to bottom.
4. For stubborn wrinkles, gently press the soleplate against the fabric while steaming.
5. The "Clean Steam" function helps to disinfect and deodorize your clothes during the process.



Figure 4: Steaming a shirt while it is on a hanger, demonstrating vertical use.



Figure 5: Detailed view of steaming a shirt sleeve, showing the steam output.

Using the Lint Brush Attachment

The included brush attachment is designed to remove lint, threads, and brush fabrics.

1. Ensure the iron is cool and unplugged before attaching or detaching the brush.
2. Align the brush attachment with the soleplate and press firmly until it clicks into place.
3. Use the brush attachment while steaming to simultaneously remove debris and smooth fabrics.



Figure 6: Demonstrating the attachment of the lint brush for use on a sweater.

Auto Shut-Off Feature

For safety, the appliance is equipped with an "Auto Shut-Off" system. If left inactive for a certain period, the iron will automatically turn off.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your steam iron.

Cleaning the Appliance

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. Empty any remaining water from the water tank.
3. Wipe the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners or solvents.
4. Clean the ceramic soleplate with a damp cloth. Do not use metallic scouring pads or harsh chemicals.

Descaling (if applicable)

Depending on water hardness, mineral deposits may build up over time. Refer to the full product manual for specific descaling instructions if a descaling function is present or recommended.

Troubleshooting Guide

If you encounter issues with your steam iron, consult the following table before contacting customer support.

Problem	Possible Cause	Solution
No steam output	Water tank is empty; appliance not heated sufficiently; steam button not pressed.	Fill water tank; wait for indicator light to stabilize; press steam button.
Water leaking from soleplate	Appliance not hot enough; water tank overfilled.	Allow iron to heat fully; do not overfill water tank.
Iron not turning on	Not plugged in; power outlet malfunction; Auto Shut-Off activated.	Check power connection; try a different outlet; press power button to restart.
Steam output is weak	Mineral buildup; low water level.	Perform descaling (if applicable); refill water tank.

Product Specifications

Brand: Cecotec

Model Number: 08509

Power: 1800 Watts

Voltage: 230 Volts (AC)

Continuous Steam Output: 28 g/min

Heat-up Time: Approximately 30 seconds

Weight: 1 Kilogram

Color: Black

Features: 2 Steam Modes, LED Touch Control, Fast Steam, Clean Steam, Anti-drip, Auto Shut-Off, Ceramic Soleplate

Included Accessories: Lint brush attachment

Country of Origin: Spain

Warranty Information

This product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. Information regarding spare parts availability indicates a period of 10 years.

Customer Support

For technical assistance, product inquiries, or warranty claims, please contact Cecotec customer service. Contact details can typically be found on the official Cecotec website or on the product packaging.
Note: Always have your product model number (08509) and purchase date ready when contacting support.

© 2026 Cecotec. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQ1DKPP5

More documents and user manuals: **https://manuals.plus/**