Acer AL16-52P-5547

Acer Aspire Lite AL16 Laptop User Manual

Model: AL16-52P-5547

1. Introduction

This manual provides essential information for the safe and efficient use of your Acer Aspire Lite AL16 Laptop. Please read this manual thoroughly before operating your device and retain it for future reference.



Figure 1: Front view of the Acer Aspire Lite AL16 Laptop.

2. Setup

2.1 Unpacking

Carefully remove all components from the packaging. Ensure the following items are present:

- Acer Aspire Lite AL16 Laptop
- AC Power Adapter and Power Cord
- Quick Start Guide (if included)

2.2 Initial Power-On and Charging

1. Connect the AC power adapter to the laptop's power input port.
2. Plug the power cord into an electrical outlet.
3. Open the laptop lid.
4. Press the power button, typically located on the keyboard or side of the chassis, to turn on the laptop.
5. Follow the on-screen instructions to complete the Windows 11 Home initial setup.

It is recommended to fully charge the battery before initial use. The laptop features a 45W battery designed for up to 12 hours of operation.

2.3 Connecting Peripherals

The Acer Aspire Lite AL16 provides various ports for connecting external devices:

- **USB 3.0 Ports:** Four ports for connecting USB devices such as external drives, mice, or keyboards.
- **HDMI Port:** One port for connecting to external displays or projectors.
- **Audio Jack:** For headphones or external speakers.
- **Kensington Lock Slot:** For physical security.



Figure 2: Left side ports including USB-C, HDMI, and USB-A.



Figure 3: Right side ports including Kensington lock, MicroSD card slot, two USB-A, and audio jack.

3. Operating Your Laptop

3.1 Power Management

- **Power On:** Press the power button.
- **Sleep Mode:** Close the lid or select 'Sleep' from the Windows Start menu.
- **Shut Down:** Select 'Shut down' from the Windows Start menu.
- **Restart:** Select 'Restart' from the Windows Start menu.

3.2 Keyboard and Touchpad

The laptop features a full-size keyboard and a precision touchpad for navigation.



Figure 4: Keyboard and touchpad layout.

- **Function Keys (Fn):** Use the 'Fn' key in combination with the F1-F12 keys for various functions like adjusting brightness, volume, or enabling/disabling Wi-Fi.
- **Touchpad Gestures:** Refer to Windows settings for customizable touchpad gestures for scrolling, zooming, and switching applications.

3.3 Display and Audio

- **Display:** The 16-inch WUXGA IPS SlimBezel display offers a resolution of 1920 x 1200 pixels for clear visuals.
- **Audio:** Integrated speakers provide audio output. An audio jack is available for connecting headphones or external speakers.

3.4 Connectivity

- **Wi-Fi 6 (802.11ax):** For high-speed wireless internet access.
- **Bluetooth:** For connecting wireless peripherals such as mice, keyboards, or headphones.

4. Maintenance

4.1 Battery Care

- Avoid exposing the battery to extreme temperatures.
- For optimal battery life, avoid frequently discharging the battery completely.
- If storing the laptop for an extended period, ensure the battery is charged to approximately 50%.

4.2 Cleaning Instructions

- Disconnect the power adapter and turn off the laptop before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a specialized screen cleaner for the display.

- For the chassis and keyboard, use a soft, dry cloth. Avoid harsh chemicals or abrasive materials.

4.3 Software Updates


Regularly check for and install operating system updates (Windows Update) and driver updates from the Acer support website to ensure optimal performance and security.

5. Troubleshooting

This section provides solutions to common issues you may encounter. If the problem persists, contact an authorized service center.

Error Message	Corrective Action
CMOS battery bad	Contact your dealer or an authorized service center.
CMOS checksum error	Contact your dealer or an authorized service center.
Disk boot failure	Insert a system (bootable) disk, then press **Enter** to reboot.
Equipment configuration error	Press **F2** (during POST) to enter the BIOS utility, then press **Exit** in the BIOS utility to reboot.
Hard disk 0 error	Contact your dealer or an authorized service center.
Hard disk 0 extended type error	Contact your dealer or an authorized service center.
I/O parity error	Contact your dealer or an authorized service center.
Keyboard error or no keyboard connected	Contact your dealer or an authorized service center.
Keyboard interface error	Contact your dealer or an authorized service center.
Memory size mismatch	Press **F2** (during POST) to enter the BIOS utility, then press **Exit** in the BIOS utility to reboot.

If you still encounter problems after going through the corrective measures, please contact your dealer or an authorized service center for assistance.



If you receive an error message, note the message and take the corrective action. The following table lists the error messages in alphabetical order together with the recommended course of action.

Error messages	Corrective action
CMOS battery bad	Contact your dealer or an authorized service center.
CMOS checksum error	Contact your dealer or an authorized service center.
Disk boot failure	Insert a system (bootable) disk, then press **Enter** to reboot.
Equipment configuration error	Press **F2** (during POST) to enter the BIOS utility, then press **Exit** in the BIOS utility to reboot.
Hard disk 0 error	Contact your dealer or an authorized service center.
Hard disk 0 extended type error	Contact your dealer or an authorized service center.

Error messages	Corrective action
I/O parity error	Contact your dealer or an authorized service center.
Keyboard error or no keyboard connected	Contact your dealer or an authorized service center.
Keyboard interface error	Contact your dealer or an authorized service center.
Memory size mismatch	Press **F2** (during POST) to enter the BIOS utility, then press **Exit** in the BIOS utility to reboot.

If you still encounter problems after going through the corrective measures, please contact your dealer or an authorized service center for assistance.

Figure 5: Excerpt from a troubleshooting guide for common system errors.

6. Specifications

The following table details the technical specifications of the Acer Aspire Lite AL16 Laptop (Model AL16-52P-5547).

Feature	Detail
Brand	Acer
Model Name	Aspire Lite AL16-52P-5547
Item Model Number	NX.J2SEM.004
Processor	13th Gen Intel Core i5-1334U (10 Cores, up to 4.6GHz)
Memory (RAM)	16GB DDR5
Storage	512GB SSD
Graphics	Intel Iris Xe Graphics (Integrated)

Feature	Detail
Display	16-inch WUXGA (1920 x 1200) IPS SlimBezel LED LCD
Operating System	Windows 11 Home
Wireless Connectivity	Wi-Fi 6 (802.11ax), Bluetooth
Ports	4x USB 3.0, 1x HDMI, Audio Jack
Battery	1 Lithium Ion (57.5 Watt Hours), up to 12 hours average life
Dimensions	27 x 19 x 9 cm
Weight	1.5 Kilograms
Color	Pure Silver

7. Warranty and Support

7.1 Warranty Information

Your Acer Aspire Lite AL16 Laptop is covered by a limited warranty. Please refer to the warranty card included with your product or visit the official Acer website for detailed terms and conditions.

7.2 Technical Support

For technical assistance, product inquiries, or service requests, please contact your dealer or an authorized Acer service center. Ensure you have your product model name (AL16-52P-5547) and serial number available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question