Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok GCBLTV64AI-D3

Azwok GCBLTV64AI-D3 Replacement Remote Control User Manual

For CHIQ TV Models: UHD55E6000ISX2, UHD65E6200ISX2

Introduction

This manual provides comprehensive instructions for the Azwok GCBLTV64AI-D3 Replacement Remote Control. This remote is designed to function as a direct replacement for the original remote controls of specific CHIQ TV models, offering all essential functions without the need for complex programming.

Compatible CHIQ TV Models:

- UHD55E6000ISX2
- UHD65E6200ISX2

Setup

Battery Installation

The Azwok GCBLTV64AI-D3 remote control requires two AAA batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use. No programming or pairing is required.



This image illustrates the open battery compartment on the back of the remote control, revealing the two slots for AAA batteries and their polarity markings.

Operating Instructions

To operate your CHIQ TV with the Azwok GCBLTV64AI-D3 remote control, ensure there is a clear line of sight between the remote's infrared emitter and the TV's infrared receiver.


P.MODE
S.MODE
ANT
TOOLS
1
2
3
4
5
6
7
8
9
MENU
0
EXIT
OK
BACK/
HOME/
SOURCE
+
APPS
P
−
EPG
LIST
FAV



This image displays the full layout of the remote control's buttons, including power, channel, volume, number pad, navigation, and special function keys.

Basic Functions:

- **Power Button ( ):** Turns the television on or off.
- **Number Buttons (0-9):** Directly select channels or input numerical values.
- **Volume Up/Down (+/-):** Adjusts the television's audio volume.
- **Channel Up/Down (P^/P˅):** Changes the television channel sequentially.
- **Mute ( ):** Toggles the television's sound on or off.

Navigation and Menu:

- **Directional Pad (Up, Down, Left, Right):** Navigates through menus and options.
- **OK Button:** Confirms selections or enters sub-menus.
- **MENU Button:** Accesses the television's main menu.
- **EXIT Button:** Exits current menus or on-screen displays.
- **HOME/SOURCE Button:** Switches between input sources (HDMI, AV, etc.) or returns to the home screen.
- **BACK/↩ Button:** Returns to the previous screen or menu.

Special Functions:

- **P.MODE / S.MODE:** Picture Mode / Sound Mode selection.
- **ANT:** Selects antenna input.
- **TOOLS:** Accesses quick settings or tools menu.
- **APPS:** Direct access to smart TV applications.
- **EPG:** Electronic Program Guide.
- **LIST:** Displays channel list.
- **FAV:** Accesses favorite channels.
- **Color Buttons (Red, Green, Yellow, Blue):** Functionality varies depending on the TV menu or application.

Maintenance

Battery Care:

- Replace batteries when the remote control's response becomes inconsistent or weak.
- If the remote control will not be used for an extended period (e.g., one month or more), remove the batteries to prevent potential leakage and damage.
- Dispose of used batteries responsibly according to local regulations.

Cleaning:

- Clean the remote control with a soft, dry cloth.

- Avoid using abrasive cleaners, solvents, or liquid sprays, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote Control Not Responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with fresh AAA batteries.
  - Check for any obstructions between the remote control and the television's infrared sensor.
  - Confirm that the remote control is pointed directly at the television.
- **Limited Functionality or Incorrect Responses:**
  - Verify that your CHIQ TV model is one of the compatible models listed (UHD55E6000ISX2, UHD65E6200ISX2). This remote is specifically designed for these models.
  - If your TV model is not listed, this remote may not be fully compatible.

Specifications

Model:	GCBLTV64AI-D3
Brand:	Azwok
Compatible TV Models:	CHIQ UHD55E6000ISX2, UHD65E6200ISX2
Connectivity Technology:	Infrared
Power Source:	2 x AAA Batteries (not included)
Product Dimensions:	8.27 x 1.89 x 0.79 inches (21 x 4.8 x 2 cm)
Item Weight:	2.46 ounces (70 grams)

Warranty and Support

This Azwok GCBLTV64AI-D3 replacement remote control comes with a 1-year replacement warranty from the date of purchase.

For any questions regarding compatibility, functionality, or warranty claims, please contact Azwok customer service. Provide your product model number (GCBLTV64AI-D3) and your CHIQ TV model for efficient assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQFHRCV5

More documents and user manuals: **https://manuals.plus/**