Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-UV013-BA

User Manual for Azwok Replacement Remote Control

Model: AU-UV013-BA

Introduction

This manual provides comprehensive instructions for the Azwok Replacement Remote Control, model AU-UV013-BA. This remote is designed as a direct replacement for original Bauhn HD Smart TV remote controls, offering full functionality without the need for complex programming.

Compatible Bauhn TV Models:

- ATV40FHDS-0320
- ATV32HDS-0420
- ATV40FHDS-0720
- ATV32HDS-1020
- ATV40FHDS-1220

If your specific model is not listed, or if your original remote differs significantly, please refer to the "Troubleshooting" section or contact customer support for assistance.

Product Features

- New replacement remote control for Bauhn HD Smart TV.
- Suitable for the specified Bauhn TV models.
- Ready to use upon battery installation; no programming required.
- Simple to operate, serving as an effective replacement for defective or lost original remotes.
- Durable design for reliable performance.

Setup

Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside

the compartment.

4. Slide the battery cover back into place until it clicks securely.



Image: Back of the remote control showing the battery compartment.



Image: Battery compartment with cover removed, ready for battery insertion.

Initial Use

Once batteries are installed, the remote control is ready for immediate use. No programming or pairing is required. Simply point the remote at your Bauhn HD Smart TV and begin operating it.

Operating Instructions

The Azwok Replacement Remote Control replicates the functions of your original Bauhn TV remote. Ensure a clear line of sight between the remote's infrared emitter and the TV's IR receiver for optimal performance.



Image: Front view of the remote control.



Image: Angled view of the remote control.

Key Functions Overview

Button	Function
Power (Red)	Turns the TV on or off.
Mute	Mutes or unmutes the TV audio.
0-9 (Number Buttons)	Direct channel selection or numerical input.
INFO	Displays program information.
LIST	Accesses the channel list.
Colored Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions, often for teletext or smart TV features.
Settings (Gear Icon)	Opens the TV's settings menu.
Back (Arrow)	Navigates back in menus or previous channel.
Navigation Pad (Up, Down, Left, Right)	Navigates through menus and options.
OK	Confirms selections.
EPG	Electronic Program Guide.
P.MODE	Picture Mode selection.
S.MODE	Sound Mode selection.
Source / Input	Selects input source (HDMI, AV, etc.).
Home (House Icon)	Accesses the TV's smart home screen.
Menu (Three Lines)	Opens the main menu.
Volume Up/Down (+/-)	Adjusts the volume level.
Channel Up/Down (P+/P-)	Changes the TV channel.

Button	Function
Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Skip)	Controls media playback (e.g., USB content, streaming apps).
Netflix, YouTube, Browser, Prime Video	Direct access buttons for popular streaming services and web browser.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones.
- **Storage:** When not in use for extended periods, store the remote in a dry place away from direct sunlight and extreme temperatures. Remove batteries if storing for several months to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

Troubleshooting

Problem	Possible Cause / Solution
Remote is not working.	• **Batteries:** Check if batteries are inserted correctly (+/- alignment). Replace old or depleted batteries with new AAA batteries. • **Line of Sight:** Ensure there is a clear path between the remote and the TV's infrared sensor. Remove any obstructions. • **TV Sensor:** Confirm the TV's IR sensor is not blocked or dirty.
Some buttons do not function.	• **Compatibility:** While designed for specific Bauhn models, some advanced or unique functions of your original remote might not be replicated if they are not standard. • **TV Settings:** Ensure the TV's settings are not preventing certain functions (e.g., parental controls). • **Remote Malfunction:** If only a few buttons fail, the remote might be defective.
Remote works intermittently.	• **Low Batteries:** Replace batteries. • **Interference:** Other electronic devices might be causing interference. Move them away from the TV or remote.

Important Note: If your TV model number is not listed in the "Introduction" section or if your original remote control looks significantly different from this replacement, please contact the seller or manufacturer for compatibility confirmation before use. This will help ensure you have the correct remote for your device.

Specifications

- **Model Number:** AU-UV013-BA
- **Product Dimensions:** 8.46 x 1.97 x 0.79 inches
- **Item Weight:** 2.46 ounces
- **Batteries Required:** 2 x AAA (not included)

- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Bauhn HD Smart Televisions (specific models listed in Introduction)
- **Special Feature:** No Programming Required

Warranty and Support

This Azwok Replacement Remote Control comes with a**12-month replacement warranty** from the date of purchase. If the product is found to be defective or does not function as described within this period, please contact the seller for a replacement or exchange.
Returns are accepted for refund or exchange if the remote does not work with your specified device models.
For any questions, concerns, or assistance with troubleshooting, please reach out to the seller or Azwok customer support. Provide your product model number (AU-UV013-BA) and your TV's model number for faster service.

© 2023 Azwok. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQFJT5LS

More documents and user manuals: **https://manuals.plus/**