Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok RM-BA004-BA

Azwok Replacement Remote Control User Manual

For Bauhn 4K Smart TV Models: ATV55UHDS-0920, ATV65UHDS-1221, ATV75UHDS-1219

Introduction

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your Azwok replacement remote control. This remote is designed to function as a direct replacement for the original remote controls of specified Bauhn 4K Smart TV models without requiring any programming.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.





Image 1: Rear view of the Azwok remote control with the battery cover removed, illustrating the battery compartment for two AAA batteries.

2. Initial Use

This replacement remote control is pre-programmed and does not require any setup or code entry. Once batteries are installed, it is ready for immediate use with compatible Bauhn TV models.

Compatible Models:

- Bauhn ATV55UHDS-0920

- Bauhn ATV65UHDS-1221
- Bauhn ATV75UHDS-1219

If your TV model is not listed, or if the remote does not function as expected, please refer to the Troubleshooting section or contact support.

Operating Instructions

The Azwok replacement remote control features a layout similar to the original Bauhn TV remote. Below is a general guide to its functions.





Image 2: Front view of the Azwok remote control, displaying the full button layout.

Button Functions:

- **Power (●):** Turns the TV on or off.
- **SOURCE:** Selects input sources (HDMI, AV, etc.).
- **Number Buttons (0-9):** Direct channel selection or inputting numbers.
- **INFO:** Displays current program information.
- **SUBT.:** Toggles subtitles on/off.
- **CH.LIST:** Displays the channel list.
- **HOME:** Accesses the TV's smart home screen or main menu.
- **NETFLIX:** Direct access to the Netflix application.
- **YouTube:** Direct access to the YouTube application.
- **Q.MENU:** Quick menu access.
- **MENU:** Accesses the main settings menu.
- **Navigation Buttons (▲ ▼ ◀ ▶):** Navigates through menus and options.
- **OK:** Confirms selections.
- **BACK:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or application.
- **Color Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV menu or application.
- **VOL (+/-):** Adjusts volume up or down.
- **CH (▲/▼):** Changes channels up or down.
- **MUTE:** Mutes or unmutes the TV sound.
- **GUIDE:** Displays the electronic program guide.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next, REC):** Controls media playback.
- **TIMESHIFT:** Activates or deactivates the timeshift function.
- **P.MODE:** Picture mode selection.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote.

Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage, which can damage the remote control.

Troubleshooting

- **Remote control is not working:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and line of sight of the TV.
- **Remote control functions are intermittent:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure there is no interference from other electronic devices.
- **Remote control does not control my specific Bauhn TV model:**
  - Verify that your TV model number (e.g., ATV55UHDS-0920) is listed as compatible in the "Setup" section.
  - If your model is not listed, this remote may not be compatible. Contact the seller for assistance.

Specifications

Model Number	RM-BA004-BA
Compatible TV Brands	Bauhn
Compatible TV Models	ATV55UHDS-0920, ATV65UHDS-1221, ATV75UHDS-1219
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	7.87 x 1.77 x 0.79 inches (approx.)
Item Weight	2.11 ounces (approx.)

Warranty Information

This Azwok replacement remote control comes with a**12-month replacement warranty** from the date of purchase. This warranty covers manufacturing defects and ensures that the remote functions as intended for compatible models. If the product is found to be defective or incompatible with the specified models within this period, a replacement will be provided.
Please retain your proof of purchase for warranty claims.

Support

For further assistance, troubleshooting not covered in this manual, or warranty claims, please contact the seller or retailer from whom you purchased this product. Provide your product model number (RM-BA004-BA) and your TV's model number for quicker service.
You can typically find contact information on your purchase receipt or the seller's online store page.

© 2023 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQGYG9TP

More documents and user manuals: **https://manuals.plus/**