**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Azwok RM-BA001-BA

# Azwok Replacement Remote Control Instruction Manual

Model: RM-BA001-BA

### Introduction

This manual provides comprehensive instructions for the Azwok RM-BA001-BA replacement remote control, designed for various Bauhn TV models. This remote offers full functionality without the need for programming. Please read this manual carefully to ensure proper use and longevity of your remote control.

### Product Overview

The Azwok RM-BA001-BA is a direct replacement remote control for compatible Bauhn TV models. It features a standard layout with all essential buttons for TV operation.






**Image 1:** Front view of the Azwok RM-BA001-BA replacement remote control. This image displays the full button layout, including power, channel, volume, numeric keypad, menu, and navigation buttons.

## Setup: Battery Installation

The remote control requires two AAA batteries (not included) for operation. No programming is necessary; once batteries are installed, the remote is ready to use.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.







**Image 2:** Back view of the remote control with the battery cover removed, showing the battery compartment ready for AAA battery insertion.

## Operating Instructions

To operate your Bauhn TV with this remote control, simply point the remote directly at the TV's infrared sensor. Ensure there are no obstructions between the remote and the TV.

### Key Button Functions:

- **STANDBY (Red Button):** Powers the TV on or off (standby mode).
- **TV/RADIO:** Switches between TV and Radio modes.
- **SOURCE:** Selects input sources (HDMI, AV, etc.).
- **PMODE:** Picture Mode selection.
- **SMODE:** Sound Mode selection.
- **SLEEP:** Sets the sleep timer.
- **MUTE:** Mutes or unmutes the TV sound.
- **Numeric Keypad (0-9):** Directly enters channel numbers.
- **MENU:** Accesses the TV's main menu.
- **EXIT:** Exits the current menu or function.
- **TEXT:** Activates or deactivates Teletext.
- **DISPLAY:** Shows current channel information.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **VOL+/-:** Adjusts the volume level.
- **CH+/-:** Changes the TV channel.
- **GOTO:** Jumps to a specific time in media playback.
- **ANGLE:** Changes viewing angle for compatible media.
- **REPEAT:** Repeats media playback.
- **A-B:** Repeats a specific segment of media.
- **HOLD:** Holds Teletext page.
- **SIZE:** Adjusts screen size/aspect ratio.
- **SUBTITLE:** Toggles subtitles on/off.
- **AUDIO:** Selects audio tracks or languages.
- **FREEZE:** Freezes the current image.
- **ZOOM:** Zooms in on the screen.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next):**Controls media playback.
- **D.SETUP:** Digital setup.
- **D.MENU:** Digital menu.
- **MEDIA:** Accesses media player functions.
- **EPG:** Electronic Program Guide.

## Maintenance

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA batteries.
- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.

## Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Some buttons not working:**
  - This remote is designed to be compatible with a wide range of Bauhn TV models. While it includes all major functions, some specific buttons might not be supported by all TV models.
  - Clean the remote's surface, especially around the unresponsive buttons, to ensure no debris is interfering.

## Specifications

- **Model:** RM-BA001-BA
- **Brand:** Azwok
- **Connectivity Technology:** Infrared (IR)
- **Batteries Required:** 2 x AAA (not included)
- **Product Dimensions:** 7.87 x 1.97 x 0.59 inches (20 x 5 x 1.5 cm)
- **Item Weight:** 2.82 ounces (80 grams)
- **Special Feature:** No Programming Required
- **Compatible Bauhn TV Models:**
  - ATV-32HDC1N
  - ATV-24LEC2
  - ATV-24LEC3
  - AS-39FHD1
  - AS-47FHZ1
  - ATV-50FHD5
  - ATV-46FLEM
  - ATV185-014
  - AT215D-0216
  - ATV32-715
  - ATV32H-014
  - ATV32H-1215
  - ATV40-014
  - ATV50-715
  - ATV50F-415
  - ATVU40-0416

- ATV40-1014

## Warranty and Support

This Azwok replacement remote control comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects. If you experience any issues or have questions regarding compatibility or functionality, please contact the seller or manufacturer for assistance. Returns are accepted for refund or exchange if the remote does not function with your compatible device.
For further support, please refer to the contact information provided by your retailer or the Azwok brand.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B0BQGYZS5P**

More documents and user manuals: **https://manuals.plus/**