**Pokémon PKW3330**

# Pokémon Train and Play Deluxe Pikachu Interactive Figure Instruction Manual

Model: PKW3330

## 1. Important Safety Information

Please read all instructions before using this product. Keep this manual for future reference.

- **Choking Hazard - Small Parts:** This product contains small parts and is not suitable for children under 3 years of age.
- Adult supervision is recommended during play.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the product is not used for an extended period.
- Dispose of batteries properly according to local regulations.

## 2. Product Overview

The Pokémon Train and Play Deluxe Pikachu is an interactive figure designed to provide engaging play. This 4.5-inch figure features over 50 unique reactions, including sounds, light-up cheeks, and movement in its arms, ears, and tail. It comes with two interactive berry accessories that trigger specific responses when brought near its nose. Pikachu also responds to touch on its head and voice commands.

### 2.1. Package Contents

- (1) 4.5-Inch Train and Play Deluxe Pikachu Figure
- (2) Interactive Berry Accessories (1 Red Apple, 1 Pink Berry)
- (3) AAA Batteries (pre-installed)

### 2.2. Figure Features

- **Interactive Berries:** Triggers reactions when held to Pikachu's nose.
- **Touch Sensor:** Responds to touch on its head.
- **Voice Recognition:** Reacts to spoken words.

- **Lights & Sounds:** Cheeks light up, and various sounds are emitted.
- **Movement:** Arms, ears, and tail move.
- **Power Modes:** ON, OFF, and TRY ME.



Figure of Pikachu with its two interactive berry accessories, a red apple and a pink berry.

## 3. Setup

### 3.1. Battery Installation

The Pikachu figure comes with three AAA batteries pre-installed. If replacement is needed, follow these steps:

1. Locate the battery compartment on Pikachu's back.
2. Using a Phillips head screwdriver, unscrew the panel covering the battery compartment.
3. Remove the old batteries and insert three new AAA batteries, ensuring correct polarity (+/-).

4. Replace the battery compartment cover and secure it with the screw.



The back of the Pikachu figure, illustrating the location of the battery compartment and screw.

### 3.2. Power Modes

A switch on Pikachu's back controls its power modes:

- **OFF:** Turns the figure off completely.
- **TRY ME:** Activates demonstration mode with limited features.
- **ON:** Activates full interactive play mode.

Set the switch to **ON** for full functionality.

## 4. Operating Instructions

### 4.1. Interactive Berry Play

Pikachu reacts differently to each of the two included berry accessories:

- Hold the red apple accessory close to Pikachu's nose to elicit a specific reaction.
- Hold the pink berry accessory close to Pikachu's nose to elicit a different specific reaction.



A hand holding the pink berry accessory near Pikachu's nose to trigger an interaction.



A hand holding the red apple accessory near Pikachu's nose to trigger an interaction.

## 4.2. Touch and Voice Interaction

Pikachu is designed to respond to physical touch and spoken words:

- Gently touch Pikachu's head to activate various sounds and movements.
- Speak to Pikachu to initiate a response. The figure is programmed to react to voice input.



A hand gently touching the top of Pikachu's head to activate its touch sensor.



The Pikachu figure demonstrating movement in its arms and ears, indicating an active reaction.

## 5. Maintenance

- **Cleaning:** Wipe the figure with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** As mentioned in safety information, remove batteries if the product is not used for extended periods to prevent leakage.

## 6. Troubleshooting

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| Pikachu does not turn on or respond. | ◦ Batteries are dead or incorrectly installed.<br>◦ Power switch is in OFF or TRY ME mode. | ◦ Replace batteries, ensuring correct polarity.<br>◦ Set the power switch to ON. |
| Pikachu is not reacting to berries, touch, or voice. | ◦ Power switch is in TRY ME mode.<br>◦ Interactions are not performed correctly (e.g., berry too far from nose).<br>◦ Low battery power. | ◦ Set the power switch to ON.<br>◦ Ensure berries are held directly to Pikachu's nose.<br>◦ Ensure touch is firm and voice is clear.<br>◦ Replace batteries. |
| Sounds are distorted or too quiet. | ◦ Low battery power. | ◦ Replace batteries. |

## 7. Specifications

| Feature | Detail |
|---|---|
| **Model Number** | PKW3330 |
| **Product Dimensions** | 4.5 x 9 x 12 inches |
| **Item Weight** | 1.37 pounds |
| **Batteries** | 3 x AAA batteries (included) |
| **Manufacturer Recommended Age** | 4 years and up |
| **Manufacturer** | Jazwares LLC |
| **Release Date** | August 1, 2023 |

## 8. Warranty and Support

This product is manufactured by Jazwares LLC. For information regarding warranty coverage or technical support, please refer to the contact information provided on the product packaging or visit the official Jazwares website. Keep your purchase receipt as proof of purchase for any warranty claims.
For additional information or inquiries, please contact Jazwares LLC customer service.

© 2024 Pokémon / Nintendo / Creatures / GAME FREAK. All rights reserved.
Jazwares LLC. All rights reserved.