Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pockrif L4-WELG-H2XQ

Pockrif Fireproof Waterproof Safe User Manual

Model: L4-WELG-H2XQ

Introduction

Thank you for choosing the Pockrif Fireproof Waterproof Safe. This manual provides essential information for the proper installation, operation, and maintenance of your safe. Please read these instructions carefully before using the product to ensure optimal performance and security. Keep this manual for future reference.

Product Features

- **Robust Construction:** Made from solid steel with three live-locking steel bolts, thick concealed hinges, and a recessed door for enhanced physical protection against forced entry.
- **Fireproof & Waterproof:** Designed to protect your valuables from fire and water damage. Includes a fireproof and waterproof document bag for added protection.
- **Digital Keypad Access:** Features a responsive electronic keypad for quick and convenient access with a programmable code.
- **Emergency Access:** Equipped with an emergency key and an external battery box for access in case of forgotten password or depleted internal batteries.
- **Smart Alarm System:** A dual alarm system activates after 3 incorrect password entries (20-second lockout) and 6 incorrect entries (5-minute lockout) to deter unauthorized access.
- **Internal LED Light:** A built-in LED light provides improved visibility inside the safe, making it easier to access items in low-light conditions.
- **Removable Shelf:** An adjustable and removable shelf allows for flexible organization of various items within the safe.



This image demonstrates the versatility of the safe's interior, showing how the removable shelf can be used to organize various items like cash, jewelry, and documents.



A detailed view of the safe's robust locking mechanism, featuring three solid steel anti-pry bolts designed to enhance security against forced entry.

Package Contents

Upon unpacking, please verify that all the following components are included:

- 1 x Pockrif Fireproof Waterproof Safe
- 1 x Fireproof and Waterproof Document Bag
- 2 x Emergency Keys
- 1 x Emergency Battery Box
- 4 x Expansion Screws (for mounting)
- 1 x User Manual (this document)



This image illustrates the external dimensions of the Pockrif safe and details the items included in the package, such as mounting hardware, emergency keys, and the fireproof bag.

SPECIFICATIONS

Brand	Pockrif
Model Number	L4-WELG-H2XQ
Material	Alloy Steel
Color	Black
External Dimensions (H x W x D)	50 cm x 38 cm x 31 cm (19.68 in x 14.57 in x 12.2 in)
Capacity	2.8 Cubic Feet

Weight	17.01 kg (37.5 lbs)
Lock Type	Electronic Combination Lock
Special Features	Fireproof, Waterproof, Alarm System, Sensor Light
Mounting Type	Wall and Floor Mount
Batteries Required	Yes (4 x AA batteries, not included)

Setup

1. Initial Battery Installation

1. Locate the battery compartment on the inside of the safe door.
2. Insert 4 AA batteries (not included) into the compartment, ensuring correct polarity.
3. Close the battery compartment cover.

Note: Always use new, high-quality batteries. Replace batteries annually or when the low battery indicator appears.

2. Emergency Key Usage

The safe comes with two emergency keys. These keys can open the safe directly, bypassing the electronic keypad. Keep these keys in a secure location outside the safe, but easily accessible in case of emergency or battery failure.

3. Mounting the Safe (Optional)

For enhanced security, the safe can be bolted to a wall or floor. Mounting hardware (expansion screws) is included.

1. Choose a suitable location for the safe.
2. Mark the drilling points through the pre-drilled holes at the back or bottom of the safe.
3. Drill holes into the wall or floor using an appropriate drill bit.
4. Align the safe with the drilled holes and insert the expansion screws.
5. Tighten the screws securely to fix the safe in place.



This diagram provides a step-by-step visual guide for securely mounting the Pockrif safe to either a wall or the floor, enhancing its stability and theft deterrence.

Operating Instructions

1. Opening the Safe

There are three primary methods to open your Pockrif safe:

- **Using Personal Password:** Enter your programmed password on the keypad, then turn the knob clockwise to open the door.
- **Using Emergency Key:** Insert the emergency key into the keyhole, turn it clockwise, then turn the knob clockwise to open the door.
- **Using External Battery Box (if internal batteries are dead):**Connect the external battery box to the port on the keypad. Enter your personal password, then turn the knob clockwise to open the door.



This diagram visually explains the three ways to access the safe: using a personal password with the knob, using an emergency key with the knob, or using the external battery box in conjunction with the password and knob if internal batteries are depleted.

2. Setting/Changing Your Password

1. With the safe door open, locate the red reset button on the inside of the door.
2. Press the reset button. The indicator light on the keypad will flash.
3. Enter your new password (3-8 digits) on the keypad.
4. Press the '#' key to confirm. The indicator light will stop flashing, confirming the new password is set.
5. Test the new password with the door open before closing it.

3. Alarm System

The safe is equipped with a smart alarm system:

- If an incorrect password is entered 3 times consecutively, the system will lock for 20 seconds.
- If an incorrect password is entered 6 times consecutively, the system will lock for 5 minutes.
- A low battery reminder will activate when batteries are running low.



This image highlights the safe's smart alarm system, which includes an audible alarm and a low battery reminder, ensuring continuous protection and operational readiness.

4. Using the Removable Shelf

The internal shelf can be removed or adjusted to accommodate items of different sizes. Simply lift and slide the shelf out of its supports to remove it, or place it on the desired support level.

Maintenance

- **Cleaning:** Wipe the safe's exterior with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Battery Replacement:** Replace the internal AA batteries annually or immediately when the low battery indicator is active to ensure continuous operation of the electronic lock.
- **Key Storage:** Always store emergency keys in a secure, separate location away from the safe.

- **Door Seal:** Periodically check the door seal for any signs of wear or damage to maintain its fireproof and waterproof integrity.

Troubleshooting

Problem	Solution
Safe does not open with password.	Ensure batteries are fresh and correctly installed. Try using the emergency key or the external battery box. Re-enter the password carefully.
Keypad is unresponsive.	Replace the batteries. If still unresponsive, use the emergency key.
Alarm sounds frequently.	Ensure no one is attempting to open the safe with incorrect passwords. Check for low battery warnings.
Door does not close properly.	Check for any obstructions around the door frame or locking bolts. Ensure the safe is on a level surface.
Lost emergency key.	Contact customer support with the serial number of your safe to inquire about replacement keys.

Warranty and Support

Pockrif offers a lifetime warranty for this product. We also provide 24-hour online customer service and a 120-day return or exchange service. Your satisfaction is our priority.
For any questions, technical assistance, or warranty claims, please contact Pockrif customer support through the retailer's platform or the contact information provided with your purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQMC5GPW

More documents and user manuals: **https://manuals.plus/**