Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok RM-C3179

Azwok RM-C3179 Remote Control User Manual

For JVC LCD/LED Televisions

Introduction

This manual provides instructions for the Azwok RM-C3179 replacement remote control, designed for various JVC LCD and LED television models. This remote control is ready to use without any programming, offering a direct replacement for your original JVC RM-C3179 remote.

Setup

Battery Installation

The RM-C3179 remote control requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

The remote control is now ready for use.





Image showing the back of the RM-C3179 remote control with the battery compartment open, illustrating where to insert two AAA batteries.





Image showing the back of the RM-C3179 remote control with the battery compartment closed.

Operating Instructions

The Azwok RM-C3179 remote control functions identically to the original JVC RM-C3179 remote. Point the remote control directly at your television's infrared sensor for optimal performance.

Key Functions Overview





Front view of the Azwok RM-C3179 remote control, displaying all buttons and their labels.

- **Power Button:** Located at the top, used to turn the TV on or off.
- **Netflix Button:** Direct access to the Netflix application.
- **Numeric Keypad (0-9):** For direct channel selection and text input.
- **Volume Control (V+/V-):** Adjusts the television's sound volume.
- **Channel Control (P+/P-):** Changes television channels.
- **Mute Button:** Silences the television audio.
- **Menu Button:** Accesses the television's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Back/Exit Buttons:** Returns to the previous screen or exits a menu.
- **Color Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and application.
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.
- **Language Button (LANG.):** Changes audio language or subtitle options.

Compatible JVC TV Models

This replacement remote control is compatible with a wide range of JVC LCD and LED TV models. A partial list includes:

- LT24C655, LT-24C655, LT24C656, LT-24C656, LT24C660, LT-24C660, LT24C661, LT-24C661
- LT24VD43A, LT-24VD43A, LT24VH43A, LT-24VH43A
- LT32C650, LT-32C650, LT32C655, LT-32C655, LT32VH43A, LT-32VH43A, LT32VH53A, LT-32VH53A, LT32VH53B, LT-32VH53B
- LT40C750, LT-40C750, LT40C755, LT-40C755, LT40VF43A, LT-40VF43A, LT40VF53A, LT-40VF53A, LT40VU83A, LT-40VU83A
- LT43VF43A, LT-43VF43A, LT43VU83A, LT-43VU83A, LT43VU83B, LT-43VU83B
- LT48VU83A, LT-48VU83A, LT48VU83B, LT-48VU83B
- LT49VF43A, LT-49VF43A, LT49VF43B, LT-49VF43B, LT49VF53A, LT-49VF53A, LT49VU83A, LT-49VU83A, LT49VU83B, LT-49VU83B
- LT50C750, LT-50C750
- LT55VU83A, LT-55VU83A, LT55VU83B, LT-55VU83B

- LT65VF53A, LT-65VF53A, LT65VF53B, LT-65VF53B, LT65VU83A, LT-65VU83A, LT65VU83B, LT-65VU83B
- UX-D327B, UXD327B

If your specific JVC TV model is not listed, or if you are unsure about compatibility, please refer to the product listing or contact customer support for verification.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops functioning. Always replace both AAA batteries simultaneously with new ones to ensure consistent performance.

Cleaning

To clean the remote control, use a soft, dry cloth. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the surface or internal components.

Troubleshooting

- **Remote Control Not Responding:**
  - Ensure batteries are inserted correctly with the proper polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any physical obstructions between the remote control and the TV's infrared sensor.
  - Ensure the remote control is pointed directly at the TV's infrared receiver.
- **Specific Buttons Not Working:**
  - This may indicate a faulty button or a need for battery replacement. If replacing batteries does not resolve the issue, contact customer support.
- **Remote Control Works Intermittently:**
  - This often indicates low battery power. Replace both batteries with new ones.

Specifications

- **Model:** RM-C3179 (AU-RM-C3179-JV008)
- **Brand:** Azwok
- **Compatible Devices:** JVC LCD/LED Televisions
- **Connectivity Technology:** Infrared
- **Batteries Required:** 2 x AAA (not included)
- **Special Feature:** No Programming Required
- **Product Dimensions:** 8.86 x 1.97 x 0.59 inches
- **Item Weight:** 3.53 ounces

Warranty and Support

This Azwok RM-C3179 remote control comes with a 12-month replacement warranty. If the remote control does not function with your compatible device, returns are accepted for refund or exchange as per the warranty terms.

For further assistance, troubleshooting, or warranty claims, please contact Azwok customer support through the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQN829QS

More documents and user manuals: **https://manuals.plus/**