Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok RM-I08U RM-I09U

Azwok RM-I08U RM-I09U Remote Control User Manual

Replacement Remote Control for Humax HD Smart Digital TV Recorders

1. Introduction

This manual provides comprehensive instructions for the Azwok RM-I08U RM-I09U replacement remote control. This remote is designed to function as a direct replacement for your original Humax remote, offering all major buttons and functions.

Compatible Humax Models:

- HB-1000S
- HDR-2000T
- HDR-1000
- HDR-1800T
- HDR-1100
- HDR-1000S
- HDR-1100S

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation. No programming is required; once batteries are installed, the remote is ready for use.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment with cover removed, showing AAA battery slots.

3. Operating Instructions

This replacement remote control is designed to function identically to your original Humax remote. Simply point the remote towards your Humax HD Smart Digital TV Recorder and press the desired button.





Figure 2: Front view of the Azwok RM-I08U RM-I09U Remote Control.

3.1 Key Functions Overview

The remote features standard buttons for controlling your Humax device:

- **Power Button:** Turns the device on or off.
- **Numeric Keypad (0-9):** For direct channel input and other numerical selections.
- **Channel Up/Down:** Navigates through channels.
- **Volume Up/Down:** Adjusts the audio level.
- **Mute Button:** Silences the audio.
- **Navigation Pad (Up, Down, Left, Right, OK):** For menu navigation and selection.
- **Menu/Guide Buttons:** Accesses the device's main menu and program guide.
- **PVR/Record/Playback Controls:** Manages recording and playback functions (Play, Pause, Stop, Fast Forward, Rewind, Record).
- **Colored Buttons (Red, Green, Yellow, Blue):** For specific functions within menus or applications, as indicated on-screen.
- **Exit/Back:** Returns to the previous screen or exits a menu.

4. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the remote. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries promptly when the remote's responsiveness decreases. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can cause internal damage.

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure the remote is pointed directly at the Humax device and there are no obstructions.
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with fresh AAA batteries.
- **Buttons Sticking:**
  - Gently press and release the button multiple times.
  - Ensure the remote is clean and free from debris around the buttons.
- **Incorrect Functionality:**
  - Verify that your Humax model is listed in the compatible models section (Section 1).
  - If your model is not listed or your original remote differs significantly, contact customer support for assistance.

6. Specifications

Feature	Detail
Model Numbers	RM-I08U, RM-I09U
Product Dimensions	8.46 x 2.17 x 0.98 inches
Item Weight	3.92 ounces
Batteries Required	2 x AAA (not included)
Special Feature	No Programming Required
Max Supported Devices	1
Compatible Devices	Humax HD Smart Digital TV Recorders
Connectivity Technology	Infrared

7. Warranty Information

This Azwok remote control comes with a 12-month replacement warranty from the date of purchase. If the product does not function with your compatible device, returns are accepted for a refund or exchange.

8. Support

For further assistance, if your specific Humax model is not listed, or if you are unsure about the compatibility of this remote control with your device, please contact our customer support. We are available to help you confirm suitability and find the correct remote for your needs.

Please refer to your purchase documentation or the retailer's website for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQN88Z6R

More documents and user manuals: **https://manuals.plus/**