Azwok AU-RC5117-HT008

Azwok RC5117 Replacement Remote Control for Hitachi TV

User Manual

1. Introduction

This manual provides instructions for the Azwok RC5117 replacement remote control, designed for use with various Hitachi TV models. This remote control functions as a direct replacement for the original RC5117 remote, offering all primary functions without requiring any programming.

Compatible Hitachi TV Models include:

- DLED49287FHD, LED24127DVDCNTD, LED24265DVDCNT, LED40127FHDCNTD, DLED32265HDCNTD, LED32127HDCNTD, LED48SST
- 32HXT16U, 32HYJ46U, 32HYT46U, 42HBT42U, 42HE4631U, 42HXT42U, 43HB6T62U, 43HGT69U, 48HB6T62U, 48HBT62U, 48HK6T64U, 49HGT69U, 50HYT62U
- 24HYT45U, 28HYJ45U, 28HYT45U, 32HB1J46U, 32HB6T41U, 32HBJ46U, 55HB6T62U, 55HK6T64U, 55HZT66U
- 42HXT12U, 42HYT42U, 24HXT45U, 24HYJ45U, 24HYT45U

If your specific model is not listed, or if your original remote differs significantly in appearance, please contact the seller for compatibility confirmation.

2. Setup: Battery Installation

The Azwok RC5117 remote control requires two AAA batteries (not included) for operation. No programming is necessary; once batteries are installed correctly, the remote is ready for use.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.




AAA/R3/LR3
AAA/R3/LR3

CE
MADE IN CHINA



Image: Back of the remote control with the battery compartment open, illustrating correct battery insertion.

3. Operating Instructions

Point the remote control directly at your Hitachi TV. Ensure there are no obstructions between the remote and the TV's infrared receiver. Press the desired button to perform the corresponding function.



Image: Front view of the Azwok RC5117 remote control.

Key Functions:

- **Power Button ( ):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **Volume Up/Down (V+/V-):** Adjusts the sound volume.
- **Channel Up/Down (P+/P-):** Changes the TV channel.
- **Mute Button ( ):** Mutes or unmutes the TV sound.
- **Menu Button:** Accesses the TV's main menu.

- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate through menus and confirm selections.
- **Back/Exit Buttons:** Returns to the previous screen or exits the current menu.
- **Source/Input Button:** Selects input sources (HDMI, AV, etc.).
- **Colored Buttons (Red, Green, Yellow, Blue):** Used for specific functions within certain TV menus or applications.

4. Maintenance

Cleaning:

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

Battery Care:

- Replace batteries when the remote's response becomes sluggish or stops working.
- Always replace both batteries at the same time with new ones of the same type (AAA).
- Do not mix old and new batteries, or different types of batteries.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote control is not responding.	• Batteries are dead or incorrectly inserted. • Obstruction between remote and TV. • Remote is too far from the TV.	• Replace batteries with new AAA batteries, ensuring correct polarity. • Remove any objects blocking the line of sight to the TV's infrared receiver. • Move closer to the TV.
Some buttons are not working.	• Specific button malfunction. • Remote control not fully compatible with a specific TV function.	• Ensure batteries are fresh. • Verify your TV model is listed in the compatibility section. If issues persist, contact customer support.
Remote works intermittently.	• Low battery power. • Interference from other electronic devices.	• Replace batteries. • Ensure other devices are not interfering with the infrared signal.

6. Specifications

- **Product Dimensions:** 9.84 x 1.97 x 0.98 inches
- **Item Weight:** 4.1 ounces
- **Batteries Required:** 2 AAA batteries (not included)
- **Special Feature:** No Programming Required
- **Max Number of Supported Devices:** 1 (Television)
- **Compatible Devices:** Television
- **Connectivity Technology:** Infrared

- **Model Number:** AU-RC5117-HT008

7. Warranty and Support

This Azwok RC5117 replacement remote control comes with a **12-month warranty**. This warranty covers manufacturing defects and ensures replacement or refund if the product does not function as intended with compatible devices.

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact the seller directly through your purchase platform. Provide your order details and a description of the issue for prompt support.