Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok N2QAYB000936

Azwok N2QAYB000936 Remote Control User Manual

Replacement Remote Control for Panasonic TVs

1. Introduction

This manual provides instructions for the Azwok N2QAYB000936 replacement remote control. This remote is designed to function as a direct replacement for the original Panasonic N2QAYB000936 remote, offering full functionality without the need for programming.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to remove it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Ensure batteries are inserted with correct polarity. Incorrect installation may prevent the remote from functioning.





Image: Back of the remote control with the battery compartment open, illustrating where to insert the two AA batteries.

2.2 Initial Use

This replacement remote control is ready to use immediately after battery installation. No programming or pairing is required. Point the remote directly at your Panasonic TV and begin operation.

3. Operating Instructions

The Azwok N2QAYB000936 remote control features all major buttons and functions found on the original remote. Below is a general overview of common button functions:





Image: Front view of the remote control, displaying the layout of all buttons.

- **POWER**: Turns the TV on or off.
- **INPUT**: Selects the input source (e.g., HDMI 1, AV).
- **MENU** / **INFO**: Accesses the TV's main menu or displays information.
- **TV** / **AV**: Switches between TV and AV modes.
- **EXIT**: Exits the current menu or screen.
- **HOME**: Accesses the TV's home screen or smart features.
- **APPS**: Opens the applications menu.
- **GUIDE**: Displays the electronic program guide.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.
- **RETURN**: Goes back to the previous screen or menu.
- **OPTION**: Displays context-sensitive options.
- **MUTE**: Mutes or unmutes the TV audio.
- **TEXT** / **STTL/AD** / **ASPECT**: Specific function buttons for teletext, subtitles/audio description, and aspect ratio adjustment.
- **VOL +/-**: Adjusts the volume level.
- **CH ^** / **v**: Changes the TV channel.
- **Number Buttons (0-9)**: Directly selects channels or enters numerical input.
- **LAST VIEW**: Returns to the previously viewed channel.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Record)**: Controls playback of media content.

4. Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these may damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AA batteries. Do not mix old and new batteries, or different types of batteries.

5. Troubleshooting

- **Remote not responding:**
  - Ensure the batteries are installed correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Point the remote directly at the TV.
- **Specific buttons not working:**
  - Check if the button is stuck or dirty. Gently clean around the button.
  - If only a few buttons are unresponsive, it might indicate a fault with the remote.
- **TV model not listed as compatible:**
  - While this remote is designed for specific Panasonic models, if your model is not listed, contact customer support for compatibility confirmation.

6. Specifications

- **Model Number:** N2QAYB000936
- **Brand:** Azwok
- **Connectivity Technology:** Infrared
- **Power Source:** 2 x AA Batteries (not included)
- **Dimensions:** 9.06 x 1.97 x 0.98 inches
- **Item Weight:** 3.87 ounces
- **Compatible Devices:** Panasonic Televisions
- **Compatible Panasonic TV Models:**
  - TH-85X940A, TH-85X940Z
  - TH-55AS800A, TH-55AS800H, TH-55AS800Z
  - TH-58AX800A, TH-58AX800Z
  - TH-60AS800A, TH-60AS800H, TH-60AS800Z
  - TH-65AX800A, TH-65AX800Z
  - TH-65AX900A, TH-65AX900Z
  - TH85X940A, TH85X940Z
  - TH55AS800A, TH55AS800H, TH55AS800Z
  - TH58AX800A, TH58AX800Z
  - TH60AS800A, TH60AS800H, TH60AS800Z
  - TH65AX800A, TH65AX800Z
  - TH65AX900A, TH65AX900Z

7. Warranty and Support

This remote control comes with a 12-month replacement warranty. If the remote control does not function with your device, returns are accepted for refund or exchange.
If you are unsure about compatibility with your specific TV model or have any questions, please contact the seller for assistance. Providing your TV's model number will help in confirming suitability.

© 2025 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQWW6FJR

More documents and user manuals: **https://manuals.plus/**