Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AKB76038001

ZdalaMit AKB76038001 Infrared Replacement Remote Control User Manual

Model: AKB76038001

Product Overview

This manual provides instructions for the ZdalaMit AKB76038001 Infrared Replacement Remote Control, designed for various LG Soundbar models. This remote offers a direct replacement solution without requiring complex programming.





Image: Front view of the AKB76038001 Infrared Replacement Remote Control, showcasing its ergonomic black design and button layout.

Setup

Battery Installation

The AKB76038001 remote control requires two (2) 1.5V AA Alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AA Alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use without any additional programming.








Image: Side view of the AKB76038001 remote control, illustrating the sleek profile and the location of the battery compartment on the rear.

Operating Instructions

This infrared replacement remote control is designed to function identically to the original LG Soundbar remote. No programming or pairing is required. Simply point the remote towards your LG Soundbar and press the desired button.

Compatible LG Soundbar Models:

- S90QY, SP9YA, DS80QR, SP8YA, DS95QR, S75QR, S65Q, SP7, SP9YT, S95QR, WTP3, SP9A, SP8A, SPP11M-SL, SP7Y, S80QY, SP11RA, SPP11M-SR, SPQ9-SL, SPQ9-SR, S78S2-S, SPQ8-W, SPQ8-S, SPP8-W, SPP5-W, SH7Q, SP70Y, DS80QY, SPQ5H-W, SPP5B-W

Key Functions:

The remote features standard buttons for controlling your LG Soundbar. While specific button labels may vary slightly from the original, their functions are consistent.





Image: Angled view of the AKB76038001 remote control, providing a clear perspective of the button arrangement for easy identification and use.

- **Power Button ( ):** Turns the soundbar on or off.
- **Volume Up (+):** Increases the soundbar volume.
- **Volume Down (-):** Decreases the soundbar volume.
- **Mute ( ):** Mutes or unmutes the sound.
- **Function/Input Selection:** Buttons for selecting different input sources (e.g., Optical, Bluetooth, HDMI).
- **Navigation Pad:** For menu navigation (if applicable to your soundbar model).
- **Settings (⚙):** Accesses soundbar settings.
- **Sound Effect/Mode:** Cycles through various sound modes (e.g., Standard, Cinema, Music).

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** If the remote will not be used for an extended period, remove the batteries to prevent leakage, which can damage the remote's internal components.

- **Storage:** Store the remote in a cool, dry place, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry or external casing.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Replace batteries with new 1.5V AA Alkaline batteries, ensuring correct polarity (+/-).
Remote has limited range or intermittent response.	Low battery power; Obstruction between remote and soundbar; Infrared sensor on soundbar is blocked or dirty.	Replace batteries. Ensure a clear line of sight between the remote and the soundbar. Clean the infrared sensor on the soundbar. Note: This replacement remote may have a slightly different range compared to the original OEM remote. Optimal performance is typically within 10-15 feet.
Certain buttons do not work.	Remote malfunction; Soundbar model incompatibility for specific advanced functions.	Verify that your soundbar model is listed in the compatible models section. If the issue persists, contact customer support.

Specifications

- **Model:** AKB76038001
- **Brand:** ZdalaMit
- **Type:** Infrared Replacement Remote Control
- **Power Supply:** 2 x 1.5V AA Alkaline Batteries (not included)
- **Product Dimensions:** 5 x 1.5 x 0.5 inches (approximately)
- **Item Weight:** 1.41 ounces (approximately)
- **Color:** Black
- **Compatible Devices:** LG Soundbars (specific models listed in Operating Instructions)

Support

For any questions, concerns, or assistance regarding your ZdalaMit AKB76038001 Infrared Replacement Remote Control, please do not hesitate to contact our customer support team. We are committed to providing prompt and helpful service.
Please refer to your purchase documentation or the retailer's website for specific contact information.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BQZXW58D

More documents and user manuals: **https://manuals.plus/**