Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Buture Pro JR300

BuTure JR300 Cordless Vacuum Cleaner User Manual

Model: JR300 | Brand: Buture Pro

1. Important Safety Instructions

Please read all instructions carefully before using the BuTure JR300 Cordless Vacuum Cleaner. Retain this manual for future reference.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and filters in place.
- Turn off the appliance before connecting or disconnecting the motorized brush, extension wand, or charger.
- Use only the charger supplied by the manufacturer to recharge the appliance.
- Store the vacuum cleaner indoors in a dry place.

2. Product Overview

The BuTure JR300 Cordless Vacuum Cleaner is designed for efficient cleaning across various surfaces. Familiarize yourself with its components.



Figure 2.1: All components of the BuTure JR300 Cordless Vacuum Cleaner, including the main unit, extension wand, floor brush, various nozzles, wall mount, and charger.

Package Contents:

- Main Motor Unit
- Extension Wand
- Motorized Floor Brush
- Crevice Tool
- 2-in-1 Brush Tool
- Wall Mount with Screws
- Power Adapter/Charger

- User Manual

3. Setup and Assembly

Follow these steps to assemble your BuTure JR300 Cordless Vacuum Cleaner and prepare it for first use.

3.1 Battery Installation and Charging

1. Ensure the main motor unit is off.
2. Align the battery pack with the slot on the main motor unit and push until it clicks into place.
3. Connect the charger to the charging port on the main unit or the wall mount. Plug the charger into a power outlet.
4. The LED display will indicate charging status. A full charge typically takes 4-5 hours.



Figure 3.1: The BuTure JR300 main unit mounted on its wall bracket, connected to the power adapter for charging.

3.2 Assembling the Vacuum Cleaner

1. Attach the extension wand to the main motor unit by aligning the connectors and pushing until it locks.
2. Connect the motorized floor brush to the other end of the extension wand in the same manner.
3. For handheld use, attach desired accessories (crevice tool, 2-in-1 brush) directly to the main motor unit.

4. Operating Instructions

Learn how to effectively use your BuTure JR300 for various cleaning tasks.

4.1 Powering On/Off and Suction Modes

1. Press the power button on the handle to turn the vacuum cleaner on. It will start in the default suction mode.
2. Use the suction adjustment button on the LED display to cycle through the three available power modes: 17Kpa (Eco), 25Kpa (Standard), and 33Kpa (Max).
3. Press the power button again to turn the vacuum cleaner off.



Figure 4.1: The LED digital display provides real-time information on battery level, current suction mode, and alerts for tangled brush rolls or high motor temperature.

4.2 Understanding the LED Display

The 8cm LED touch screen displays crucial information:

- **Battery Indicator:** Shows remaining battery percentage.
- **Suction Indicator:** Displays the current suction power level (Eco, Standard, Max).
- **Brush Roll Tangle Alert:** Illuminates if the brush roll is obstructed or tangled.
- **Over-temperature Protection:** Warns if the motor temperature becomes too high.
- **Air Channel/Dust Sensor Blocked:** Indicates a blockage in the air path or dust sensor.

4.3 Using Attachments

The BuTure JR300 comes with various attachments for versatile cleaning:

- **Motorized Floor Brush:** Ideal for carpets and hard floors. Features LED lights to illuminate dust.
- **Crevice Tool:** Perfect for narrow gaps, corners, and edges.
- **2-in-1 Brush Tool:** Use with bristles extended for delicate surfaces like upholstery or retracted for general dusting.



Figure 4.2: The BuTure JR300 adapts to different cleaning needs, from large floor areas to intricate details on furniture and in tight spaces.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

5.1 Emptying the Dustbin

1. Ensure the vacuum cleaner is turned off.
2. Hold the main unit over a trash can.
3. Press the dustbin release button to open the bottom flap and empty the contents.
4. Close the flap securely until it clicks.



Figure 5.1: The dustbin can be emptied easily with a single touch, releasing debris directly into a trash receptacle.

5.2 Cleaning Filters

The filters should be cleaned regularly to maintain suction power. The LED display will remind you when cleaning is due.

1. Twist and pull to remove the dustbin from the main unit.
2. Remove the internal filters (HEPA filter and metal mesh filter).
3. Tap off loose dust. Rinse the filters under cold running water until the water runs clear.
4. Allow filters to air dry completely for at least 24 hours before reassembling. Do not use a dryer or heat.



Figure 5.2: The internal filters, including the HEPA filter, are crucial for maintaining air quality and vacuum performance.

5.3 Cleaning the Brush Roll

Hair and debris can tangle around the brush roll. Clean it periodically to prevent performance issues.

1. Turn off the vacuum cleaner and detach the motorized floor brush.
2. Locate the brush roll release tab/button and remove the brush roll.
3. Use scissors or a cleaning tool to cut and remove any tangled hair or fibers.
4. Reinsert the brush roll and secure it.

6. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Charge the battery fully. Ensure the battery pack is securely clicked into place.
Weak suction power	Dustbin is full, filters are clogged, or there is a blockage in the hose/brush.	Empty the dustbin. Clean or replace filters. Check for and remove any blockages.
Brush roll not spinning	Brush roll is tangled with hair/debris or obstructed.	Turn off the vacuum, remove the brush roll, and clear any obstructions.
LED display shows error (e.g., over-temperature)	Motor overheating due to prolonged use or blockage.	Turn off the vacuum and allow it to cool down for at least 30 minutes. Check for blockages.

7. Specifications

Technical details of the BuTure JR300 Cordless Vacuum Cleaner.

Feature	Specification
Model Number	JR300
Brand	Buture Pro
Power	400 Watts
Voltage	400 Volts
Suction Power	Up to 33 Kpa
Dustbin Capacity	1 Litre
Runtime	Up to 55 minutes (Eco mode)
Noise Level	68 dB
Weight	3.43 Kilograms
Special Features	Brushless Motor, Touch Screen Display
Battery Type	Lithium-ion (included)

8. Warranty and Support

BuTure Pro offers comprehensive support for your JR300 Cordless Vacuum Cleaner.

8.1 Warranty Information

The BuTure JR300 comes with a standard 2-year warranty. Customers who register their warranty with BuTure official receive an additional 1-year extension, totaling a **3-year warranty period**.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact our customer service team:

- **Email:** sales@ibuture.com
- Our customer service is available 7 days a week, 24 hours a day.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BR357KFD

More documents and user manuals: **https://manuals.plus/**