Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YUYTE YUYTE7dxqm2zggp-12

YUYTE Kids Digital LED Sport Watch Instruction Manual

Model: YUYTE7dxqm2zggp-12

Introduction

Thank you for choosing the YUYTE Kids Digital LED Sport Watch. This manual provides essential information for the proper setup, operation, and maintenance of your watch. Please read it carefully to ensure optimal performance and longevity of the product.

Product Overview

The YUYTE Kids Digital LED Sport Watch features a clear LED display and a durable plastic construction with a soft, adjustable strap. It is designed for daily wear and various outdoor activities.



Figure 1: Front view of the YUYTE Kids Digital LED Sport Watch.



Figure 2: Side view of the watch, highlighting the control button.

Setup

1. Adjusting the Watch Strap

The watch features a multi-hole design on its strap for adjustable tightness. To adjust:

1. Unbuckle the strap.
2. Place the watch on the wrist.
3. Insert the buckle pin into the desired hole that provides a comfortable and secure fit.



Figure 3: Adjustable watch strap with multiple holes.

Operating Instructions

1. Displaying the Time

The watch features a clear LED display. To view the current time, press the single button located on the side of the watch. The time will illuminate for a few seconds before turning off to conserve battery.



Figure 4: Clear LED time display.

2. Setting the Time

To set the time on your YUYTE Digital LED Sport Watch:

1. Press the side button once to display the current time.
2. While the time is displayed, press and hold the side button for approximately 3-5 seconds until the hour digits begin to flash.
3. Press the button repeatedly to advance the hour. Each press will increase the hour by one.
4. Once the correct hour is set, press and hold the button again for approximately 3-5 seconds until the minute digits begin to flash.
5. Press the button repeatedly to advance the minutes.
6. After setting the minutes, press and hold the button one last time for approximately 3-5 seconds to confirm and exit the setting mode. The display will stop flashing, and the new time will be set.

Note: The watch typically operates in a 12-hour format. Ensure you set the correct AM/PM if applicable (though this model appears to be a simple 24-hour display based on images).

Maintenance

1. Cleaning

To clean your watch, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the plastic and LED display.

2. Battery Replacement

The watch is powered by a CR2032 button cell battery. When the display becomes dim or stops working, it may be time to replace the battery.

1. Carefully remove the back cover of the watch using a small screwdriver or appropriate tool.
2. Locate the CR2032 battery.
3. Gently remove the old battery and insert a new CR2032 battery, ensuring correct polarity (+ side up).
4. Replace the back cover securely.



Figure 5: Back of the watch, indicating the battery compartment location.

Warning: Battery replacement should be performed by an adult. Keep button cell batteries out of reach of children.

Troubleshooting

- **Display is dim or not working:** The battery may be low or depleted. Replace the CR2032 battery.
- **Time is incorrect:** Re-set the time following the "Setting the Time" instructions.
- **Watch does not respond to button presses:** Ensure the battery is correctly installed and has sufficient charge. If the issue persists, contact customer support.

Specifications

Feature	Detail
Model Number	YUYTE7dxqm2zggp-12
Brand	YUYTE
Display Type	Digital LED
Material	Plastic casing, plastic strap
Battery Type	CR2032 Button Cell (integrated)
Battery Capacity	240mAh
Strap	Adjustable, multi-hole design
Dimensions (Package)	18 x 5 x 5 cm

Warranty and Support

Specific warranty information is not provided in the product details. For support or warranty inquiries, please refer to the retailer where the product was purchased or contact YUYTE customer service directly through their official channels.

© 2023 YUYTE. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BRBGC5YF

More documents and user manuals: **https://manuals.plus/**