Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok RC3902

Azwok RC3902 Replacement Remote Control User Manual

Model: RC3902

Introduction

This manual provides instructions for the Azwok RC3902 Replacement Remote Control, designed for use with various Sharp LCD TV models including LC22D12E, LC22LE22E, LC32D12E, and LC40F22E. This remote control functions as a direct replacement, offering all major buttons and functions of the original RC3902 remote.

Package Contents

- 1 x Azwok RC3902 Replacement Remote Control

Note: AAA batteries are not included and must be purchased separately.

Setup

Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA 1.5V alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Image: Back of the remote control with the battery compartment open, illustrating how to insert AAA batteries.

First Use

This Azwok RC3902 replacement remote control requires no programming. Once batteries are correctly installed, it is ready for immediate use with compatible Sharp LCD TV models.

Operating the Remote Control

Point the remote control directly at your Sharp LCD TV's infrared receiver. Ensure there are no obstructions between the remote and the TV.



Image: Front view of the remote control, displaying the layout of all buttons.

Button Functions

Button	Function
Power (Red button)	Turns the TV on or off.
Number Buttons (0-9)	Direct channel selection.

Button	Function
CH +/-	Changes TV channels up or down.
VOL +/-	Adjusts the TV volume up or down.
Mute	Mutes or unmutes the TV audio.
Source / Input	Selects the input source (e.g., HDMI, AV).
Menu	Opens the TV's main menu.
OK / Enter	Confirms selections within menus.
Navigation Arrows (Up, Down, Left, Right)	Navigates through menus and options.
Return / Back	Goes back to the previous menu or screen.
Info	Displays information about the current program or input.
EPG	Accesses the Electronic Program Guide.
Sleep	Sets the TV's sleep timer.
Colored Buttons (Red, Green, Yellow, Blue)	Functions vary depending on the TV model and current menu/application. Refer to your TV's manual for specific uses.

Maintenance

- Keep the remote control clean by wiping it with a soft, dry cloth.
- Avoid exposing the remote control to direct sunlight, high temperatures, or moisture.
- Do not drop the remote control or subject it to strong impacts.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with new AAA alkaline batteries.
- **Line of Sight:** Make sure there are no objects blocking the path between the remote control and the TV's infrared sensor.
- **Distance:** Ensure you are within the effective operating range (up to 10 meters) of the TV.
- **TV Compatibility:** Verify that your Sharp LCD TV model is listed as compatible (LC22D12E, LC22LE22E, LC32D12E, LC40F22E). If your model is not listed, the remote may not be compatible.

Specific Buttons Not Working

- Clean the remote control surface and buttons to ensure no debris is interfering with button presses.
- If only certain buttons are unresponsive, it might indicate a fault with the remote control.

Specifications

Feature	Detail
Brand	Azwok
Model Number (Manufacturer)	AU-RC3902-SP0012
Compatible Devices	Sharp LCD Televisions (LC22D12E, LC22LE22E, LC32D12E, LC40F22E)
Connectivity Technology	Infrared
Special Feature	No Programming Required
Max Number of Supported Devices	1
Button Quantity	25
Controller Type	Button Control
Maximum Range	10 Meters
Batteries Required	2 x AAA (Alkaline recommended, not included)
Item Weight	79 Grams

Warranty and Support

This Azwok RC3902 Replacement Remote Control comes with a**12-month warranty** from the date of purchase.
If you encounter any issues or have questions regarding the compatibility or functionality of this remote control, please contact Azwok customer support. Provide your product model number (RC3902) and a detailed description of the issue for prompt assistance.
For returns or exchanges due to non-functionality with your device, please refer to the retailer's return policy.

© 2026 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BRBJT538

More documents and user manuals: **https://manuals.plus/**