Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YOOHOO 109

YOOHOO 12.5-inch Portable DVD Player

Model: 109

Introduction

This manual provides essential information for the safe and efficient operation of your YOOHOO 12.5-inch Portable DVD Player. Please read these instructions carefully before using the device and retain them for future reference.

Key Features

- **10.1-inch HD Swivel Screen:** The high-definition screen (1024 x 600 pixels) can swivel 270 degrees and flip 180 degrees, allowing for optimal viewing angles. It can also be rotated to function like a tablet and mounted for car use.
- **Region-Free Playback:** Supports a wide range of disc formats including CD, DVD, CD-R(+RW), DVD-R (+R), DVD-RW (+RW), CVD(SVCD), VCD(DVCD), HDCD, DTSCD. (Note: Blu-ray discs are not supported).
- **Extensive Media Compatibility:** Plays media from USB drives and SD cards up to 32GB. Supported media formats include MP3, WMA, MPG, VOB, AVI, DIVX, MPEG, JPEG, and TXT (AVI resolution under 720x576).
- **Dual Stereo Speakers:** Integrated dual speakers deliver clear and crisp audio. A 3.5mm earphone jack is available for private listening or connecting to external stereo equipment.
- **Last Memory Function:** The player automatically resumes playback from the last stopped position, ensuring a seamless viewing experience.
- **TV Synchronization:** Connect the DVD player to a television or projector using the included AV cable to enjoy content on a larger screen.
- **Rechargeable Battery:** Equipped with a long-life lithium battery providing approximately 3-4 hours of playback on a full charge.

Setup

1. **Initial Charging:** Before first use, fully charge the device using the provided power adapter. The charging indicator light will turn green when fully charged.

2. **Power On/Off:** Locate the ON/OFF switch on the device. Slide it to the 'ON' position to power on the player. Slide to 'OFF' to power down.
3. **Screen Adjustment:** Adjust the screen to your preferred viewing angle. The screen can swivel 270 degrees and flip 180 degrees.

Operating Instructions

Disc Playback

1. Open the disc cover.
2. Carefully place a compatible DVD or CD onto the spindle, ensuring it is seated correctly. Do not touch the disc lens.
3. Close the disc cover. The player will automatically begin reading the disc.
4. Use the controls on the player or the remote control to navigate menus, play, pause, stop, and adjust volume.

USB/SD Card Playback

1. Insert a USB drive into the USB port or an SD card into the SD card slot.
2. Press the 'MODE' button on the player or remote to select 'USB' or 'SD' mode.
3. Navigate through your files using the directional buttons and 'OK' button.
4. Select the desired media file to begin playback.

Connecting to a Television

1. Ensure both the portable DVD player and the television are powered off.
2. Connect one end of the included AV cable to the 'AV OUT' port on the DVD player.
3. Connect the other end of the AV cable to the corresponding 'AV IN' ports on your television (typically yellow for video, red/white for audio).
4. Power on both devices and select the correct AV input source on your television.



Image: Portable DVD player connected to a television, displaying content on a larger screen.

Using the Remote Control

Point the remote control towards the infrared receiver on the right side of the DVD player for optimal response. Insert 2 AAA batteries (not included) into the remote control.



Image: The remote control, car charger, DC adapter, and RCA cable included with the player.

Special Functions

- **A-B Repeat:** Press the A-B button once to mark the start point (A) and press it again to mark the end point (B). The player will repeatedly play the selected section.
- **Slow Motion:** Allows playback at a reduced speed.
- **Zoom:** Magnifies a portion of the screen during playback.
- **Screen Rotation:** The screen can be physically rotated 270 degrees and flipped 180 degrees for various viewing orientations.



Image: Demonstrates the screen's ability to swivel 270 degrees and flip 180 degrees for flexible viewing.

Media Compatibility

Category	Supported Formats
Disc Formats	CD, DVD, CD-R(+RW), DVD-R (+R), DVD-RW (+RW), CVD(SVCD), VCD(DVCD), HDCD, DTSCD (Region 1-6, excluding Blu-ray)
Video File Formats	MPG, VOB, AVI, DIVX, MPEG, FLV, RMVB (AVI/RMVB under 720x576 resolution)
Audio File Formats	MP3, WMA, WAV, EAC3
Image File Formats	JPEG (Support Resolution: 8176*4080)

Category	Supported Formats
Text File Formats	TXT
External Storage	USB Disk, SD/MMC/MS Card (up to 32GB)



Image: Detailed view of the player's ports (DC, ON/OFF, AV IN/OUT, Earphone, SD Card, USB) and a summary of supported file and disc formats.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the player's surface. Do not use liquid cleaners or abrasive materials.
- **Disc Lens Care:** Avoid touching the disc lens directly. Use a specialized DVD lens cleaner if necessary.
- **Battery Care:** To maintain battery health, ensure the player is charged at least once every 3 months, even if not in use.

- **Storage:** Store the player in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **No Power:** Ensure the power adapter is securely connected and the ON/OFF switch is in the 'ON' position. Check if the battery is charged.
- **Disc Not Playing:** Verify the disc is clean, free of scratches, and inserted correctly. Ensure it is a supported format (Blu-ray discs are not supported).
- **No Sound/Low Volume:** Check the volume level on the player and remote. If using headphones, ensure they are properly plugged in. If connected to a TV, check the TV's volume and input settings.
- **Remote Control Not Working:** Ensure batteries are correctly inserted and not depleted. Point the remote directly at the infrared receiver on the right side of the player.
- **Picture Quality Issues:** Ensure the disc or media file is of good quality. If connected to a TV, check the AV cable connection.

Specifications

Feature	Detail
Brand	YOOHOO
Model Number	109
Screen Size	10.1 inches
Display Type	LCD
Display Resolution	1024 x 600 pixels
Connectivity	Auxiliary (AV In/Out), USB, SD Card, Earphone Jack
Compatible Devices	Television, Headphones
Item Weight	1.41 kilograms
UPC	757611676796

Package Contents

The following items are included in your package:

- 1 x YOOHOO Portable DVD Player
- 1 x Power Adapter
- 1 x Car Charger
- 1 x Remote Control (Batteries not included)
- 1 x RCA/AV Cable
- 1 x User Manual

Important Notes

- A protective film may be present on the screen. This film can be scratched, but it does not affect the screen itself.
- Always ensure the player has at least one charge within a 3-month period to maintain battery health.
- The player supports most region-free discs, but Blu-ray discs are not compatible.
- When using the remote control, aim it towards the infrared receiver located on the right side of the player.
- The charging indicator light will turn green when the player is fully charged.

Warranty and Support

This product comes with a 1-year warranty. For any technical issues or inquiries, please contact our customer support team. We offer 24/7 professional customer service to assist you.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BRC63765

More documents and user manuals: **https://manuals.plus/**