Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY CV-AKB32606601-101-705-SH

ALLIMITY Replacement Remote Control User Manual

For LG DVD/VCR Recorders

1. Introduction

This document provides comprehensive instructions for the ALLIMITY replacement remote control, designed for use with various LG DVD and VCR recorder models. This remote control functions as a direct replacement and does not require any programming or setup. Simply insert batteries to begin operation.

Compatible LG Models include:

- RC897T
- RC286HM
- RC797T
- RC700N
- RC397HM
- RC397H-M
- RC297H
- RC286H-M
- 6711R1N203A
- RC286H
- RC297H-M
- RC397H
- AKB32606601
- AKB36097101
- AKB31238705

2. Setup

2.1 Battery Installation

The remote control requires two (2) 1.5V AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.

2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Figure 1: Battery compartment on the back of the remote control.

2.2 Initial Use

This ALLIMITY replacement remote control is pre-programmed and ready for immediate use with compatible LG DVD/VCR recorders. No additional setup or programming is required after battery installation. Point the remote control directly at your device and press the desired function button.

3. Operating Instructions

The remote control features a standard layout for easy navigation and control of your LG DVD/VCR recorder. Below is a general overview of key button functions:



Figure 2: Front view of the ALLIMITY replacement remote control.

- **POWER (DVD/VCR):** Turns the DVD/VCR unit on or off.
- **TV POWER:** Turns the television on or off.
- **INPUT:** Selects the input source on the television.
- **Number Buttons (0-9):** Used for direct channel selection or entering numerical data.
- **VOL (+/-):** Adjusts the volume level.
- **CH (+/-):** Changes channels.
- **PLAY (►):** Starts playback of a disc or tape.

- **PAUSE/STEP ( ):** Pauses playback or advances frame by frame.
- **STOP (■):** Stops playback.
- **REWIND (◄◄):** Rewinds disc or tape.
- **FAST FORWARD (►►):** Fast forwards disc or tape.
- **SKIP (◄◄| / |►►):**Skips tracks or chapters.
- **HOME:** Accesses the main menu or home screen.
- **Navigation Buttons (Up, Down, Left, Right, ENTER):** Used to navigate menus and confirm selections.
- **DISC MENU/LIST:** Accesses the disc menu or a list of available content.
- **RETURN:** Returns to the previous screen or menu.
- **REC (●):** Initiates recording.
- **AUDIO:** Changes audio tracks or languages.
- **SUBTITLE:** Toggles or selects subtitle options.
- **ZOOM:** Adjusts the screen zoom level.
- **DISPLAY:** Shows on-screen information.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops functioning. Always replace both batteries simultaneously with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's finish or internal components.

5. Troubleshooting

- **Remote control is not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote control and the LG DVD/VCR recorder's infrared sensor.
  - Ensure you are within the effective operating range and pointing the remote directly at the device.
- **Certain buttons do not work:**
  - Verify that the remote control is compatible with your specific LG DVD/VCR model (refer to the compatibility list in Section 1).
  - Clean the remote control surface, as dirt or debris might be obstructing button presses.

6. Specifications

Product Dimensions	6.5 x 1.38 x 0.72 inches

Item Weight	2.5 ounces
Power Supply	2 x 1.5V AAA batteries (not included)
Connectivity Technology	Infrared
Compatible Devices	LG DVD Recorders, LG VCR Recorders
Model Number	CV-AKB32606601-101-705-SH

7. Support

For any questions or assistance regarding your ALLIMITY replacement remote control, please contact the seller or manufacturer directly. Providing feedback or inquiries before leaving reviews can help resolve issues efficiently.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BRCMJ57N

More documents and user manuals: **https://manuals.plus/**