Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok CT-8541

Azwok CT-8541 Replacement Remote Control for Toshiba TVs User Manual

Model: CT-8541

1. Introduction

This manual provides instructions for the Azwok CT-8541 replacement remote control, designed for various Toshiba TV models. This remote control offers the primary functions found on the original Toshiba CT-8541 remote, providing a direct replacement solution without the need for complex programming.

Key Features:

- Direct replacement for Toshiba CT-8541 remote.
- No programming required; ready to use after battery installation.
- Compatible with a wide range of Toshiba TV models.



Figure 1: Front view of the Azwok CT-8541 Replacement Remote Control.

2. Setup

2.1 Battery Installation

The Azwok CT-8541 remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use with compatible Toshiba TVs. No additional programming is required.


M-4 AAA
1.5V



Figure 2: Battery compartment with two AAA batteries installed.

3. Operating Instructions

The Azwok CT-8541 remote control functions identically to the original Toshiba CT-8541 remote. Point the remote directly at your Toshiba TV's infrared receiver for optimal performance.

3.1 Basic Functions

- **Power Button (●):** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down (+/-):** Adjusts the TV volume.
- **Channel Up/Down (P+/P-):** Changes TV channels sequentially.
- **Mute Button:** Mutes or unmutes the TV audio.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Back Button:** Returns to the previous screen or menu.
- **Exit Button:** Exits the current menu or application.
- **Guide Button:** Accesses the electronic program guide (if supported by your TV).
- **Netflix Button:** Direct access to the Netflix application (if supported by your TV).

3.2 Compatible TV Models

This remote control is compatible with numerous Toshiba TV models, including but not limited to:

- 24D2863DB, 24D3863DB, 24L2863DB, 24W2863DB, 24W3863DB
- 28W2863DB
- 32D3862DB, 32W3864DB, 32L2863DB, 32L3863DB, 32D2863DB, 32W2863DB, 32D3863DB, 32W3863DB
- 39L2863DB, 39L3863DB
- 40L2863DB, 40L3863DB
- 43U2963DB, 43U6863DB, 43V6863DB, 43L2863DB, 43L3863DB
- 48L2863DB
- 49U2963DB, 49U6863DB, 49V6863DB, 49L2863DB, 49L3863DB
- 50U2963DB, 50U6863DB
- 55U2963DB, 55U5863DB, 55U6863DB, 55V6863DB
- 65U2963DB, 65U6863DB, 65V6863DB
- *For a complete list or to confirm compatibility, please refer to the product listing or contact support.*

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both AAA batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly installed batteries. Obstruction between remote and TV. Remote out of range.	Replace batteries with new AAA batteries, ensuring correct polarity. Remove any objects blocking the signal path. Ensure you are within 10 meters (33 feet) of the TV.
Some buttons not working	Dirt or debris under buttons. Remote malfunction.	Clean the remote surface. If the issue persists, the remote may be defective. Contact customer support.
Remote works intermittently	Low battery power. Interference.	Replace batteries. Minimize sources of infrared interference (e.g., direct sunlight, other IR devices).

6. Specifications

- **Model Name:** CT-8541
- **Manufacturer Part Number:** AU-CT-8541-TB011
- **Brand:** Azwok
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Toshiba Televisions
- **Power Source:** 2 x AAA Batteries (not included)
- **Maximum Range:** 10 meters (approximately 33 feet)
- **Item Weight:** 89 grams
- **Special Feature:** No Programming Required

7. Warranty and Support

7.1 Warranty Information

This Azwok CT-8541 replacement remote control comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

If you encounter any issues with your remote control, or if your specific Toshiba TV model is not listed in the compatibility section, please contact Azwok customer support for assistance. We are committed to helping you find the correct solution.
For support, please refer to the contact information provided with your purchase or visit the official Azwok support website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BRDBBXWN

More documents and user manuals: **https://manuals.plus/**