Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DELTACO GAMING GAM-139

Deltaco GAM-139 Gaming Controller User Manual

Model: GAM-139

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Deltaco GAM-139 Gaming Controller. Designed for versatility, this black USB gamepad offers analogue control and is compatible with Android, PC, PlayStation, Xbox, and iOS devices. Please read this manual carefully to ensure optimal performance and longevity of your device.

Product Overview



A black gaming controller with orange accents, featuring a D-pad on the left, two analog sticks, a central touchpad, and illuminated action buttons on the right. The controller's ergonomic design includes textured grips for comfortable handling.

The Deltaco GAM-139 is a feature-rich gaming controller designed for a wide range of platforms. Key features include:

- **Wireless Connectivity:** Enjoy freedom of movement with reliable wireless connection.
- **Integrated Touchpad:** Provides additional input options for compatible games and applications.
- **Analogue Sticks and Triggers:** For precise control in various gaming scenarios.
- **Multi-platform Compatibility:** Supports Android, PC, PlayStation, Xbox, and iOS.

Setup Guide

Connecting to Your Device

1. **For Wired Connection (PC/Console):**

   Connect the USB cable from the controller to an available USB port on your PC or console. The controller should be automatically recognized by most systems. Drivers may install automatically.

2. **For Wireless Connection (Bluetooth Pairing):**

   Ensure your device (Android, PC with Bluetooth, PlayStation, Xbox, iOS) has Bluetooth enabled.

   On the Deltaco GAM-139 controller, press and hold the **SHARE** button and the **PS** button simultaneously until the light bar starts flashing rapidly. This indicates pairing mode.

   On your device, go to Bluetooth settings and search for new devices. Select "Deltaco GAM-139" or a similar name from the list of available devices to complete the pairing process. The light bar will turn solid when connected.

Initial Setup and Calibration

After connecting, it is recommended to check your device's controller settings to ensure all buttons and analog sticks are registering correctly. Some games or platforms may require specific controller configurations.

Operating Instructions

Button Layout and Functions

- **D-Pad (Directional Pad):** Located on the left, used for precise directional input.
- **Left and Right Analog Sticks:** For 360-degree movement and camera control. Pressing them down often acts as L3/R3 buttons.
- **Action Buttons (Triangle, Circle, Cross, Square):** Located on the right, used for primary in-game actions.
- **Shoulder Buttons (L1, R1) and Triggers (L2, R2):** Located on the top, used for various actions like aiming, shooting, or menu navigation.
- **Touchpad:** The rectangular area in the center, supports touch input and can be clicked as a button.
- **SHARE Button:** Used for sharing gameplay content (functionality varies by platform).
- **OPTIONS Button:** Typically used to access in-game menus or pause the game.
- **PS Button (Home Button):** Used to turn on the controller, access system menus, or return to the home screen.

Touchpad Usage

The integrated touchpad can be used for navigation in compatible games and system interfaces. It supports swiping gestures and can be pressed down to act as an additional button. Specific functionality may vary depending on the game or operating system.

Battery and Charging

The controller features an internal rechargeable battery. Connect the controller to a USB power source (e.g., console, PC, USB wall adapter) using the provided USB cable to charge. The light bar will indicate charging status and turn off when fully charged.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe down the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the controller frequently. Charge it regularly, even if not in constant use.
- **Avoid Drops:** Protect the controller from physical impact, as drops can damage internal components.

Troubleshooting

Problem	Solution
Controller not connecting wirelessly.	Ensure Bluetooth is enabled on your device. Make sure the controller is in pairing mode (flashing light bar). Try forgetting the device on your system and re-pairing. Ensure the controller is charged.

Problem	Solution
Buttons or analog sticks are unresponsive.	Check for physical obstructions or debris. Restart the controller and the connected device. Try connecting the controller via USB to see if the issue persists.
Input lag or delayed response.	Ensure you are within range of your device for wireless connection. Reduce interference from other wireless devices. Try a wired connection to rule out wireless issues.
Controller not charging.	Verify the USB cable is securely connected to both the controller and the power source. Try a different USB port or charging cable. Ensure the power source is active.

Technical Specifications

Brand	DELTACO GAMING
Model	GAM-139
Connectivity	USB (Wired), Wireless (Bluetooth)
Compatibility	Android, PC, PlayStation, Xbox, iOS
Features	Touchpad, Analogue Sticks, Vibration Feedback (where supported)
Package Dimensions	27 x 14 x 9 cm
Package Weight	15 kg (Note: This weight seems unusually high for a controller package and might be a data entry error. Please verify with product packaging.)
ASIN	B0BRQ2PJ8X
Manufacturer Reference	GAM-139

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official DELTACO GAMING website. You may also contact your retailer for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BRQ2PJ8X

More documents and user manuals: **https://manuals.plus/**