TRAKK B0BRYKKB8P

TRAKK Foot Spa Massager User Manual

Model: B0BRYKKB8P

Important Safety Information

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Avoid using strong chemical cleaners or solvents such as benzene, harsh detergents, or abrasives.
- Do not submerge the electrical components in water.
- Unplug the device when not in use and before cleaning.
- Always ensure the basin is dry before using the massager again.
- Do not use if you have any medical conditions that could be affected by heat or vibration.
- Consult a doctor before use if you are pregnant or have any health concerns.

Product Overview

The TRAKK Foot Spa Massager is designed to provide a relaxing and revitalizing foot massage experience with features like vibration, bubbles, and heating.



Figure 1: Top-down view of the TRAKK Foot Spa Massager, highlighting the blue basin and central control knob.



Figure 2: The TRAKK Foot Spa Massager shown within its retail packaging, illustrating key features and included soothing salts.

Setup

1. Place the foot spa on a flat, stable surface.
2. Ensure the power cord is easily accessible and not obstructed.
3. Fill the basin with warm water up to the indicated fill line. Do not overfill.
4. Add any desired foot spa salts or essential oils (ensure they are compatible with foot spa devices).
5. Plug the power cord into a standard electrical outlet.

Operating Instructions

The TRAKK Foot Spa features toe-touch controls for easy activation.

1. Once filled and plugged in, gently place your feet into the basin.

2. Use your toe to press the control button to activate the soothing vibration.
3. The foot spa is designed to maintain the temperature of the water placed into the basin for an estimated 10 minutes of relaxation.
4. Utilize the massage nodes and pinpoint massage attachment for a full foot massage experience.
5. To turn off the unit, press the control button again or unplug from the outlet.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene.

1. **After Each Use:** Unplug the unit and carefully empty the water from the basin.
2. Rinse the basin with clean water.
3. Wipe down the interior and exterior surfaces with a soft, damp cloth.
4. Do not use abrasive cleaners or harsh chemicals.
5. Allow the unit to air dry completely before storing.
6. Store in a cool, dry place away from direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; Power outlet issue; Unit malfunction.	Ensure the power cord is securely plugged into a working outlet. Try a different outlet. If problem persists, contact customer support.
Vibration is weak or absent.	Insufficient water level; Unit malfunction.	Ensure water level is at the recommended fill line. If problem persists, contact customer support.
Water does not stay warm.	Unit is designed to maintain initial water temperature for a limited time; Malfunction.	The unit maintains initial water temperature for approximately 10 minutes. It does not actively heat cold water. If it fails to maintain temperature for this duration, contact customer support.

Specifications

Brand: TRAKK

Model: B0BRYKKB8P

UPC/GTIN: 194587627139

Use For: Feet

Power Source: Corded Electric

Material: Plastic

Color: Blue

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact TRAKK customer service directly. Specific warranty details may vary by region and retailer.

Please note: Information regarding specific warranty terms was not available at the time of this manual's creation.

© 2024 TRAKK. All rights reserved.
For more information, visit TRAKK Product Page

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question