RIDGID R4031S

RIDGID R4031S 7-Inch Wet Tile Saw Instruction Manual

Model: R4031S

Introduction

This manual provides essential information for the safe operation, setup, maintenance, and troubleshooting of your RIDGID R4031S 7-inch wet tile saw. Please read and understand all instructions before operating the tool. Keep this manual for future reference.


RIDGID

Figure 1: RIDGID R4031S 7-inch wet tile saw assembled on its stand.

Safety Information

Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury. This section outlines general safety guidelines applicable to power tools and specific warnings for wet tile saws.

General Power Tool Safety

- **Work Area Safety:** Keep the work area clean and well-lit. Cluttered or dark areas invite accidents. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- **Electrical Safety:** Avoid body contact with grounded surfaces. Do not expose power tools to rain or wet conditions. Never abuse the cord. Keep the cord away from heat, oil, sharp edges, or moving parts.
- **Personal Safety:** Always wear eye protection. Use hearing protection when operating the saw. Dress properly; avoid loose clothing or jewelry. Do not overreach. Stay alert and use common sense.
- **Tool Use and Care:** Do not force the tool. Use the correct tool for your application. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools.

Wet Tile Saw Specific Safety

- **Water and Electricity:** Ensure all electrical connections are dry and protected from water spray. Use a Ground Fault Circuit Interrupter (GFCI) with this tool.
- **Blade Safety:** Always use the correct type and size of blade for the material being cut. Ensure the blade guard is in place and functioning correctly. Never attempt to cut without water flowing to the blade.
- **Material Handling:** Secure the workpiece firmly. Never hold small pieces by hand while cutting. Allow the blade to reach full speed before beginning a cut.

Package Contents

Verify that all items listed below are present in your package. If any parts are missing or damaged, do not operate the tool. Contact customer service for assistance.

- RIDGID R4031S 7-inch Wet Tile Saw
- Folding Stand
- 7-inch Diamond Blade
- Operator's Manual
- Water Pump
- Miter Guide
- Rip Fence

Setup

Follow these steps to assemble and prepare your wet tile saw for operation.

1. Stand Assembly

1. Unfold the stand legs until they lock into position. Ensure all locking mechanisms are securely engaged.
2. Place the saw's water tray onto the stand, aligning the mounting points.
3. Secure the saw to the stand using the provided fasteners.

2. Blade Installation (if not pre-installed)

1. **Disconnect power:** Ensure the saw is unplugged from the power source.

2. **Remove blade guard:** Loosen the fasteners and carefully lift the blade guard.
3. **Install blade:** Place the 7-inch diamond blade onto the arbor with the cutting direction arrows on the blade matching the rotation direction of the saw.
4. **Secure blade:** Reinstall the blade washer and arbor nut, tightening securely.
5. **Reattach guard:** Replace the blade guard and tighten its fasteners.

3. Water System Setup

1. Fill the water tray with clean water until it reaches the recommended level, typically indicated by a fill line.
2. Place the water pump into the water tray, ensuring it is fully submerged.
3. Connect the pump's hose to the saw's water nozzle inlet.
4. Adjust the water nozzles to direct water flow onto the blade.

4. Laser Guide Adjustment

The laser guide assists in aligning cuts. To adjust:

1. Plug in the saw and turn on the laser (if it has a separate switch).
2. Make a test cut on a scrap piece of tile.
3. Adjust the laser line using the adjustment screws until it aligns precisely with the blade's cutting path.
4. Unplug the saw before making any further adjustments to the saw itself.

Operating Instructions

Always wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and gloves, before operating the saw.

1. Preparing for a Cut

- Ensure the water tray is filled and the pump is submerged and connected.
- Plug the saw into a GFCI-protected outlet.
- Position the tile on the cutting table. Use the rip fence for straight cuts or the miter guide for angled cuts.
- Adjust the rip fence or miter guide to the desired measurement.

2. Making a Cut

1. Turn on the saw. Allow the blade to reach full operating speed.
2. Ensure water is flowing to the blade.
3. Gently push the tile through the blade. Maintain a steady, even pressure. Do not force the cut.
4. Once the cut is complete, turn off the saw and wait for the blade to stop rotating before removing the tile.

3. Special Cuts

- **Miter Cuts:** Adjust the miter guide to the desired angle. Ensure the tile is firmly against the guide.
- **Plunge Cuts:** For internal cuts, consult the full operator's manual for specific instructions and safety precautions.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your tool. Always disconnect the saw from the power source before performing any maintenance.

1. Cleaning

- **After Each Use:** Drain the water tray and clean out any tile slurry. Rinse the tray, pump, and water nozzles thoroughly.

- **Saw Body:** Wipe down the saw body with a damp cloth. Do not use harsh chemicals or abrasive cleaners.

2. Blade Inspection and Replacement

- Regularly inspect the diamond blade for wear, cracks, or damage. A dull blade will result in slow cutting and excessive chipping.
- Replace the blade when it shows signs of significant wear or damage. Refer to the "Blade Installation" section for replacement steps.

3. Water Pump Maintenance

- Clean the water pump filter regularly to prevent clogging from tile debris.
- Ensure the pump is free of obstructions to maintain proper water flow.

Troubleshooting

This section addresses common issues you might encounter with your RIDGID R4031S wet tile saw.

Problem	Possible Cause	Solution
Saw does not start	No power; GFCI tripped; Faulty switch	Check power connection; Reset GFCI; Contact service if switch is faulty.
Poor cut quality (chipping, slow cutting)	Dull or incorrect blade; Insufficient water flow; Forcing the cut	Replace blade; Check water pump and nozzles; Reduce feed pressure.
Insufficient water flow to blade	Clogged pump filter; Kinked hose; Low water level	Clean pump filter; Straighten hose; Refill water tray.
Laser guide not visible or misaligned	Laser off; Dirty lens; Misalignment	Turn on laser; Clean lens; Adjust laser alignment (refer to Setup section).

For issues not listed here, or if solutions do not resolve the problem, contact RIDGID customer support.

Specifications

Feature	Detail
Brand	RIDGID
Model Number	R4031S
Power Source	Corded Electric
Voltage	120 Volts (DC)
Wattage	1307 watts
Blade Diameter	7 Inches
Blade Material	High Speed Steel (typically diamond-tipped for tile)
Speed	5700 RPM
Surface Recommendation	Tile
Product Dimensions (L x W x H)	34.75" x 23" x 12.5"

Feature	Detail
Color	Orange
Handle Material	Metal Alloy or High-Strength Plastic
UPC	715450422691

Warranty and Support

Your RIDGID R4031S wet tile saw is backed by the RIDGID Industry Leading Lifetime Service Agreement. This agreement covers FREE Parts and FREE Service for the life of the tool.
For detailed warranty information, service requests, or technical support, please visit the official RIDGID website or contact their customer service department. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question