Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BOBOPAI 4037258538--64809399

BOBOPAI E27 Rechargeable LED Bulb User Manual

Model: 4037258538--64809399

Introduction

This manual provides instructions for the BOBOPAI E27 Rechargeable LED Bulb. This bulb is designed for versatile lighting without the need for a direct power connection, featuring an integrated 2600mAh battery, remote control, and touch control. It emits a 3000K warm white light, suitable for various indoor and outdoor applications.

Product Features

- **Rechargeable Design:** Integrated 2600mAh battery for cordless operation.
- **USB-C Charging:** Convenient charging via USB-C port.
- **Dual Control:** Operate with the included remote control or via the touch button on the bulb.
- **Dimmable:** Adjustable brightness from 10% to 100%.
- **Timer Function:** Remote control offers 15, 30, and 60-minute timer settings.
- **Memory Function:** Retains the last brightness setting.
- **Portable:** Includes a plastic hook for hanging in various locations.
- **Standard Base:** E27/E26 screw base for compatibility with most fixtures (note: base does not conduct electricity).
- **Light Output:** 7W LED, up to 700 lumens, 3000K Warm White.

Package Contents

- BOBOPAI E27 Rechargeable LED Bulb (1 unit)
- Remote Control (1 unit)
- USB-C Charging Cable (1 unit)
- Telescopic Hook (1 unit)



Image: Contents of the BOBOPAI E27 Rechargeable LED Bulb package, showing the bulb, remote, USB-C cable, and hanging hook.

Setup

1. **Initial Charge:** Before first use, fully charge the bulb using the provided USB-C cable. Connect the cable to the bulb's USB-C port and a 5V/2A charger (not included). The indicator light will be red during charging and turn blue when fully charged. Avoid fast chargers.
2. **Remote Control:** Ensure the remote control has a working battery. Point the remote towards the bulb for operation.
3. **Installation:**
    - **In a Fixture:** Screw the bulb into any standard E27 or E26 lamp holder. Note that the lamp holder will not power the bulb; it operates solely on its internal battery.
    - **Hanging Use:** Attach the telescopic hook to the top of the bulb for hanging in closets, garages, tents, or other areas without power outlets.



Image: The LED bulb connected to a USB-C cable for charging, showing the charging indicator light and dimensions.



Image: The rechargeable LED bulb with its detachable hook base, demonstrating how it can be hung for use.

Operating Instructions

Remote Control Operation

The remote control allows for convenient operation from a distance.

- **ON/OFF:** Press the **ON** button to turn the bulb on, and the**OFF** button to turn it off.
- **Brightness Adjustment:** Use the brightness buttons (**+** / **-**) to increase or decrease the light intensity. The bulb supports 10% to 100% dimming.
- **Timer Settings:** Press the 15min, 30min, or 60min buttons to set the bulb to automatically turn off after the selected duration.



Image: The remote control for the LED bulb, illustrating its functions for power, brightness adjustment, and timer settings.

Touch Control Operation

The bulb also features a touch button for direct control.

- **Power ON/OFF:** Short press the touch button to turn the bulb on or off.
- **Brightness Adjustment:** Long press the touch button to cycle through brightness levels. Release at the desired brightness.

Charging and Battery Life

The bulb is equipped with a 2600mAh lithium-ion battery.

- **Charging Time:** Approximately 3 to 5 hours for a full charge using a 5V/2A charger.
- **Battery Indicator:** Red light indicates charging; blue light indicates fully charged.
- **Run Time:** Provides 8 to 30 hours of illumination, depending on the selected brightness level. For example, 100% brightness offers 7-8 hours, while 10% brightness can last up to 24 hours.

- **Important:** Only use the integrated special battery. Do not attempt to replace the battery with an inappropriate type, as this may damage the bulb.

Maintenance

- **Cleaning:** Wipe the bulb with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store in a cool, dry place when not in use for extended periods.
- **Water Exposure:** While suitable for outdoor use, protect the bulb from direct heavy rain or prolonged water immersion.
- **Charging Cable:** Use the provided USB-C charging cable. Avoid using fast charging cables or adapters not rated for 5V/2A, as this can damage the battery.

Troubleshooting

Problem	Possible Cause	Solution
Bulb does not turn on.	Battery is depleted.	Charge the bulb fully using the USB-C cable.
Remote control not working.	Remote battery is dead or remote is too far.	Replace remote battery. Ensure remote is within range and pointed towards the bulb.
Bulb not charging.	Faulty cable or charger.	Try a different USB-C cable or a 5V/2A charger. Ensure connections are secure.
Short battery life.	High brightness setting or incomplete charging.	Reduce brightness for longer run time. Ensure bulb is fully charged (blue indicator light).

Specifications

Model Number	4037258538--64809399
Brand	BOBOPAI
Light Type	LED
Color Temperature	3000 Kelvin (Warm White)
Luminous Flux	Up to 700 Lumens
Wattage	7 Watts
Incandescent Equivalent	40 Watts
Bulb Base	E27 / E26
Bulb Shape Size	A21
Battery Type	1 Lithium-ion (included)
Battery Capacity	2600 mAh
Charging Port	USB-C

Input Voltage	5 Volts DC
Control Method	Remote Control, Touch Control
Special Features	Dimmable, Timer, Rechargeable, Durable
Product Dimensions	6.68 x 6.68 x 13.59 cm; 70 grams
CRI	95.00
Beam Angle	270 Degrees
Lifespan	10 Years (Light Source)
Energy Label	F

Warranty and Support

- **Manufacturer Warranty:** Free replacement within one year in case of manufacturing defects.
- **Return Policy:** 30-day refund/replacement policy.
- For support or warranty claims, please contact your retailer or the manufacturer directly.

Important Safety Information

- This product is designed for use with its internal battery only. The E27/E26 screw base does not conduct electricity and is for mounting purposes only.
- Do not expose the bulb to extreme temperatures or direct flame.
- Keep out of reach of children.
- Do not disassemble or modify the bulb.
- Dispose of the product according to local regulations for electronic waste.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BS3NFZNY

More documents and user manuals: **https://manuals.plus/**