WINGBO WBFM-KY11-SP-FBA

WINGBO 15.7" Modern 3-Light Flush Mount Ceiling Light Fixture Instruction Manual

Model: WBFM-KY11-SP-FBA

Product Overview

The WINGBO 15.7" Modern 3-Light Flush Mount Ceiling Light Fixture is designed to provide soft, bright illumination for various indoor spaces. It features a metal frame with a fabric and acrylic double drum shade, creating an elegant and warm ambiance. The acrylic shade diffuses light to prevent flickering and harsh glare, ensuring eye comfort.
This fixture is compatible with three E26 base bulbs (maximum 40W each, bulbs not included) and supports incandescent, halogen, LED, and CFL bulb types. Its versatile design makes it suitable for bedrooms, living rooms, dining rooms, hallways, and entryways.



Image: WINGBO 15.7" Modern 3-Light Flush Mount Ceiling Light Fixture in Brown.

Safety Information

- Always turn off the main power supply at the circuit breaker before installation, maintenance, or bulb replacement.
- Ensure all electrical connections are secure and comply with local electrical codes. If unsure, consult a qualified electrician.
- Do not exceed the maximum wattage of 40W per bulb.
- This fixture is designed for indoor use only and is not water-resistant.
- Handle the acrylic shade and bulbs with care to prevent damage.

Package Contents

Verify that all components are present and undamaged before beginning installation.

- 1 x Light Fixture (Metal Frame, Fabric & Acrylic Double Drum Shade)

- Mounting Hardware (Screws, Wire Nuts, etc.)
- Instruction Manual

Note: Bulbs are NOT included and must be purchased separately.

Setup and Installation

Installation of this fixture is designed to be straightforward. It is recommended to have two people for installation for safety and ease.

1. **Turn Off Power:** Before starting, ensure the power to the junction box is turned off at the circuit breaker.
2. **Prepare Mounting Plate:** Attach the mounting plate to the junction box using the provided screws.
3. **Make Electrical Connections:** Connect the fixture's wires to the house wires according to standard electrical codes (black to black, white to white, ground to ground). Secure connections with wire nuts.
4. **Mount Fixture:** Carefully lift the fixture and attach it to the mounting plate, securing it with the provided screws.
5. **Install Bulbs:** Screw three E26 base bulbs (max 40W each) into the sockets.
6. **Attach Diffuser:** Place the acrylic diffuser plate into the bottom of the shade.
7. **Restore Power:** Turn the power back on at the circuit breaker.



Image: Product details showing the metal base, acrylic cover, and fabric shade.

Dimension



Image: Dimensions and bulb compatibility for the WINGBO ceiling light.

Your browser does not support the video tag.

Video: Official WINGBO video demonstrating the 15.7" Modern 3-Light Flush Mount Ceiling Light. This video shows the light fixture in various settings and highlights its design and illumination.

Your browser does not support the video tag.

Video: Official WINGBO video showcasing the Modern Drum Shape Flush Mount Ceiling Light. This video provides a closer look at the light's design and how it appears when installed.

Operating Instructions

This ceiling light fixture operates via a standard wall switch (not included). Ensure the switch is in the "ON" position for illumination.

- **Turning On/Off:** Use your existing wall switch to turn the light fixture on or off.

- **Light Output:** The fixture provides up to 1500 lumens of warm white light, suitable for general room illumination.
- **Soft Illumination:** The acrylic shade ensures a soft, diffused light output, reducing glare and eye strain.



Image: The ceiling light shown in both ON and OFF states.

Maintenance

Regular maintenance will help prolong the life and appearance of your light fixture.

- **Cleaning:** Dust the fixture regularly with a soft, dry cloth. For more thorough cleaning, wipe with a damp cloth and mild soap, then dry immediately. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure power is off before replacing bulbs. Allow old bulbs to cool completely. Use only E26 base bulbs with a maximum wattage of 40W.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

Troubleshooting

If you encounter issues with your light fixture, refer to the following common solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wiring connection. Faulty bulb(s).	Check circuit breaker and wall switch. Turn off power, check and secure wiring. Replace bulb(s).
Light flickers.	Loose bulb. Incompatible dimmer switch (if applicable). Faulty bulb.	Tighten bulb(s). Ensure dimmer switch is compatible with bulb type. Replace bulb(s).
Light is too dim/bright.	Incorrect bulb wattage. Bulb type not suitable for desired brightness.	Ensure bulbs are within the 40W max limit. Replace with bulbs of appropriate lumen output for your needs.

If problems persist after trying these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	WINGBO
Model Name	WBFM-KY11-SP-FBA
Color	Brown
Material	Acrylic, Metal, Fabric
Style	Modern
Light Fixture Form	Close to Ceiling
Product Dimensions	15.7" Diameter x 5.9" Height (approx. based on images)
Power Source	Corded Electric
Installation Type	Semi Flush Mount
Light Source Type	Compatible with LED, Incandescent, Halogen, CFL
Number of Light Sources	3
Voltage	120 Volts (AC)
Wattage (Max)	40 watts per bulb
Bulb Base	E26
Brightness	1500 lumens (total, typical for 3x40W equivalent)
Item Weight	5.14 pounds (2.34 Kilograms)
Indoor/Outdoor Usage	Indoor

Feature	Detail
Water Resistance Level	Not Water Resistant

Warranty and Support

WINGBO is committed to providing superior products and customer satisfaction. If you encounter any problems with your product, please contact us directly via the Amazon Message Box for assistance. Please refer to your purchase documentation for specific warranty details and duration.
For further information or support, please visit the official WINGBO Store on Amazon:WINGBO Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question