De'Longhi ECAM 22.110B/22.115B

De'Longhi ECAM 22.110B/22.115B Fully Automatic Espresso Machine User Manual

1. Important Safety Instructions

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your mains voltage.
- Always unplug the appliance from the power outlet before cleaning and when not in use.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep children away from the appliance during operation.
- Use only original De'Longhi spare parts and accessories.

2. Product Overview

The De'Longhi ECAM 22.110B/22.115B is a fully automatic espresso machine designed to deliver high-quality coffee beverages with ease. Familiarize yourself with its components:





Figure 2.1: Front view of the De'Longhi ECAM 22.110B/22.115B fully automatic espresso machine, showcasing its sleek black design and control panel.



Figure 2.2: Angled view of the De'Longhi ECAM 22.110B/22.115B, highlighting its compact footprint and side water tank access.

2.1 Key Components

- **Control Panel:** Intuitive buttons and dials for selecting coffee type, strength, and quantity.
- **Coffee Bean Hopper:** Located at the top, for whole coffee beans.
- **Water Tank:** Removable tank, typically located on the side or rear, for fresh water.
- **Steam Wand (Cappuccino System):** For frothing milk and dispensing hot water.
- **Coffee Spouts:** Adjustable height spouts for dispensing coffee into cups.
- **Drip Tray:** Collects excess water and coffee drips, with a removable grounds container.
- **Brew Unit:** The heart of the machine, where coffee is brewed. (Internal, accessible for cleaning).



Figure 2.3: Close-up of a finger interacting with the control panel, showing the intuitive button layout for various coffee selections.



Figure 2.4: A hand lifting the lid of the coffee bean hopper, revealing the compartment for whole coffee beans.



Figure 2.5: Diagram illustrating the dimensions of the De'Longhi ECAM 22.110B/22.115B espresso machine, showing its height, width, and depth.

3. Setup

3.1 Unpacking and Initial Preparation

1. Remove the appliance from its packaging.
2. Remove all protective films and packaging materials.
3. Place the machine on a stable, level surface away from water splashes and heat sources.
4. Wash the water tank, drip tray, and grounds container with warm water and mild detergent. Rinse thoroughly.

3.2 Filling the Water Tank

1. Remove the water tank from the machine.
2. Fill the tank with fresh, cold tap water up to the MAX level indicator.
3. Replace the water tank securely in the machine.

3.3 Adding Coffee Beans

1. Open the coffee bean hopper lid.
2. Pour fresh coffee beans into the hopper. Do not overfill.
3. Close the lid securely.

3.4 First Use and Priming

1. Plug the appliance into a suitable power outlet.
2. Press the ON/OFF button to turn on the machine.
3. The machine will perform an automatic rinse cycle. Place a container under the coffee spouts.
4. Follow any on-screen prompts or indicator lights for initial setup, such as water hardness setting.

4. Operating Instructions

4.1 Making Espresso

1. Ensure the water tank is filled and the bean hopper has enough coffee beans.
2. Place one or two cups under the coffee spouts.
3. Press the button for a single espresso or double espresso, as desired.
4. The machine will grind the beans, brew, and dispense the coffee.

4.2 Adjusting Coffee Strength and Grind

- **Coffee Strength:** Use the coffee strength dial on the control panel to adjust the amount of ground coffee per cup (from mild to strong).
- **Grind Setting:** The grind adjustment dial is located inside the bean hopper. Adjust it only when the grinder is operating. A finer grind produces stronger coffee, a coarser grind produces weaker coffee.

4.3 Using the Steam Wand (Cappuccino System)



Figure 4.1: A hand demonstrating the use of the steam wand to froth milk in a stainless steel pitcher, essential for cappuccinos and lattes.

1. Place a container with cold milk under the steam wand.
2. Turn the steam dial or press the steam button to activate the steam function.
3. Immerse the steam wand into the milk and move the container to create froth.
4. Once desired froth is achieved, turn off the steam.
5. *Important:* Always clean the steam wand immediately after use by wiping it with a damp cloth and purging a small amount of steam.

4.4 Hot Water Dispensing

1. Place a cup under the steam wand.
2. Select the hot water function (refer to your control panel for the specific button/dial).
3. Hot water will be dispensed. Turn off the function when done.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your espresso machine.

5.1 Daily Cleaning

- **Drip Tray and Grounds Container:** Empty and rinse daily.
- **Coffee Spouts:** Wipe with a damp cloth.
- **Steam Wand:** Clean immediately after each use (as described in section 4.3).

5.2 Weekly/Monthly Cleaning

- **Brew Unit:** Remove the brew unit (refer to your machine's specific instructions for removal), rinse under running water, and let it air dry before reinserting. Do this at least once a week.
- **Water Tank:** Clean the water tank thoroughly with a brush and mild detergent.

5.3 Descaling

The machine will indicate when descaling is required. Use only De'Longhi descaling solution and follow the instructions provided with the descaler or in the machine's display/manual.

1. Empty the water tank and fill it with the descaling solution as per instructions.
2. Place a large container under the coffee spouts and steam wand.
3. Initiate the descaling cycle (refer to your machine's specific instructions).
4. After the descaling solution has run through, rinse the tank and run several cycles of fresh water through the machine to flush out any residue.

5.4 Water Filter Replacement

If your machine uses a water filter, replace it regularly as indicated by the machine or every two months, whichever comes first.

6. Troubleshooting

Before contacting customer service, please refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
No coffee dispensed.	Water tank empty; coffee beans empty; brew unit clogged.	Fill water tank; add coffee beans; clean brew unit.
Coffee is too weak.	Grind setting too coarse; insufficient coffee dose.	Adjust grind to finer setting; increase coffee strength.
Machine leaks water.	Drip tray full; water tank not seated correctly; internal leak.	Empty drip tray; re-seat water tank; contact support if leak persists.
Steam wand not producing steam.	Wand clogged; not heated sufficiently.	Clean wand nozzle; wait for machine to heat up fully.

7. Specifications

- **Brand:** De'Longhi
- **Model:** ECAM 22.110B/22.115B
- **Color:** Black
- **Power:** 1450 W

- **Water Tank Capacity:** 1.8 Liters
- **Pump Pressure:** 15 Bar
- **Dimensions (W x D x H):** Approximately 24 x 34 x 43 cm
- **Weight:** 4 kg
- **Special Features:** Rapid Cappuccino System, Cappuccino System

8. Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, or visit the official De'Longhi website for detailed warranty information.
For technical support, spare parts, or service, please contact De'Longhi customer service or visit their official website:
Official De'Longhi Store: De'Longhi Store on Amazon

© 2023 De'Longhi. All rights reserved. Manual Version 1.0

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question