PULIVIA PL-703L

PULIVIA Sports Stopwatch PL-703L User Manual

Model: PL-703L | Brand: PULIVIA

1. Introduction

Thank you for choosing the PULIVIA Sports Stopwatch PL-703L. This digital stopwatch is designed for precise timing in various sports and activities, offering multiple functions including a stopwatch, clock, alarm, and hourly chime. Its ergonomic design and large display ensure ease of use and readability.

Package Contents:

- 1 x PULIVIA Sports Stopwatch PL-703L
- 1 x Lanyard
- 1 x User Manual (this document)



Figure 1: PULIVIA Sports Stopwatch PL-703L with lanyard.

2. Setup

2.1 Initial Use

Upon first use, you may notice a protective film on the display. This is designed to prevent scratches during shipping. Gently peel off the screen protector for optimal display clarity.

2.2 Attaching the Lanyard

Thread the provided lanyard through the loop at the top of the stopwatch. This allows for convenient carrying around your neck, keeping your hands free during activities.

3. Operating Instructions

The PULIVIA Sports Stopwatch features three primary buttons:**MODE** (A), **START-STOP** (B), and **SPLIT-RESET** (C).



Figure 2: Button layout and alarm/hourly tone indicators. Button A is MODE, Button B is START-STOP, Button C is SPLIT-RESET.

3.1 Mode Selection

Press the **MODE** (A) button to cycle through the different functions: Time Display, Stopwatch, and Alarm.

3.2 Setting Time and Date

1. In Time Display mode, press and hold the**SPLIT-RESET** (C) button until the seconds begin to flash.
2. Press the **START-STOP** (B) button to adjust the flashing value (seconds, minutes, hours, month, date, day of week).
3. Press the **MODE** (A) button to move to the next setting.
4. Once all settings are complete, press**SPLIT-RESET** (C) again to exit setting mode.
5. To switch between 12-hour and 24-hour format, press the**START-STOP** (B) button while in Time Display mode (not in setting mode).

3.3 Using the Stopwatch Function

1. Press the **MODE** (A) button until "0:00:00" or a similar stopwatch display appears.
2. Press **START-STOP** (B) to start the timer.
3. Press **START-STOP** (B) again to pause the timer.
4. To resume, press **START-STOP** (B).
5. To record a split time (lap time), press **SPLIT-RESET** (C) while the stopwatch is running. The display will show the split time, while the internal timer continues. Press **SPLIT-RESET** (C) again to return to the running time.
6. To stop the stopwatch completely, press **START-STOP** (B) to pause it, then press **SPLIT-RESET** (C) to reset it to zero.

3.4 Setting the Alarm

1. Press the **MODE** (A) button until the alarm time display appears (e.g., "AL").
2. Press and hold the **SPLIT-RESET** (C) button until the alarm hours begin to flash.
3. Press the **START-STOP** (B) button to adjust the flashing hour.
4. Press the **MODE** (A) button to move to the minutes setting.
5. Press the **START-STOP** (B) button to adjust the flashing minutes.
6. Press **SPLIT-RESET** (C) to exit alarm setting mode.

To turn the alarm ON or OFF: In alarm mode, press the **START-STOP** (B) and **SPLIT-RESET** (C) buttons simultaneously. An alarm icon will appear or disappear to indicate its status.

3.5 Hourly Chime

To turn the hourly chime ON or OFF: In Time Display mode, press the **SPLIT-RESET** (C) and **MODE** (A) buttons simultaneously. A chime icon will appear or disappear to indicate its status.

4. Maintenance

4.1 Cleaning

Wipe the stopwatch with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used. Avoid using harsh chemicals or abrasive cleaners.

4.2 Water Resistance

The stopwatch is designed to be splash-proof and resistant to light rain. **Do not press buttons underwater. Do not submerge the stopwatch in water.**

4.3 Storage

Store the stopwatch in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

5. Troubleshooting

- **Display is blank or dim:** The battery may be low or depleted. Replace the battery (CR2032, typically, though not specified in product data).
- **Buttons are unresponsive:** Ensure the stopwatch is not exposed to extreme temperatures or moisture. Try resetting the device by removing and reinserting the battery (if accessible).
- **Incorrect time display:** Refer to Section 3.2 "Setting Time and Date" to re-adjust the time.
- **Alarm not sounding:** Ensure the alarm function is turned ON (refer to Section 3.4). Check alarm volume settings if applicable (though this model likely has a fixed volume).

6. Specifications

Feature	Detail
Model	PL-703L
Brand	PULIVIA
Material	Plastic
Dimensions (H x W x D)	7 cm x 6.5 cm x 1.7 cm (approx.)
Weight	40 g
Display Size	2.76 inches (diagonal)
Time Precision	1/100th of a second
Functions	Stopwatch, Clock (12/24h), Alarm, Hourly Chime, Split Memory
Water Resistance	Splash-proof (not for underwater use)



Figure 3: Physical dimensions (6.5cm width, 7cm height) and weight (35g, though spec says 40g, I'll use the spec value) of the stopwatch.

7. Warranty and Support

For any questions, concerns, or technical assistance, please contact PULIVIA customer service via Amazon Email. We are committed to providing 7 days / 24 hours customer support to ensure your satisfaction.
Please note that specific warranty details may vary by region and retailer. Retain your proof of purchase for any warranty claims.

© 2023 PULIVIA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question