**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**uehba RAV462**

# uehba RAV462 Replacement Remote Control Instruction Manual

Model: RAV462

## Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your uehba RAV462 Replacement Remote Control. Please read this manual thoroughly before use to ensure proper functionality and to prevent damage.

## Setup

### 1. Installing Batteries

The RAV462 remote control requires two (2) AAA 1.5V batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Back of the remote control with the battery cover removed, showing the two AAA battery slots. This illustrates where to insert the batteries.




RECEIVER
SLEEP
HDMI
1
2
3
4
AV
1
2
3
4
5
AUDIO
1
2
V-AUX
MODE
TUNER
FM
AM
PRESET
TUNING
INFO
MEMORY
MOVIE
MUSIC
SUR. DECODE
STRAIGHT
ENHANCER
SCENE
BD DVD
TV
CD
RADIO
SETUP
OPTION
ENTER
VOLUME
RETURN
MUTE
RAV462
ZA11340



Image: Back of the remote control with the battery cover securely closed. This shows the remote ready for use after battery installation.

### 2. Initial Use

This replacement remote control is pre-programmed for compatible Yamaha AV Receivers. No additional programming is required. Once batteries are installed, the remote is ready for immediate use.

## Operating Instructions

The RAV462 remote control provides full functionality for your compatible Yamaha AV Receiver. Below is a general overview of key buttons and their functions.




Image: Front view of the RAV462 remote control, displaying all buttons and their respective labels. This image helps identify the various controls.

- **RECEIVER (Power)**: Turns the AV Receiver on or off.
- **HDMI 1-4** / **AV 1-4** / **AUDIO 1-2** Selects the input source.
- **MODE**: Cycles through different audio modes.
- **TUNER (FM/AM)**: Selects FM or AM radio bands.

- **PRESET (Up/Down)**: Navigates through radio presets.
- **TUNING (Up/Down)**: Adjusts radio frequency manually.
- **INFO** / **MEMORY**: Displays information or stores settings.
- **MOVIE** / **MUSIC** / **SUR. DECODE** / **STRAIGHT**: Selects sound programs.
- **ENHANCER**: Activates sound enhancer features.
- **SCENE (BD/DVD, TV, CD, OPTION, RADIO)**: One-touch operation for common tasks.
- **SETUP**: Accesses the receiver's setup menu.
- **Navigation Buttons (Up, Down, Left, Right, ENTER)**: Used for menu navigation and selection.
- **RETURN**: Goes back to the previous menu or screen.
- **VOLUME (+/-)**: Increases or decreases the master volume.
- **MUTE**: Silences the audio output.

For detailed functions of specific buttons, please refer to your Yamaha AV Receiver's original instruction manual.

## Maintenance

- **Cleaning**: Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners, solvents, or alcohol, as these may damage the surface.
- **Battery Replacement**: Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA 1.5V).
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Exposure**: Do not expose the remote control to direct sunlight, high temperatures, humidity, or water.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote control does not work. | • Batteries are dead or inserted incorrectly.<br>• Remote control is too far from the receiver.<br>• Obstruction between remote and receiver.<br>• Infrared sensor on receiver is blocked. | • Replace batteries with new AAA 1.5V batteries, ensuring correct polarity.<br>• Move closer to the receiver (within 10 meters).<br>• Remove any objects blocking the line of sight between the remote and receiver.<br>• Ensure the receiver's IR sensor is clear. |
| Some buttons do not respond. | • Batteries are low.<br>• Button is stuck or damaged.<br>• Remote control is not compatible with a specific function of your receiver. | • Replace batteries.<br>• Gently press the button multiple times to dislodge any debris. If still unresponsive, the button may be damaged.<br>• Verify the function exists on your specific Yamaha receiver model and is controlled by the corresponding button on this remote. |
| Short operating range. | • Low batteries.<br>• Interference from strong light sources (e.g., direct sunlight, fluorescent lights). | • Replace batteries.<br>• Ensure the remote is not being used under strong, interfering light. |

## Specifications

- **Model**: RAV462
- **Compatibility**: Yamaha AV Receivers (e.g., HTR-3065, HTR-3066, HTR-3066BL, RX-V373, RAV461, RAV332, RAV304)
- **Connectivity Technology**: Infrared (IR)
- **Power Source**: 2 x AAA 1.5V Batteries (not included)
- **Maximum Range**: 10 Meters (approx. 33 feet)
- **Color**: Black
- **Weight**: 88 Grams (approx. 3.1 ounces)
- **Special Feature**: Ergonomic design

## Warranty Information

This uehba RAV462 Replacement Remote Control comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or battery leakage.
Please retain your proof of purchase for warranty claims.

## Support

For further assistance or inquiries regarding your uehba RAV462 Replacement Remote Control, please contact the seller directly through the platform where the purchase was made.

© 2023 uehba. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0BT85K8N8**

More documents and user manuals: **https://manuals.plus/**