ALLIMITY BN59-01014A

ALLIMITY BN59-01014A Replacement Remote Control User Manual

For Samsung Televisions

1. Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your ALLIMITY BN59-01014A replacement remote control. This remote is designed to be compatible with a wide range of Samsung TV models, offering a direct replacement for original remote controls such as BN59-01078, RM-L919, and BN59-01069A.

Compatible Samsung TV models include, but are not limited to: LN40C630, LN46C600, LN46C610, LN46C630, LN55C610, LN55C630, LN60C630, PN50C550, PN50C590, PN58C550, PN58C590, PN63C550, LN40D630, LN46D610, LN46D630, UN32C5000, UN32C5100, UN37C5000, UN37C5100, UN37C6300, UN40C5000, UN40C5100, UN55C5000, UN55C6300, UN60C6300, PN58C550G1, BN5901041A, LN32C550J1, LN40C610N1, LN40D630M3, LN55C610N1F, LN55C630K1F, LN60C630K1F, PN50C550G1F, PN50C590G4F, LN32C550J1F, LN32C550, LN37C550, LN40C550, LN40C610, PL50C550, PN63C590, LN46C550J, LN46C610N, UN40C6300, UN46C5000, UN46C6300, LN40D610, LN46C550, UA22C4000PD, UA22C4000PM, UA22C4010PM, UA26C4000PD, UA26C4000PM, UA32C4000PD, UA32C4000PM, UA32C5000QF.

2. Setup

The ALLIMITY BN59-01014A remote control requires no programming or setup. Simply insert batteries, and it will be ready for use with your compatible Samsung TV.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.




CE
MADE IN CHINA


AAA
+
+



Figure 1: Battery compartment on the back of the remote control.

Note: Batteries are not included with the remote control. Always use new alkaline batteries for optimal performance.

3. Operating the Remote Control

Once batteries are installed, the remote is ready to operate your compatible Samsung TV. Point the remote directly at the TV's infrared sensor.



Figure 2: Front view of the remote control with button layout.

3.1 Key Functions

- **POWER (Red Button):** Turns the TV on or off.
- **SOURCE:** Selects the input source (HDMI, AV, Component, etc.).
- **Number Buttons (0-9):** Directly select TV channels.
- **CH LIST:** Displays the channel list.

- **VOL (+/-):** Adjusts the volume level.
- **CH (Up/Down):** Changes TV channels sequentially.
- **MUTE:** Mutes or unmutes the TV sound.
- **MENU:** Opens the TV's main menu.
- **GUIDE:** Displays the electronic program guide.
- **INFO:** Displays information about the current program.
- **TOOLS:** Accesses quick settings or tools menu.
- **RETURN:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or function.
- **Directional Pad (Up/Down/Left/Right) & Enter:** Navigates menus and confirms selections.
- **Colored Buttons (A, B, C, D):** Used for specific functions within certain TV applications or menus, as indicated on the TV screen.
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback from connected devices or TV's media player.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Follow the battery installation steps outlined in Section 2.1. Always replace both batteries simultaneously with new ones.

4.2 Cleaning

To clean the remote control, wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm the remote is pointed directly at the TV.
- **Some buttons not working:**
  - This remote is a direct replacement and does not require programming. If specific buttons are not functioning, ensure your TV model is listed as compatible.
  - Clean the remote control to remove any dirt or debris that might be obstructing button presses.
- **Intermittent operation:**
  - Weak batteries are often the cause of intermittent performance. Replace them.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the remote's infrared signal.

6. Specifications

Model Number	BN59-01014A
Brand	ALLIMITY
Dimensions (L x W x H)	4.72 x 1.57 x 0.24 inches (12 x 4 x 0.6 cm)
Weight	2 ounces (approx. 57 grams)
Battery Type	2 x AAA Alkaline Batteries (not included)
Special Feature	No Programming Required
Compatible with	Samsung TVs (models listed in Introduction)

7. Warranty and Support

For any questions, concerns, or support regarding your ALLIMITY BN59-01014A remote control, please contact the manufacturer or your point of purchase. Please refer to your purchase documentation for specific warranty details.

© 2023 ALLIMITY. All rights reserved.