ALLIMITY QYSY-GCBLTV61AI-1-QYSY

ALLIMITY GCBLTV61-AI Replacement Remote Control User Manual

Introduction

This manual provides comprehensive instructions for the ALLIMITY GCBLTV61-AI Replacement Remote Control. Designed to be fully compatible with various Changhong United TV models, this remote offers a direct replacement solution without the need for complex programming.

Compatible TV Models: LED40S26, LED32D2200DS, LED40D1100ISX, UHD49E5600ISX2, GCBLTV61-AI.

Setup

The ALLIMITY GCBLTV61-AI remote control is designed for immediate use upon battery installation. No programming or pairing is required for compatible models.

Battery Installation





Image: Front view of the ALLIMITY GCBLTV61-AI Replacement Remote Control, showing all buttons and the overall design.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by the arrow to open it.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote is ready for operation with your compatible Changhong United TV.

Operating Instructions

The ALLIMITY GCBLTV61-AI remote control functions identically to your original remote. Simply point the remote towards your television's infrared sensor and press the desired button.



Image: Angled view of the ALLIMITY GCBLTV61-AI Replacement Remote Control, highlighting its ergonomic design and button layout.

Button Functions

- **Power Button (Red):** Turns the television on or off.
- **Mute Button:** Mutes or unmutes the television audio.
- **Number Buttons (0-9):** Directly select channels or input numerical values.
- **Volume Up/Down (+/-):** Adjusts the television's volume level.
- **Channel Up/Down (P^/Pˇ):** Changes the television channel.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **MENU Button:** Accesses the main menu of the television.

- **EXIT Button:** Exits the current menu or function.
- **BACK/↩ Button:** Returns to the previous screen or menu.
- **HOME/SOURCE Button:** Switches input sources (HDMI, AV, etc.) or returns to the home screen.
- **APPS Button:** Accesses smart TV applications.
- **INFO Button:** Displays program information.
- **EPG Button:** Opens the Electronic Program Guide.
- **ANT Button:** Switches between antenna/cable inputs.
- **TOOLS Button:** Accesses quick settings or tools menu.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next, Record):**Controls media playback.
- **Color Buttons (Red, Green, Yellow, Blue):** Functions vary depending on the TV model and current menu.
- **3D Button:** Activates or deactivates 3D mode (if supported by TV).
- **LIST Button:** Displays a list of channels or recorded programs.
- **FAV Button:** Accesses favorite channels list.

Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA alkaline batteries.
- **Cleaning:** Use a soft, dry cloth to clean the remote's surface. Do not use liquid cleaners, sprays, or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. If not used for extended periods, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

Troubleshooting

If you encounter issues with your remote control, refer to the following troubleshooting steps.

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Verify that the TV's infrared sensor is clean and not blocked.
- **Limited Range:**
  - Ensure you are within the effective operating range (up to 10 meters) and have a clear line of sight to the TV.
  - Check battery levels; low batteries can reduce range.
- **Certain Buttons Not Working:**
  - This remote is a direct replacement. If a specific button does not work, ensure your TV model supports that function with its original remote.
  - Clean the remote's surface around the button to ensure no debris is preventing proper contact.

Specifications

Feature	Detail
Brand	ALLIMITY
Model	QYSY-GCBLTV61AI-1-QYSY
Compatible Devices	LED40S26, LED32D2200DS, LED40D1100ISX, UHD49E5600ISX2, GCBLTV61-AI
Connectivity Technology	Infrared
Battery Type	2 x AAA Alkaline (not included)
Product Dimensions	4 x 12 x 0.3 cm
Item Weight	50 g
Maximum Range	10 Meters
Special Features	Universal
Controller Type	Button Control
Number of Buttons	10

Warranty and Support

This product is designed for reliability and durability. For any issues not covered in this manual, please refer to the seller's return policy or contact ALLIMITY customer support through your purchase platform.

© 2024 ALLIMITY. All rights reserved.