JORLAI T408Brown-0204

JORLAI 9-in-1 Turntable System User Manual

Model: T408Brown-0204

Introduction

Welcome to the user manual for your JORLAI 9-in-1 Turntable System. This versatile audio system combines vintage charm with modern technology, allowing you to enjoy music from various sources including vinyl records, CDs, cassette tapes, AM/FM radio, USB/SD/MMC cards, and Bluetooth-enabled devices. Please read this manual thoroughly before operating the unit to ensure proper use and to maximize your listening experience.



Figure 1: Overview of the JORLAI 9-in-1 Turntable System's multi-functional capabilities.

Important Safety Instructions

To reduce the risk of electric shock, fire, etc., please observe the following safety precautions:

- Do not expose this unit to rain or moisture.
- Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this unit during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel.

Package Contents

Please check that all items listed below are included in your package:

- JORLAI 9-in-1 Turntable System
- User Manual
- Remote Control
- 45 RPM Adapter
- Power Adapter

Product Overview

Familiarize yourself with the various components of your JORLAI Turntable System.



Figure 2: Front view of the JORLAI Turntable System.

Main Components:

- **Turntable Platter:** For playing vinyl records.
- **Tone Arm:** Holds the stylus for playing records.
- **Cassette Deck:** For playing and recording cassette tapes.
- **CD Player:** For playing audio CDs.
- **LCD Display:** Shows current mode, track information, and radio frequency.
- **Control Knobs & Buttons:** For power, volume, function selection, tuning, and playback controls.
- **USB/SD/MMC Ports:** For playing digital audio files and encoding.

- **Aux-In Jack:** For connecting external audio devices.
- **Headphone Jack:** For private listening.
- **RCA Line-Out:** For connecting to external speakers or amplifiers.
- **Built-in Stereo Speakers:** For direct audio output.



Figure 3: Rear view with RCA Line-Out connections.

Setup

1. **Unpacking:** Carefully remove the unit from its packaging. Retain the packaging for future transport or storage.
2. **Placement:** Place the unit on a flat, stable surface away from direct sunlight, heat sources, and excessive dust or moisture.
3. **Power Connection:** Connect the power adapter to the DC IN jack on the back of the unit, then plug the adapter into a wall outlet.
4. **Dust Cover:** Ensure the dust cover is properly seated on the hinges.
5. **External Connections (Optional):**

- **RCA Line-Out:** To connect to external speakers or an amplifier, use an RCA cable (not included) to connect the LINE OUT jacks on the back of the unit to the audio input jacks on your external audio system.
- **Aux-In:** To play music from an external device (e.g., smartphone, MP3 player), connect a 3.5mm audio cable (not included) from the device's headphone jack to the AUX IN jack on the front of the unit.

Operating Instructions

1. Turntable Operation (Vinyl Player)



Figure 4: Turntable components and speed settings.

1. Lift the dust cover.
2. Place a vinyl record on the turntable platter. If playing a 45 RPM single, place the 45 RPM adapter on the center spindle.
3. Select the appropriate speed (33, 45, or 78 RPM) using the speed selector switch.
4. Move the AUTO STOP switch to "ON" for automatic stop at the end of the record, or "OFF" for continuous play.

Note: Some records may stop prematurely or continue playing if "AUTO STOP" is "ON".

5. Gently lift the tone arm using the cue lever and position the stylus over the desired track of the record.
6. Lower the tone arm slowly onto the record using the cue lever. The music will begin to play.
7. Adjust the volume using the VOLUME knob.
8. At the end of the record, the tone arm will automatically return to its rest (if AUTO STOP is ON) or you can manually lift it and return it to the rest.

2. CD Player Operation



Figure 5: CD and Cassette playback sections.

1. Press the FUNCTION SELECT button to choose "CD" mode.
2. Press the OPEN/CLOSE button to open the CD tray.
3. Place a CD (label side up) into the tray and press OPEN/CLOSE again to close it.
4. The unit will read the CD, and the total number of tracks will appear on the LCD display.

5. Press the PLAY/PAUSE button to start playback. Press again to pause.
6. Use the SKIP FORWARD/BACKWARD buttons to navigate between tracks.
7. Press the STOP button to stop playback.

3. Cassette Player Operation

1. Press the FUNCTION SELECT button to choose "TAPE" mode.
2. Press the EJECT/STOP button to open the cassette door.
3. Insert a cassette tape into the deck with the open edge facing upwards. Close the cassette door firmly.
4. Press the PLAY button to start playback.
5. Use the FAST FORWARD (FF) and REWIND (REW) buttons to quickly move through the tape.
6. Press the PAUSE button to temporarily stop playback. Press again to resume.
7. Press the EJECT/STOP button to stop playback and eject the tape.
8. **Recording to Cassette:** This unit supports recording from Vinyl, CD, USB/SD, Aux-In, and Radio to cassette. Insert a blank cassette, select the desired source, and press the RECORD button on the cassette deck.

4. Bluetooth Connection



Figure 6: Bluetooth connectivity for streaming music.

1. Press the FUNCTION SELECT button to choose "BT" (Bluetooth) mode. The LCD display will show "BT" and flash, indicating it's in pairing mode.
2. Enable Bluetooth on your smartphone, tablet, or other Bluetooth-enabled device.
3. Search for "JORLAI" or "T408Brown-0204" in your device's Bluetooth list and select it to pair.
4. Once successfully paired, the "BT" indicator on the display will stop flashing and remain solid.
5. You can now play music from your device through the JORLAI system. Use your device's controls for playback, or the system's PLAY/PAUSE, SKIP FORWARD/BACKWARD buttons.

5. AM/FM Radio Operation

1. Press the FUNCTION SELECT button to choose "RADIO" mode.
2. Press the AM/FM button to switch between AM and FM bands.
3. Rotate the TUNING knob to manually tune to your desired radio station. The frequency will be displayed on the LCD.

4. For better FM reception, extend the FM wire antenna located at the back of the unit. For AM reception, rotate the unit for optimal signal.

6. USB/SD/MMC Playback and Encoding

1. Insert a USB flash drive into the USB port or an SD/MMC card into the card slot.
2. Press the FUNCTION SELECT button to choose "USB" or "SD" mode. The unit will automatically detect and start playing compatible audio files (MP3, WAV).
3. Use the PLAY/PAUSE, SKIP FORWARD/BACKWARD buttons for playback control.
4. **Encoding (Recording to USB/SD):** This unit allows you to record audio from Vinyl, CD, Cassette, Aux-In, or Radio directly to a USB drive or SD card in MP3 format.
    - Select the desired source (e.g., Vinyl, CD).
    - Insert your USB drive or SD card.
    - Start playing the source audio.
    - Press the REC button on the unit. The recording will begin.
    - Press the REC button again to stop recording. The recorded file will be saved on your USB drive or SD card.

7. Aux-In and RCA Line-Out Usage

- **Aux-In:** Connect an external audio device to the AUX IN jack using a 3.5mm audio cable. Select "AUX" mode using the FUNCTION SELECT button. Audio from the external device will play through the system's speakers.
- **RCA Line-Out:** Connect the RCA LINE OUT jacks on the back of the unit to the audio input of an external amplifier or powered speakers. This allows you to enjoy the system's audio through a larger sound system.

8. Remote Control Usage

The included remote control allows for convenient operation of various functions from a distance.

- **Power:** Turn the unit ON/OFF.
- **Function Select:** Switch between modes (Vinyl, CD, Tape, Bluetooth, Radio, USB/SD, Aux).
- **Volume +/-:** Adjust the master volume.
- **Playback Controls:** Play/Pause, Stop, Skip Forward/Backward (for CD, USB/SD, Bluetooth).
- **Tuning:** For radio mode.
- **Record:** Initiate recording to USB/SD or Cassette.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not active.	Ensure power cord is securely plugged in; Try a different outlet.
No sound	Volume too low; Incorrect function selected; External speakers not connected properly.	Increase volume; Select correct function (e.g., PHONO, CD, BT); Check RCA connections.
Turntable not spinning or playing	Speed setting incorrect; Tone arm not lowered; Auto-stop engaged prematurely.	Select correct RPM; Lower tone arm onto record; Try setting AUTO STOP to "OFF".

Problem	Possible Cause	Solution
Bluetooth pairing failed	Unit not in BT mode; Device too far; Bluetooth not enabled on external device.	Ensure unit is in BT mode; Move device closer; Enable Bluetooth on your device and re-scan.
Poor radio reception	Antenna not extended/positioned correctly.	Extend FM wire antenna; Rotate unit for better AM reception.
Cassette door not closing properly	Cassette tape not inserted correctly.	Ensure the cassette tape is fully and correctly seated in the tray before closing the door.

Maintenance

- **Cleaning the Unit:** Use a soft, dry cloth to wipe the exterior of the unit. Do not use abrasive cleaners or solvents.
- **Cleaning the Stylus:** Periodically clean the stylus tip with a soft brush, brushing from back to front.
- **Cleaning Records:** Use a record cleaning brush or cloth to remove dust and debris from your vinyl records before playing.
- **Dust Cover:** Keep the dust cover closed when not in use to protect the turntable from dust.

Specifications

Feature	Detail
Brand	JORLAI
Model Number	T408Brown-0204
Dimensions (L x W x H)	32 x 29 x 20 cm (12.7 x 11.4 x 7.8 inches)
Weight	Approx. 9.6 lbs
Power Voltage	AC110V~130V
Turntable Speeds	33 1/3, 45, 78 RPM
Connectivity	Bluetooth, USB, SD/MMC, Aux-In, RCA Line-Out
Media Playback	Vinyl, CD, Cassette, MP3/WAV (from USB/SD)
Radio	AM/FM PLL Digital Radio
Encoding	USB/SD from Vinyl, CD, Cassette, Aux-In, Radio
Included Components	Turntable, User Manual, Remote Control, 45 RPM Adapter, Built-in Speakers

Warranty and Support

JORLAI is committed to providing high-quality products. For any questions regarding your product, technical support, or warranty claims, please contact JORLAI customer service.
While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty-related inquiries. JORLAI aims to resolve any issues and provide assistance.
For more information, you may visit the official JORLAI brand page or contact their support channels.

© 2024 JORLAI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is my JORLAI T408Brown-0204 turntable system not recording to a USB drive?

To record audio from Vinyl, CD, Cassette, Aux-In, or Radio to a USB drive on your JORLAI T408Brown-0204, please follow these steps:Select the Source: Use the FUNCTION SELECT button to choose the mode you...

Read full answer