Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

One For All WM7476

One For All WM7476 Quadpod TV Stand User Manual

1. Introduction

This manual provides detailed instructions for the safe and efficient assembly, operation, and maintenance of your One For All WM7476 Quadpod TV Stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The One For All WM7476 Quadpod TV Stand is designed to securely hold televisions up to 70 inches, offering a stylish and flexible viewing solution with 360-degree rotation capability.

2. Safety Information

- **Weight Capacity:** Do not exceed the maximum weight capacity specified for this stand. Refer to the specifications section for details.
- **Secure Fastening:** Ensure all screws, bolts, and connections are securely tightened before placing a television on the stand.
- **Stability:** Place the stand on a flat, stable, and level surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the assembly area. Do not allow children to climb on or play with the stand.
- **Professional Assistance:** If you are unsure about any part of the assembly or installation process, consult a qualified professional.
- **Cable Management:** Properly route all cables to prevent tripping hazards and damage to equipment.

3. Package Contents

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Main Vertical Pole
- Quadpod Base Legs (4 pieces)
- TV Mounting Brackets (2 pieces)
- Hardware Kit (various screws, washers, spacers for TV mounting)
- Assembly Tools (e.g., Allen key)

- Cable Management Clips/Ties

4. Setup Instructions

Follow these steps carefully to assemble your One For All WM7476 Quadpod TV Stand.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Assemble the Quadpod Base:** Attach the four wooden legs to the central hub of the quadpod base. Ensure they are firmly secured using the provided screws and tools.
3. **Attach Main Pole:** Insert the main vertical pole into the assembled quadpod base. Secure it with the designated fasteners, ensuring it is upright and stable.
4. **Attach TV Mounting Brackets to TV:** Identify the correct screws and spacers from the hardware kit that fit the VESA mounting holes on the back of your television. Attach the two TV mounting brackets to your television. Ensure they are level and securely fastened.
5. **Mount TV onto Stand:** With assistance, carefully lift your television and hook the attached mounting brackets onto the main vertical pole of the stand. Secure the TV to the stand using the safety screws or clips provided. Double-check that the TV is level and stable.
6. **Cable Management:** Route all television and accessory cables neatly along the main pole using the provided cable management clips or ties. This helps maintain a clean appearance and prevents accidental disconnections.



Image 1: Fully assembled One For All WM7476 Quadpod TV Stand. This image shows the complete stand with its central pole and four wooden legs, ready for a television to be mounted.



Image 2: Close-up view of the Quadpod base. This image highlights the connection point where the wooden legs meet the central hub, illustrating the sturdy design of the stand's foundation.

5. Operating Instructions

The One For All WM7476 Quadpod TV Stand is designed for ease of use and flexibility.

- **360-Degree Rotation:** Gently rotate your television to achieve the desired viewing angle. The stand allows for full 360-degree rotation, providing optimal viewing from various positions in a room.
- **Cable Management:** Utilize the integrated cable management system to keep all cables organized and out of sight. This enhances the aesthetic appeal and prevents clutter.



Image 3: Television mounted on the stand, showcasing accessory shelves. This image demonstrates how additional media devices can be neatly integrated with the stand, maintaining a clean setup.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your TV stand.

- **Cleaning:** Clean the stand with a soft, dry, or slightly damp cloth. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Periodic Inspection:** Periodically check all screws, bolts, and connections to ensure they remain tight. Re-tighten if necessary.
- **Damage Check:** Inspect the stand for any signs of wear, damage, or instability. If any issues are found, discontinue use and contact customer support.

7. Troubleshooting

If you encounter any issues with your One For All WM7476 Quadpod TV Stand, refer to the following common solutions:

- **TV Not Level:** Ensure the TV mounting brackets are correctly aligned and securely fastened to both the TV and the stand. Adjust as needed.
- **Stand Unstable:** Verify that the stand is placed on a flat, level surface. Check that all four quadpod legs are fully extended and securely tightened to the central hub.

- **Difficulty Rotating TV:** Ensure no cables are snagged or obstructing the rotation mechanism. Check that the TV is not pressing against any walls or furniture.
- **Missing Parts:** If any parts were missing upon unboxing, do not proceed with assembly. Contact One For All customer support immediately for replacement parts.

8. Specifications

Brand	One For All
Model Number	WM7476
Compatible Devices	Television
Maximum TV Size	Up to 70 inches
Rotation	360 degrees
Material	Metal, Wood
Mounting Type	Floor Stand

9. Warranty and Support

For detailed warranty information, product registration, or technical support, please visit the official One For All website or contact their customer service department directly. Keep your purchase receipt as proof of purchase.

One For All Official Website: www.oneforall.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTZ4JTKQ

More documents and user manuals: **https://manuals.plus/**