Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jufjsfy L-088AM

Jufjsfy L-088AM Portable Radio & MP3 Player

Instruction Manual

1. Introduction

Thank you for purchasing the Jufjsfy L-088AM Dual Band Portable Mini Pocket Digital Auto AM FM Radio Receiver with MP3 Music Audio Player Speaker. This device combines the functionality of a radio and an MP3 player in a compact, portable design. This manual provides detailed instructions for its setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

2. Product Overview

The Jufjsfy L-088AM is designed for ease of use and portability, offering both AM/FM radio reception and MP3 playback capabilities from external storage. It features a built-in rechargeable battery and a clear digital display.

Key Features:

- Dual Band AM/FM Radio: Automatic scanning and memory channels.
- MP3 Player: Supports playback from TF card and USB drive (up to 16GB).
- Rechargeable Battery: Integrated 600mAh (marked 800mAh) -5C Lithium battery.
- Digital Number Buttons: Direct selection of radio channels and MP3 tracks.
- Audio Input: Connects to external audio sources like computers, phones, etc.
- Built-in LED Flashlight.
- Compact and Portable Design.

Component Identification:



Figure 2.1: Front View

Shows the speaker grille on the left, digital display, and numeric keypad with playback controls on the right. The display shows the frequency, and buttons include LED, REP, 0-9, previous/next track, play/pause, and mode (M).



Figure 2.2: Side View (Ports)

Illustrates the various input/output ports on the side of the device. From top to bottom: Mini USB charging port (DC5V), standard USB port for flash drives, TF card slot, 3.5mm AUX input, and 3.5mm earphone jack. A wrist strap is also visible.



Figure 2.3: Back View (Battery Compartment)
Shows the rear of the device with the removable cover for the battery compartment. A product label with model number L-088AM, rated power, and input specifications is affixed to the back. A 'QC PASSED' sticker is also visible.

3. Setup

3.1 Initial Charging

Before first use, fully charge the device. The internal 600mAh (marked 800mAh) rechargeable -5C battery requires approximately 2-3 hours for a full charge.

1. Locate the Mini USB charging port (DC5V) on the side of the device (refer to Figure 2.2).
2. Connect the provided USB charging cable to the Mini USB port on the radio.
3. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
4. The charging indicator light (if present, typically red) will illuminate during charging and turn off or change color when fully charged.

Note: *Ensure the input power is 5V 500mA for optimal charging.*

3.2 Powering On/Off

Locate the power switch, typically on the top or side of the device. Slide the switch to the "ON" position to power on the radio. Slide it to the "OFF" position to power off.

4. Operating Instructions

4.1 Mode Selection

Press the **M** (Mode) button to switch between different modes: FM Radio, AM Radio, MP3 Player (USB/TF card), and AUX Input.

4.2 Radio Operation (AM/FM)

1. **Select Radio Mode:** Press the **M** button until "FM" or "AM" appears on the display.
2. **Automatic Channel Scan:** Press and hold the **Play/Pause** button (►▮▮) to initiate an automatic scan. The radio will scan and save all available channels.
3. **Manual Tuning/Channel Selection:**
    - Use the **Previous** (◄◄) and **Next** (►►) buttons to navigate through saved channels.
    - Alternatively, use the numeric keypad (0-9) to directly input a channel number (e.g., for 105.7 FM, input 1-0-5-7).

4.3 MP3 Player Operation

The device supports MP3 playback from a TF (MicroSD) card or a USB flash drive (maximum 16GB).

1. **Insert Storage:** Insert a TF card into the TF card slot or a USB drive into the USB port (refer to Figure 2.2).
2. **Select MP3 Mode:** Press the **M** button until the display indicates MP3 mode (e.g., "USB" or "TF"). The device will automatically start playing music.
3. **Play/Pause:** Press the **Play/Pause** button (►▮▮) to pause or resume playback.
4. **Next/Previous Track:** Use the **Next** (►►) and **Previous** (◄◄) buttons to skip tracks.
5. **Direct Track Selection:** Use the numeric keypad (0-9) to directly input the track number.
6. **Repeat Function:** Press the **REP** button to cycle through repeat modes (e.g., Repeat One, Repeat All).

4.4 AUX Input Mode

Connect an external audio device (e.g., smartphone, computer) to the 3.5mm AUX input port using an audio cable (not included). Press the **M** button to switch to AUX mode. The device will then play audio from the connected external source.

4.5 Volume Control

The volume is typically controlled by a rotary dial or dedicated volume buttons (not explicitly shown in images, but common for such devices). Adjust to your desired listening level.

4.6 LED Flashlight

Press the **LED** button to turn the built-in flashlight on or off.

5. Maintenance

5.1 Cleaning

- Ensure the device is powered off before cleaning.
- Wipe the exterior with a soft, dry cloth.

- Do not use abrasive cleaners, solvents, or strong chemicals, as these may damage the surface.

5.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the device regularly, even if not in use, to maintain battery health.
- If storing the device for an extended period, charge it to about 50% and recharge every few months.
- Do not expose the battery to extreme temperatures.

6. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Battery is depleted.	Charge the device for 2-3 hours.
No sound from speaker.	Volume is too low or muted.	Increase the volume.
Poor radio reception.	Weak signal; antenna not extended.	Extend the telescopic antenna fully. Try repositioning the radio.
MP3 player not reading USB/TF card.	Card/drive not inserted correctly; unsupported format; corrupted files; card/drive capacity too large.	Ensure card/drive is fully inserted. Check if files are MP3 format. Ensure capacity is 16GB or less. Try another card/drive.
Buttons are unresponsive.	Temporary software glitch.	Power off the device, wait a few seconds, then power it back on.

7. Specifications

Feature	Specification
Model	L-088AM (Manufacturer Model: 332175)
Input Power	5V 500mA
Maximum Output	3W
Battery Capacity	600mAh (marked 800mAh) rechargeable -5C Lithium battery
Signal to Noise Ratio	87dB
MP3 Decoding	8-320Kbps
FM Radio Frequency	87.5-108MHz
AM Radio Frequency	522-1710KHz

Feature	Specification
Loud Speaker	45mm 4 ohm 3W (Internal magnetic)
Charging Time	2-3 hours
Play Time	2-10 hours (depending on usage)
Material	Acrylonitrile Butadiene Styrene (ABS)
Dimensions	127 x 59 x 24 mm (Product); 14.5 x 7 x 4.5 cm (Package)
Weight	177 g
Connectivity	USB, 3.5mm Audio
Special Features	Built-In Flashlight, Portable, Rechargeable

8. Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your seller directly. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2023 Jufjsfy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BTZWVNRR

More documents and user manuals: **https://manuals.plus/**