ebm-papst A6D800-AD01-01

Ebm-papst A6D800-AD01-01 Axial Cooling Fan Instruction Manual

Model: A6D800-AD01-01 | Brand: ebm-papst

1. Introduction

This manual provides essential information for the safe and efficient installation, operation, and maintenance of the ebm-papst A6D800-AD01-01 Axial Cooling Fan. Please read this manual thoroughly before attempting any installation or operation.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in electric shock, fire, serious injury, or death.

- Always disconnect power before installing, servicing, or cleaning the fan.
- Installation and electrical connections must be performed by qualified personnel in accordance with all local and national electrical codes.
- Ensure proper grounding of the fan.
- Do not operate the fan if any parts are damaged or missing.
- Keep hands, clothing, and other objects away from moving parts.
- The fan is designed for specific voltage and frequency. Verify compatibility before connection.
- Protect the fan from moisture and extreme temperatures outside its specified operating range.

3. Product Overview

The ebm-papst A6D800-AD01-01 is an industrial-grade axial cooling fan designed for ventilation and heat dissipation applications. It features a robust motor and durable construction suitable for demanding environments.



Figure 3.1: Front view of the ebm-papst A6D800-AD01-01 Axial Cooling Fan. This image shows the fan's five black blades and the central motor housing.



Figure 3.2: Close-up view of the fan's identification label. The label displays the model number A6D800-AD01-01, manufacturer ebm-papst, nominal voltage (400V), frequency (50Hz), current draw (3.9/2.23A), power consumption (1940/1210W), speed (880/670 min-1), and protection degree (IP54).

4. Technical Specifications

Parameter	Value
Model	A6D800-AD01-01
Brand	ebm-papst
Type	Axial Fan
Motor	M6D138-LA
Nominal Voltage	400VAC

Frequency	50Hz
Speed	880/670 min-1
Power Consumption	1940/1210W
Current Draw	3.9/2.23A
Min. Ambient Temperature	-40°C
Max. Ambient Temperature	+60°C
Weight	23.6KG
Degree of Protection	IP54
Insulation Class	F
Motor Bearing	Ball bearing
Material	Copper (Motor components)




Figure 4.1: Detailed technical drawing illustrating the dimensions and mounting points of the A6D800-AD01-01 axial fan. Key dimensions include diameter, depth, and bolt patterns.

5. Installation

IMPORTANT: Installation must be carried out by a qualified electrician or technician. Ensure all power is disconnected before beginning installation.

1. **Mounting:** Securely mount the fan using appropriate hardware. Refer to Figure 4.1 for mounting dimensions and

bolt patterns. Ensure the mounting surface can support the fan's weight (23.6 KG).

2. **Electrical Connection:**
    - Verify that the supply voltage matches the fan's nominal voltage (400VAC) and frequency (50Hz).
    - Connect the fan to a properly grounded electrical circuit.
    - Follow the wiring diagram provided with the fan (if applicable) or standard industrial electrical practices for 3-phase AC motors.
    - Ensure all connections are tight and insulated to prevent short circuits.
3. **Airflow Direction:** Confirm the fan is oriented to provide the desired airflow direction for your application.
4. **Pre-Operation Check:** Before applying power, visually inspect all connections and ensure no foreign objects are obstructing the fan blades.

6. Operation

Once properly installed and connected, the ebm-papst A6D800-AD01-01 fan is ready for operation.

- **Power On:** Apply power to the fan's circuit. The fan should start rotating smoothly.
- **Monitoring:** During initial operation, observe the fan for any unusual noises, vibrations, or overheating. If any anomalies are detected, immediately disconnect power and investigate the cause.
- **Environmental Conditions:** Operate the fan within the specified ambient temperature range of -40°C to +60°C.

7. Maintenance

CAUTION: Disconnect all power before performing any maintenance.

- **Regular Cleaning:** Periodically inspect and clean the fan blades and housing to prevent dust and debris buildup, which can reduce efficiency and cause imbalance. Use a soft cloth or brush. Do not use harsh chemicals.
- **Bearing Inspection:** The fan uses ball bearings. While generally maintenance-free, listen for unusual bearing noises during operation.
- **Electrical Connections:** Periodically check electrical connections for tightness and signs of corrosion or wear.
- **Physical Inspection:** Inspect the fan for any physical damage, loose components, or excessive vibration.

8. Troubleshooting

Problem	Possible Cause	Solution
Fan does not start	No power supply Incorrect wiring Motor fault	Check power source and circuit breaker. Verify wiring against diagram. Consult qualified technician.
Excessive noise or vibration	Loose mounting hardware Debris on blades Bearing wear Imbalance	Tighten mounting bolts. Clean blades (power off). Consult qualified technician for bearing replacement. Consult qualified technician.
Reduced airflow	Blocked intake/exhaust Dirty blades	Clear obstructions. Clean blades (power off).

Overheating	Insufficient ventilation around motor Overload Motor fault	Ensure adequate clearance for heat dissipation. Verify fan is used within specifications. Consult qualified technician.

9. Warranty and Support

For warranty information, technical support, or service inquiries, please contact your supplier or the manufacturer, ebm-papst, directly. Keep your purchase receipt and product model number (A6D800-AD01-01) readily available when contacting support.

The manufacturer's website for ebm-papst can be found atwww.ebmpapst.com.

© 2023 ebm-papst. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question